

Operation & Maintenance Manual

DIESEL GENERATOR, POWER UNIT ENGINE

D1146, P086TI, DP086TA, DP086LA, PU086TI, PU086TI

Forward

This Operation and Maintenance Manual provides information on engine management and maintenance techniques to customers and technicians of Hyundai Doosan Infracore's <a href="https://doi.org/10.1016/j.j.goo.j.g

To provide the best engine to our customers, the <u>D1146/D1146T/P086TI/PU086TI/DP086TA/DP086LA</u> diesel engine is designed to satisfy all requirements for low noise, economic fuel consumption, high speed and durability with the latest technology and quality.

Exact operation and proper maintenance are essential for operating engines for an extended time with optimum conditions and best performance. This Operation and Maintenance Manual provides detailed descriptions of specifications, specified values, defect diagnosis, component diagrams, and drawings for easier and more precise understanding of the product and for proper maintenance and troubleshooting.

With the help of the recommended operation methods and procedures, high-level maintenance techniques and safety of workers can be ensured. Please read and understand this manual before working with our engines.

To ensure best performance and quality as well as to enhance maintenance techniques, Hyundai Doosan Infracore is doing it's best to continuously develop and invest. The design of our product may be changed without prior notice and Hyundai Doosan Infracore shall not be held liable for the failure of this manual to contain all the design changes made to improve the product.

We, Hyundai Doosan Infracore, do our best to provide more convenient and safe maintenance techniques and to meet the requirements of our customers. If you have any questions or find any errors in this Operation and Maintenance Manual, please do not hesitate to contact us.

Thank you for purchasing our engine and we hope this Operation and Maintenance Manual be helpful for you.

2022. 06. 950106-062012EN Hyundai Doosan Infracore

- * Items exempted from warranty coverage
 - Malfunctions resulting from failing to comply with the proper handling instructions, regular inspections, and machine storage techniques specified in the user manual
 - Malfunctions resulting from failing to have the machine repaired at a designated dealer or center, or resulting from the use of non-genuine parts
 - · Malfunctions resulting from unauthorized modifications, changes, or external hardware
 - · Malfunctions resulting from incorrect operation by the user, delayed repairs, accidents, and natural disasters
- * The contents of this operation and maintenance manual are the exclusive property of Hyundai Doosan Infracore. Any unauthorized reproduction, printing and distribution thereof are strictly prohibited.

Table of contents

١.	General Introduction	
	General information	3
	Danger, warning, caution, and note	4
	Engine maintenance	7
2.	Operation and maintenance	9
	Starting and stopping of the engine	11
	Break-in period of the engine	13
	Operation in winter	15
	Inspection and repair of the engine	16
3.	Performance and specifications	17
	Engine specifications and performance	19
	Exterior view drawing of the engine (D1146/PU086)	24
	Exterior view drawing of the engine (D1146T/PU086T)	26
	Exterior view drawing of the engine (P086TI)	28
	Exterior view drawing of the engine (DP086TA)	30
	Exterior view drawing of the engine (DP086LA)	33
	Exterior view drawing of the engine (PU086TI)	36
	Engine identification number	39
4.	Regular inspection	41
	General information	43
	Regular inspection table	44
	Cooling system	47
	Lubrication system	52
	Fuel system	56
	Intake/exhaust system	64
	Cylinder block/head	67
	Electric system	69
	Others/driving system	70
5.	About the engine	73
	Marking system of units	75
	Tightening torque	76
	Engine Disassembly	79
	Engine Assembly	88

6.	Cooling system	107
	General information	109
	Thermostat	111
7.	Lubrication system	113
	General information	115
	Oil pump	117
8.	Fuel system	119
	General information	121
	Fuel injection pump	124
	Fuel feed pump	140
9.	Intake/exhaust system	145
	General information	147
	Turbocharger	148
10	D. Cylinder block/head	157
	General information	159
	Cylinder block	160
	Cylinder head	161
	Valve	163
	Rocker arm	166
	Tappet and push rod	168
	Camshaft	169
11	1. Electric system	171
	General information	173
	Starter	174
	Alternator	178
12	2. Others/driving system	183
	General information	185
	Crankshaft	186
	Piston	189
	Connecting rod	193
	Others	194

1. General introduction

General information	3
General Information	3
Danger, warning, caution, and note	4
General Information	4
General Instructions	4
Precautions in Starting the Engine	5
Cautions for Inspection and Repair	5
General Repair	6
Other Safety Instructions and Environmental Pollution	6
Use of Genuine Parts	6
Engine maintenance	7
Prevention of damage and abrasion	7
Prevention of Pollution	7
Handling of Engine Oil	7



General information

General Information

This Operation and Maintenance Manual provides the most efficient methods for engine maintenance as well as quick, efficient methods to determine the cause of engine faults to ensure that any actions taken by authorized skilled technicians are done in the most efficient and efficient way possible. If maintenance is performed by unskilled technicians, or maintenance without the specified tools and facilities, serious bodily injury or critical faults in engine performance may occur.

Regular inspection and maintenance are required to maintain long-term optimal engine conditions and best performance. In the event that a part must be replaced, only genuine parts as defined by the parts the list (PARTS BOOK) should be used. Hyundai Doosan Infracore shall not be held liable for any critical damage or faults which may be caused by the use of unauthorized or remanufactured parts. The maintenance methods stated in this Operation and Maintenance Manual are the most efficient and safest work procedures. Some work procedures require special tools. For questions about genuine parts and special tools, please contact us.

This Operation and Maintenance Manual includes 'Danger,' 'Warning,' and 'Caution' in order to reduce possible injuries and engine faults which may occur while performing maintenance. If workers do not follow the instructions, critical faults in engine performance and operation or serious bodily injury may occurred. 'Danger,' 'Warning,' and 'Caution' instructions must be followed. However, we inform you that it is not possible to describe all possible and unexpected dangers which may arise while performing engine maintenance.

1. General introduction

Danger, warning, caution, and note

General Information

This Operation & Maintenance manual divides maintenance operations such as performing engine checks, trouble-shooting, or diagnosing faults into three categories, "Danger," "Warning," and "Caution." In addition, Note) is used to provide additional descriptions and information required for maintenance technicians to successfully operate Hyundai Doosan Infracore engines. The recommended repair methods and 'Danger,' 'Warning,' and 'Caution' can enhance the degree of completion of engine maintenance and prevent bodily injury which may occur to workers. However, this manual cannot predict all possible risks..

↑ DANGER

Workers MUST observe instructions, otherwise fatal or serious injuries to workers and other persons may occur.

↑ WARNING

Workers must follow this instruction as failing to do so may result in the death or serious bodily harm? of workers or others.

ACAUTION

Workers must observe this instruction since failing to do so may cause critical faults which can have impact on the engine performance and operation.

Note) Indicates additional description, information, and references for workers' easy understanding.

General Instructions

- In order to maintain the best long term performance and safety, please read and understand this manual and execute routine inspections and regular inspections.
- We have divided the content of this manual into causes of bodily injury and damage to assets and causes of pollution.

↑ WARNING

When a safety accident, such as skin contact with corrosive acids or fuel, burns with hot oil, exposure of eyes to fuel or antifreeze, occurs while starting, inspecting, or repairing an engine, see a doctor immediately.

↑ WARNING

When a safety accident, such as skin contact with corrosive acids or fuel, burns with hot oil, exposure of eyes to fuel or antifreeze, occurs while starting, inspecting, or repairing an engine, see a doctor immediately.

↑ WARNING

During operating the engine, be careful not to touch the safety guard of cooling fan. Otherwise, it can cause serious injuries such as a cutting of fingers to you by the rotating cooling fan.

↑ WARNING

During operating the engine, be careful not to touch the safety guard of v-belt. Otherwise, it can cause serious injuries such as a cutting of fingers to you by the rotating v-belt.

⚠ WARNING

V-belt safety guard is an optional item for customers. In order to prevent accidents, you should install a vbelt safety guard. If v-belt safety guard is not installed, you should not access to the engine in operating. The engine maker won't be responsible for an accidents or injury arising without an installation of v-belt safety guard.

↑ WARNING

Immediately after stopping the engine or during driving, be careful not to touch a part of turbocharger. Otherwise, it can cause you to severe burns due to a hot turbocharger. If you need to contact the turbocharger for maintenance, you should wait until the temperature of the turbocharger will be lower sufficiently.

↑ WARNING

Immediately after stopping the engine or during driving, be careful not to touch a part of exhaust manifold or heat screen. Otherwise, it can cause severe burns to you due to the hot exhaust manifold or heat screen. In particular, be careful not to touch the heat screen installed on the exhaust manifold because it has also a high temperature.

↑ WARNING

If you need an emergency engine stop, use an electronic emergency stop device installed on a generator at first instead of mechanical emergency stop of engine. It is difficult to operate a mechanical emergency stop device mounted on a fuel pump and it can cause serious burns to you by contact with the exhaust manifold. The operator is requested to install the separate cable for operating the mechanical emergency stop. The engine maker won't be responsible for an accidents or injury arising without an installation of separate auxiliary cable.

Precautions in Starting the Engine

- Before starting the engine, please read this manual carefully and fully understand 'Danger,' 'Warning,' and 'Caution'. If you cannot fully understand it or have any question, please contact us.
- For safety reasons, attach "Warning" signs around engines in operation to keep people other than workers from accessing the engines. Let engine operators know that they are responsible for the safety of the engine room.
- Only authorized people may start and operate engines.
 Unauthorized people should not be allowed to handle engines.
- 4. Do not get close moving or rotating parts while the engine is in operation.
- 5. Do not touch the hot engine during operation since.
- Exhaust gas is poisonous. Fully ventilate before starting engine. If the space is enclosed, ensure that it is well ventilated.
- Keep vicinity of engine, ladders and stairways free of oil and grease. Accidents caused by slipping can have serious consequences.

Cautions for Inspection and Repair

- 1. Inspection and repair of engine should be performed only when the engine is stopped.
- 2. If it is inevitable to perform inspection or repair on the operating engine, do not get close to the rotating parts.

↑ DANGER

When accessories such as necklaces, rings, watches, or gloves become stuck in rotating parts while the engine is running, serious bodily injury may occur.

↑ WARNING

Do not exchange or disassemble a pipe or horse (from the engine fuel circuit, engine oil circuit, coolant circuit, or compressed air circuit) while the engine is running. The leaked liquid may cause bodily injuries.

- Use an engine oil drain container that is large enough to prevent the overflow of engine oil while draining engine oil.
- 4. Open the engine coolant cap after fully cooling the engine to exchange or replenish coolant.

⚠ WARNING

If the coolant cap is opened while the engine is still hot, hot water will spurt out and may cause burns. Open the engine coolant cap after fully cooling the engine.

5. Fuel is highly flammable. Smoking or use of fire around an engine may cause fire.

↑ WARNING

Only refuel when the engine is stopped.

- Mark and separately manage the containers for storing coolant from beverage bottle for avoiding confusion. See a doctor immediately in case of drinking coolant.
- 7. Follow the instructions provided by the battery manufacturer when checking or handling batteries.

MARNING

Battery fluid is corrosive and dangerous because of its explosiveness and toxicity. Therefore, it should only be handled by a skilled technician who specializes in battery fluid.

- 8. Only authorized skilled technicians should repair and maintain engines.
- Only appropriate tools should be used. If the jaws of a wrench are worn out, the wrench might slip during use, causing safety accidents.
- 10. Do not allow other persons to stay or pass under an engine when lifting the engine with a crane. Before lifting the engine, ensure that there is no one around the engine and to secure enough safety space.

1. General introduction

- 11. Before inspecting or replacing the electrical apparatus, disconnect the battery ground wire first. Connect the battery ground wire after completing all required work for checking or replacing the electrical apparatus in order to prevent a short circuit.
- 12. Before performing electric welding works, turn off engine, block the power supply to the engine, and remove the wire harness connector.
- 13. Do not give any electric or mechanical shocks or perform welding works on the electrical apparatus or the ECU.

General Repair

- Wait until the engine is properly cooled down before starting work, since you may get burned by the heated engine.
- 2. Disconnect the battery ground wire from to prevent damage of wires and sensors caused by a short circuit.
- Engine oil and coolant may damage paint and should be stored in a separate container and marked for safe management.
- 4. Store the disassembled parts in a specified space to avoid damage or pollution.
- 5. Use specified and special tools for efficient and safe repair.
- If parts need to be replaced, use only genuine parts for replacement. Using unauthorized or remanufactured parts may cause critical damage and faults in engine performance.
- Replace parts such as cotter pins, gaskets, Orings,seal rings, oil seals, and washers with new ones during repairs. Reuse of parts may be the cause of engine faults and engine may not operate properly.
- Group and store disassembled parts in disassembling order. Due to the fact that bolts and nuts vary in strength, shape and torque according to their assembly position.
 Please divide and store them accordingly to these characteristics.
- Clean disassembled parts to remove foreign substances before inspecting or reassembling parts. Use compressed air to clean the oil holes or holes.
- 10. Thinly spread oil or grease on rotating parts or parts requiring lubrication, before assembling them.
- 11. If required, use a specified adhesive to assemble gaskets to prevent water or oil from leaking.
- 12. Assemble bolts and nuts with the specified tightening torque.
- 13. After completing repairs, conduct a final inspection and perform a test operation to check if all works have been successfully completed.

Other Safety Instructions and Environmental Pollution

Observe the following instructions to protect workers from danger and to prevent the environmental pollution while performing engine repairs.

- 1. Good ventilation and low humidity should be maintained in the work space.
- 2. The workspace should be clean, in good order, and no flammables are allowed in the workshop.
- 3. Smoking is strictly forbidden in the workshop.
- 4. Workers should wear working clothes, protective goggles, and safety shoes.
- 5. Workers are not allowed to wear accessories such as necklaces, rings, watches, and earrings.
- Start the engine in a well-ventilated space and fully ventilate the space before starting engine to prevent carbon monoxide poisoning.
- Wait until the engine is properly cooled down before starting work, since you may get burned by the heated engine.
- 8. Do NOT work on rotating or running parts once the engine has been started.
- 9. Discard oil according to the regulations set forth by the relevant authorities.
- 10. If engine oil or fuel leaks on the floor or is improperly discharged, serious environmental pollution of sea, river or underground water may occur.
- 11. Discard the undiluted anticorrosive agent, antifreeze, filter elements, and cartridges as special wastes.
- 12. Discard coolant and special waste according to the regulations of the appropriate authorities.

⚠WARNING

Failure to observe the regulations of the relevant authorities violates environmental pollution regulations and may be subject to legal penalties.

Use of Genuine Parts

An engine consists of many parts which are mechanically harmonized. To prevent engine faults in advance and use engines with best performance for a long period, maintenance and replacement of expendable parts should be conducted regularly.

Use of genuine parts is recommended. Using unauthorized or remanufactured parts may cause critical damage and faults to engine for which Hyundai Doosan Infracore shall not be held liable.

Engine maintenance

Prevention of damage and abrasion

Using an engine for any purposes other than the designed purpose may cause critical faults to the engine for which Hyundai Doosan Infracore shall not be held liable. For details concerning the usage and purpose of the engine, please direct questions to Hyundai Doosan Infracore Sales Team. Do NOT adjust, convert, or change the ECU without Hyundai Doosan Infracore authorization.

If a problem is found in an engine, figure out and solve the cause to prevent the critical faults in advance.

Use of genuine parts is recommended. Using unauthorized or remanufactured parts may cause critical damage and faults to engine for which Hyundai Doosan Infracore shall not be held liable.

Consider the following while managing engines.

 Use clean, specified, and qualified fuel only. Use fuel recommended in this Operation and Maintenance Manual.

ACAUTION

Using inappropriate or unspecified fuel may cause critical damage and faults in engine performance.

- Do not operate an engine without lubrication oil or coolant. Use only the products (engine oil, cooling water, anticorrosive agent, and etc) recommended by Hyundai Doosan Infracore.
- 3. Always keep surroundings of the engine clean.
- 4. Use fuel recommended in this Operation & Maintenance manual.
- 5. Conduct inspections and exchanges regularly according to the regular inspection table.
- 6. If the engine is overheated, do not stop it immediately, but operate it at idle status for five minutes or more to lower the engine temperature to the proper level.

↑ WARNING

If the radiator cap is opened while the engine is still hot, hot water will spurt out and may cause burns.

7. Check the engine oil level on a flat surface. Do not exceed the maximum of the oil level gauge.

ACAUTION

Immediately replenish engine oil when the engine oil level is below the lower limit of the engine oil gauge.

- 8. If there are gauges for battery, oil pressure and coolant and temperature, check if they indicate a normal status.
- 9. Do not operate engine without coolant.

ACAUTION

Always use coolant mixed with antifreeze. If coolant without antifreeze is used, the coolant may freeze causing the coolant passage in the cylinder block to freeze and damaging the engine.

↑ CAUTION

Do not spray high-pressure water directly on the engine. It may damage engine parts, electronic parts, and wiring.

Prevention of Pollution

Consider the following to manage engine without causing environmental pollution.

- 1. Discharge oil and coolant using collection containers.
- 2. Discard oil and coolant according to the regulations of the relevant authorities.
- Be careful not to let discharged oil and cooling water flow into the ground or the sewer. Otherwise, serious pollution of the drinking water source may occur.
- Classify the oil, filters, and filter cartridges as environmental pollution wastes and discards them according to regulations.
- Classify the antifreeze, cooling water, and anticorrosive agent as hazardous wastes and discards them by observing the regulations.

Handling of Engine Oil

Prolonged and repeated contact of skin with engine oil may cause skin to dry out and contract, causing dermatitis.

Engine oil includes substances toxic to the human body.

Handle engine oil by observing the following safety rules:

- 1. Do not expose skin to used engine oil for a long time.
- 2. Always wear working clothes and gloves.
- 3. If skin comes in contact with engine oil, immediately wipe it off with water, soap or hand cleaners.
- 4. Do not clean skin with gasoline, fuel, thinner, or solvent.
- 5. Apply a skin care cream after cleaning from oil.
- 6. Do not put oil-stained gloves or cloth in ones pocket.

1. General introduction

⚠WARNING

Discard oil according to the regulations set forth by the relevant authorities. Disposing of discharged oil into the ground, sewers, drains, rivers, or the sea will cause serious environmental pollution. Violation of regulations regarding discard of engine oil without observing the handling regulations, will be punished.

2. Operation and maintenance

Starting and stopping of the engine	11
Preparing for Start	11
Starting the Engine	11
Running in	11
During Operation	11
Stopping the Engine	12
Break-in period of the engine	13
General Information	13
Break-in Period of a New Engine	13
Check Points	13
Cold Start Operation	13
Inspection after Starting the Engine	13
Operation in winter	15
Cold Start	15
Preventing Coolant from Freezing	15
Preventing Overcooling of the Engine	15
Engine Oil	15
Inspection and repair of the engine	16
Checking Engine Parts after ProlongedOperation	16
Inspection and Repair of Turbocharger	16
Intake System	16
Exhaust System	16
Lubrication System	16



Starting and stopping of the engine

Preparing for Start

Check the following before starting the engine for the first time after purchase.

- Before starting an engine, check the levels of fuel, coolant, and oil and replenish those fluids if required.
- Check if engine oil level is between the upper and lower limit of the oil level gauge. The upper and lower limit of the oil level gauge indicate the maximum and minimum of the engine oil level.

♠ CAUTION

- When replenishing engine oil, do not exceed the maximum on the oil level gauge. Too much oil may cause damage to the engine.
- The oil required to fill the oil filters and pipes depends upon the engine equipment and use and must be determined individually at the time of initial commissioning. Make a note of the determined quantity.
- 3. Be careful not to mix foreign substances in fuel, engine oil, or coolant while adding the fluid, and keep the fluid clean while it is not in use. Use fuel, oil, and coolant recommended by Hyundai Doosan Infracore. Otherwise, critical damage to the engine may occur

Starting the Engine

Observe the following when starting the engine.

- 1. Insert key in starting lock.
- 2. Moving control lever to idle speed.
- 3. Key switch rotate clockwise.
- 4. Do not operate for longer than 10 seconds at a time.
- 5. After ignition of the engine, take-off the hands in key switch.
- 6. and adjust control lever for desired speed.
- 7. If engine fails to start, release the key, wait about 1 minute, then operate starter again.

 Avoid running the cold engine for any length of time since in any internal combustion engine this is liable to cause increased wear due to corrosion. Prolonged idling is harmful to the environment.

CAUTION

- On initial start of an overhauled engine or after long periods without use, press shutdown lever in "stop" position and operate starter motor for a few seconds (max. 10) until oil pressure is indicated.
- Ensure that the engine can not be started by unauthorized persons.
- Keep no-load operation to a minimum. During no-load operation combustion chamber temperatures drop to the point where fuel does not burn completely, causing slobbering and white smoke. Always have some load connected when the gen set is run for long periods.

Running in

It is recommended that new or overhauled engines should not be operated at a load higher than about 75% manimum load during the first few hours of operation. Initial run-in should be at varying speeds or load. After this initial run-in, the engine should be brought up to fuel output gradually.

During Operation

ACAUTION

Do not overload the engine. Do not exceed the maximum permissible engine tilt. if faults occur, find their cause immediately and have them eliminated in order to prevent more serious damage.

- 1. Oil pressure
- During operation the oil pressure in the engine lubrication system must be monitored. if the monitoring devices register a drop in the lube oil pressure, switch off the engine immediately.
- 2. Coolant temperature
- Operating an engine with too low coolant temperature increases fuel consumption, abrasion of the cylinder liner, and shortens the engine's life span.
- Alternator
 In order to avoid damage to the alternator, observe the following instructions while the engine is running.

2. Operation and maintenance

- 1) Do not switch off the main battery.
- Do not disconnect the battery or pole terminals or the cables
- If during operation the battery charge lamp suddenly lights up, stop the engine immediately and remedy the fault in the electrical system.
- 4) Do not short-circuit the connections of the alternator with those of the regulator or said connection with ground, not even by briefly bringing the connections into contact.
- 5) Do not operate th alternator without battery connection of the alternator with those of the regulator or said connections with ground, not even by briefly bringing the connections into contact.
- 6) Do not operate the alternator without battery connection.

Stopping the Engine

Cut off the main circuit breaker of the generator control panel but do not stop the engine immediately.

Keep running the engine at idle speed for about 5minutes before stopping the engine.

Break-in period of the engine

General Information

Hyundai Doosan Infracore engines are subjected to a final approval test to ensure the provision of high quality engines before being shipped. However, engines are not operated for a long period of time in this test. Therefore, new engines require a break-in period of during the initial 50 hours after delivery. By properly breaking-in an engine, the highest levels of engine performance can be maintained long-term.

Break-in Period of a New Engine

If the engine's bearings are not properly broken in, they may be easily damaged and the lifetime of the engine may be shortened by overloading or high speeds. In order to prevent this, please follow the guidelines below for the initial 50 hours after delivery of new engine.

- Fully warm up the engine until the engine temperature reaches the normal operation condition, before starting operation of the engine.
- 2. Do not overload the engine or operate it at too high RPM.
- 3. Do not operate the engine with high speed at idle.
- 4. Do not rapidly start up or stop the engine.
- 5. Operate the engine with less than 70 % of the engine load.
- Inspection, check, and repair of engines should be managed by officially-certified technicians at certified service centers in compliance with corresponding rules.

Check Points

check the following during the break-in period of a new engine.

1. Periodically check if the engine oil level is between the minimum and maximum limit of the oil level gauge.

ACAUTION

If you cannot accurately check the oil level through the oil level gauge, rotate the oil level gauge to 180 degree, put it in the guide tube, and then pick it out again to check.

2. If the oil indicator lamp on the apparatus is turned on or blinks, the oil pressure may be insufficient. In this case, check the oil level and replenish oil if required. When replenishing engine oil, do not exceed the maximum on the oil level gauge. If the oil level is normal, check other related parts such as the oil pressure sensor, oil pump, or oil line.

ACAUTION

The oil pressure may increase with high rpm and decrease with low rpm. In addition, the pressure of cold oil may be higher at a specific rpm than that of warm oil. This phenomenon may occur when the engine operates properly.

- Check the coolant level to check if the coolant circulates properly. If the coolant in the radiator is not enough, the coolant level indicated may not be accurate.
- Exchange engine oil and oil filter after the break-in period.

♠ CAUTION

If engine oil and oil filter need to be replaced, use only genuine engine oil and parts recommended by Hyundai Doosan Infracore.

Cold Start Operation

Slowly warm up the engine in case of starting up in cold weather or in areas with cold climate. Do not rapidly raise the rpm or load before the engine has not been warmed up. The engine may consume oil until its piston ring is in position. Please check the engine oil level frequently for the initial 50 hours of the break-in period.

Inspection after Starting the Engine

Check the pressure of the engine lubrication system by using the engine oil pressure gauge mounted on the apparatus while the engine is in operation. If pressure decreases on oil pressure gauge, immediately stop the engine. In addition, make sure that the recharge alarm indicator lamp of the alternator is turned off while the engine is operating.

- Tightly connect the +/- terminals to prevent gaps between them. The sheath of battery connection cables should not be damaged or broken.
- If the recharge alarm indicator lamp suddenly turns on or blinks during engine operation and the engine stops, fix the fault of the electric apparatus.

2. Operation and maintenance

3.	If color or odor of exhaust gas is unusual during opera	-
	tion, stop the engine, diagnose the cause and fix the fau	ılt.

4. Check the engine status through the alarm indicator lamp and gauges mounted on the apparatus during operation.

Operation in winter

Cold Start

 The preheat lamp turns on when the key switch is set to "ON." When the preheat lamp goes off, proceed as follows. The pre-heater device activates when the coolant temperature is below 25°C, and the preheating system is automatically adjusted based on the coolant temperature. (The max. preheating time is around 25 seconds) It does not activate when the coolant temperature is over 25°C.

⚠ CAUTION

The engine is equipped with a preheating system for enhancing cold start ability.

- 2. In order to start the engine after the preheat lamp turns off, turn the key switch to the ignition position. When the key switch is turned to the ignition position, the pre-heater plug or air heater runs continuously to make starting the engine easier and reduce white exhaust gas. If the coolant temperature is over 25°C, it is not necessary to operate the pre-heater plug or air heater.
- When the engine starts, set the key switch in the ON position. The timer runs for another 5 minutes even after the engine starts to heat the intake air and quickly eliminate white exhaust gas.

⚠ CAUTION

Do not run the start motor for over 10 seconds. If the engine still cannot be started after preheating, wait for 30 seconds and then perform preheating again before the second attempt to start the engine.

Preventing Coolant from Freezing

When only water used as coolant without mixing with antifreeze, corrosion in the engine, degradation of cooling efficiency, and freezing of the engine in winter may occur. If the engine is not operated for a long period during cold weather or in areas with cold climate, fully discharge the coolant from the engine. Freezing of coolant leads to critical damage to the engine. Please use a mixture of coolant with antifreeze at revised ratio when replacing or replenishing the coolant. The antifreeze prevents coolant from freezing.

Preventing Overcooling of the Engine

When the engine is cooled below the normal operating temperature, thermal efficiency is lowered and fuel consumption as well as abrasion of the cylinder liner may increase. Therefore, the engine should be operated within the normal operating temperature. If the engine has been sufficiently operated, but the temperature of coolant remains-below the normal operating temperature, check the water temperature controller or other parts related to the cooler.

Engine Oil

When viscosity of engine oil increases due to its low temperature during cold weather or in areas with cold climate, the rpm may not be stable after starting the engine. To prevent this, replace oil to engine oil for cold weather or areas with cold climate. When replacing engine oil, use of Hyundai Doosan Infracore genuine engine oil is recommended.

2. Operation and maintenance

Inspection and repair of the engine

Checking Engine Parts after ProlongedOperation

Wear, corrosion, or degradation of engine elements and assemblies may occur, causing lowered performance of engine parts. To maintain high engine performance, check the engine after prolonged operation to enhance durability of the engine.

Unexpected faults may occur in some weak engine parts after normal operation of the engine, when operation time is prolonged. In this case, it is difficult to maintain high engine performance by simply repairing some parts. It is recommended to replace or repair the entire related parts in order to diagnose the causes more accurately and maintainhigh engine performance.

To prevent engine failure in advance and use the engine safely for a long period, perform periodic replacements and inspections.

It is recommended to perform engine adjustments and preventive inspections during spring after the engine was exposed to winter or cold weather. This allows economic, long-term use of the engine without faults.

As the following parts affect the engine output and performance, they should be regularly checked and inspected.

- 1. Parts affecting intake and exhaust
- · Air filter
- · Inter cooler
- turbocharger, silencer
- · Other parts
- 2. Parts affecting lubrication and cooling
- Air filter
- Oil filter
- Antifreeze
- Other parts

Inspection and Repair of Turbocharger

As performance of turbocharger significantly affects the engine performance, regular inspection and repair should be made and inspection and maintenance regulations should be observed.

Intake System

Be careful to handle air filter carefully. In regards to the dry air filter, intake resistance should be small to ensure a smooth intake of air.

Exhaust System

If exhaust gas is leaked from the connections in the exhaust pipe, the turbocharger efficiency is lowered, causing degraded engine output and seizure of related parts in the worst case. As parts related to exhaust and turbocharger are used at high temperature, be careful not to mix the bolts and nuts with other parts when performing repair.

Lubrication System

Inspection and exchange of oil and oil filter should be performed while considering their exchange cycle. Overheated engine oil significantly affects the engine performance as well as the engine itself.

Engine specifications and performance	19
Engine specification	19
Engine output	23
Exterior view drawing of the engine (D1146/PU086) .	24
Front/Rear (D1146/PU086)	24
Left/Right (D1146/PU086)	25
Exterior view drawing of the engine (D1146T/PU086T	·)26
Front/Rear (D1146T/PU086T)	26
Left/Right (D1146/PU086)	27
Exterior view drawing of the engine (P086TI)	28
Front/Rear (P086TI)	28
Left/Right (P086TI)	29
Exterior view drawing of the engine (DP086TA)	30
Front/Rear (DP086TA)	30
Left/Right (DP086TA)	31
Top (DP086TA)	32
Exterior view drawing of the engine (DP086LA)	33
Front/Rear (DP086LA)	33
Left/Right (DP086LA)	34
Top (DP086LA)	35
Exterior view drawing of the engine (PU086TI)	36
Front/Rear (PU086TI)	36
Left/Right (PU086TI)	37
Top (PU086TI)	38
Engine identification number	39
Engine code and manufacturing number	39
Engine number engraving	39
9 9 9	



Engine specifications and performance

Engine specification

Iter	ns	D1146/ PU086	D1146T/ PU086T	P086TI	DP086TA	DP086LA	Remarks
Engine type		4 cycle, in-line, water-cooled type, natu- rally aspirated	4 cycle, in-line, water-cooled type, turbo charged	_	ne, water-coole arged inter cool		
Combustion cha	amber type		D	irect injection typ	ре		
Cylinder liner ty	ре		Re	placeable dry lir	ner		
Timing gear sys	stem			Gear driven type)		
No. of piston rin	ıg		Compr	ession ring 2, oi	l ring 1		
No. of cylinder - (mm)	bore x stroke			6 - 111 × 139			
Total piston disp	olacement (cc)			8,071			
Compression ra	atio	17.9 : 1	17.0 : 1		17.1 : 1		
Engine dimensi		1,224 x 830 x 974	1,224 x 830 x 1,082	1,248 x 918 x 1,102	1,242 x 746 x 1,113	1,242 x 1,122 x 1,113	
Engine weight (kg)	720 / 780	780 / 780		790	1	
Rotation		Counter clockwise				Viewed from flywheel	
Fuel injection order		1 - 5 - 3 - 6 - 2 - 4					
Fuel injection ting	ming	18°	18° / 12°	12°	19° 14°		BTDC static
Injection pump	In - line "AD" type In-line "P" type In-line "P" type		"P" type				
Governor type			governor type SV)	Electrical governor type	Electrical gavernor type		
Injection nozzle	type	Multi-hole type					
Fuel injection points (kg/cm ²)	ressure		214				at 200rpm
Compression pressure (kg/cm²)		28					
Valve clear-	Intake	0.3 ±0.05			at cold		
ance (mm)	Exhaust	0.3 ±0.05					at cold
Intoles webse	Open at			16°			BTDC
Intake valve	Close at	36°				ABDC	
	Open at			46°			BBDC
Exhaust valve	Close at	14°			ATDC		

Iter	ms	D1146/ PU086	D1146T/ PU086T	P086TI	DP086TA	DP086LA	Remarks
Lubrication met	thod		Full for	ced pressure fee	ed type		
Oil pump type			Gear ty	pe driven by ca	mshaft		
Oil filter type			Full	-flow, cartridge t	уре		
Lubricating oil	Max.			15.5			
capacity (lit)	Min.			12			
Oil specifica-	Oil class (API)	API CI-4					
uon	SAE	10W40					
Oil cooler type		Water cooled					
Water pump		Centrifugal type driven by belt					
Cooling Method	t		Fresh	water forced circ	ulation		
Cooling water capacity (lit)		14 / 11					engine only
Thermostat type		Wax pallet type					
Alternator volta (V - A)	ternator voltage - capacity ' - A)						
Starting motor put (V - kW)	voltage - out-	24 -	4.5		24 - 6.0		

ltems		PU0		
		ЕВРРА	ЕВРРВ	Remarks
Engine type		4 cycle water cooled tur	bo charged inter cooled	
Combustion ch	amber type	Direct inje	ction type	
Cylinder liner ty	/pe	Replaceab	le dry liner	
Timing gear sys	stem	Gear driv	ven type	
No. of piston rir	ng	Compression r	ing 2, oil ring 1	
No. of cylinder (mm)	- bore x stroke	6 - 111	× 139	
Total piston dis	placement (cc)	8,0	71	
Compression ra	atio	17.1 : 1	15.9 : 1	
Engine dimens (length x width		1,242 x 918 x 1,100	1,116 x 728 x 1,106	
Engine weight	(kg)	792	800	
Rotation		Counter clockwise		Viewed from flywheel
Fuel injection o	order	1 - 5 - 3 -		
Fuel injection timing		15° ±1°	18° ±1°	BTDC static
Injection pump type		Mechanical		
Governor type		Mechanical gove		
Injection nozzle	e type	Multi-ho		
Fuel injection p	ressure (bar)	21		
Compression p	pressure (bar)	25.0		at 200 rpm
Valve clear-	Intake	0.3 ±	0.05	at cold
ance (mm)	Exhaust	0.3 ±	0.05	at cold
Intake valve	Open at	16	S°	BTDC
make vaive	Close at	36	5°	ABDC
Exhaust valve	Open at	46°		BBDC
Exilaust valve	Close at	14°		ATDC
Lubrication me	thod	Full forced pres	ssure feed type	
Oil pump type		External spu	ur gear type	
Oil filter type		Full-flow, ca		
Lubricating oil	Max.	15	.5	
capacity (lit)	Min.	1:	2	

li o		PU0	Remarks	
ite	ms	ЕВРРА	ЕВРРА ЕВРРВ	
Oil specifica-	Oil class (API)	API	API CI-4	
tion	SAE	100	V40	
Oil cooler type	<u> </u>	Water	Water cooled	
Water pump		Centrifual (Pulley type)		
Cooling Metho	d	Radiator		
Cooling water	capacity (lit)	13.2 eng		engine only
Thermostat typ	е	Wax pallet type		
Alternator voltage - capacity (V - A)				
Starting motor put (V - kW)	voltage - out-	24 -	24 - 6.0	

Engine output

(Production tolerance: ±5%)

Generating-Set Engines			Condition			Domosilio
			Continuous	Prime	Stand by	Remarks
D1146	Standard	50HZ	-	105PS	116PS	
		(1,500 rpm)		(77kW)	(85kW)	
D1140		60HZ	-	130PS	143PS	
		(1,800 rpm)		(96kW)	(105kW)	
	Standard	50HZ	-	145PS	160PS	
D1146T		(1,500 rpm)		(107kW)	(118kW)	
D11461		60HZ	-	170PS	187PS	
		(1,800 rpm)		(125kW)	(138kW)	
	DP086TA	50HZ	-	186PS	207PS	
P086T		(1,500 rpm)		(137kW)	(152kW)	
P0001		60HZ	-	228PS	254PS	
		(1,800 rpm)		(168kW)	(187kW)	
	Standard	50HZ	205PS	240PS	270PS	
		(1,500 rpm)	(151kW)	(177kW)	(199kW)	
		60HZ	253PS	279PS	303PS	
		(1,800 rpm)	(186kW)	(205kW)	(223kW)	
	P086TI-1	50HZ	-	203PS	223PS	
P086TI		(1,500 rpm)		(149kW)	(164kW)	
F00011		60HZ	-	237PS	260PS	
		(1,800 rpm)		(174kW)	(164kW)	
	DP086LA	50HZ	-	273PS	305PS	
		(1,500 rpm)		(201kW)	(224kW)	
		60HZ	-	310PS	344PS	
		(1,800 rpm)		(228kW)	(253kW)	

(Production tolerance: ±5%)

Power-Unit Engines			Max. Output			Remarks
			rpm	PS	kW	nemarks
PU086	6 Cyl.	Naturally Aspirated	2,200	160	118	Max. power rating
PU086T	6 Cyl.	Turbo Charged	2,200	205	151	Max. power rating
DP086LAF	6 Cyl.	Turbo Charged	1,500	304	224	Max. power rating
DP086TAF	6 Cyl.	Turbo Charged	1,500	206.7	152	Max. power rating
PU086TI (EBPPA)	6 Cyl.	Turbo Charger & Intercooler	2,200	290	213.3	Max. power rating (Power unit)
PU086TI (EBPPB)	6 Cyl.	Turbo Charger & Intercooler	2,450	310	228	Max. power rating (Fire pump)

Note) All data are based on operation without cooling fan at ISO 3046.

Note) Ratings Definitions

The power ratings of Emergency Standby and Prime are in accordance with ISO 8528.

Fuel Stop power in accordance with ISO 3046.

Electric power (kWe) must be considered cooling fan loss, alternator efficiency, altitude derating and ambient temperature.


STANDBY POWER RATING is applicable for supplying emergency power for the duration of the utility power outage. No overload capability is available for this rating. A standby rated engine should be sized for a maximum of an 80% average load factor and 200 hours of operation per year. This includes less than 25 hours per year at the Standby Power rating.

PRIME POWER RATINNG is available for an unlimited number of hours per year in variable load application. Variable load should not exceed a 70% average of the Prime Power rating during any operating period of 24 hours. The Total operating time at 100% Prime Power shall not exceed 500 hours per year. A 10% overload capability is available for a period of 1 hour withing a 12 hour period of operation. Total operating time at the 10% overload power shall not exceed 25 hours per year.

Exterior view drawing of the engine (D1146/PU086)

Note) The images shown represent the standard model; they do not include all models.

Front/Rear (D1146/PU086)




EA9O1003_1

- 1. Cylinder head cover
- 2. Cooling water pipe
- 3. Fuel injection pipe
- 4. Water pump
- 5. Mounting bracket
- 6. Oil level gauge

- 7. Flywheel
- 8. Flywheel housing

Left/Right (D1146/PU086)



EA9O1003_2

- 1. Cooling fan
- 2. Alternator
- 3. Thermostat
- 4. Oil filter
- 5. Oil filter cap
- 6. Exhaust manifold


- 7. Vibration damper
- 8. Oil cooler
- 9. Cooling water pipe
- 10. Oil pan
- 11. Oil drain valve
- 12. Starter

- 13. Intake stake
- 14. Intake manifold
- 15. Fuel filter
- 16. Fuel injection pump

Exterior view drawing of the engine (D1146T/PU086T)

Note) The images shown represent the standard model; they do not include all models.

Front/Rear (D1146T/PU086T)




EA9O1004_1

- 1. Exhaust elbow
- 2. Turbocharger
- 3. Cylinder head cover
- 4. Air pipe
- 5. Water pump
- 6. Mounting bracket

- 7. Flywheel
- 8. Flywheel housing

Left/Right (D1146/PU086)



EA9O1004_2

- 1. Cooling fan
- 2. Alternator
- 3. Thermostat
- 4. Oil filter cap
- 5. Cylinder head cover
- 6. Exhaust manifold


- 7. Breather
- 8. Vibration damper
- 9. Oil filter
- 10. Cooling water pipe
- 11. Oil cooler
- 12. Oil drain valve

- 13. Intake manifold
- 14. Fuel filter
- 15. Starter
- 16. Fuel injection pump

Exterior view drawing of the engine (P086TI)

Note) The images shown represent the standard model; they do not include all models.


Front/Rear (P086TI)



EA9O1005_1

- 1. Cylinder head
- 2. Cooling water pipe
- 3. Flywheel
- 4. Mounting bracket
- 5. Water pump
- 6. Flywheel housing

Left/Right (P086TI)



EA9O1005_2

- 1. Cooling fan
- 2. Thermostat
- 3. Oil filter cap
- 4. Air pipe
- 5. Turbocharger
- 6. Exhaust elbow


- 7. Breather
- 8. Vibration damper
- 9. Oil cooler
- 10. Oil pan
- 11. Oil drain valve
- 12. Starter

- 13. Intake manifold
- 14. Fuel injection pump
- 15. Oil filter
- 16. Oil level gauge
- 17. Air pipe

Exterior view drawing of the engine (DP086TA)

Note) The images shown represent the standard model; they do not include all models.

Front/Rear (DP086TA)




EK00345A

- 1. Fuel filter
- 2. Oil filter
- 3. Cooling fan pulley
- 4. Crankshaft pulley
- 5. Oil drain plug
- 6. Oil pan

- 7. Flywheel housing
- 8. Flywheel

Left/Right (DP086TA)




EK00346A

- 1. Cooling pan
- 2. Alternator
- 3. Thermostat
- 4. Turbocharger
- 5. Exhaust manifold
- 6. Starter
- 7. Vibration damper
- 8. Cooling water pipe
- 9. Oil cooler
- 10. Oil pan
- 11. Oil drain valve
- 12. Intake manifold
- 13. Fuel filter
- 14. Fuel injection pump
- 15. Oil level gauge
- 16. Oil filter

3. Performance and specifications

Top (DP086TA)



EK00347A


1. Oil cap

2. Breather

Exterior view drawing of the engine (DP086LA)

Note) The images shown represent the standard model; they do not include all models.

Front/Rear (DP086LA)



EK00348A


- 1. Fuel filter
- 2. Oil filter
- 3. Oil pan pulley

- 4. Crankshaft pulley
- 5. Oil drain plug
- 6. Oil pan

- 7. Flywheel housing
- 8. Flywheel

3. Performance and specifications


Left/Right (DP086LA)



EK00349A

- 1. Cooling pan
- 2. alternator
- 3. Thermostat
- 4. Turbocharger
- 5. Exhaust manifold
- 6. Starter
- 7. Vibration damper
- 8. Cooling water pipe
- 9. Oil cooler
- 10. Oil pan
- 11. Oil drain valve
- 12. Intake manifold
- 13. Fuel filter
- 14. Fuel injection pump
- 15. Oil level gauge
- 16. Oil filter

Top (DP086LA)



EK00350A


1. Oil cap 2. Breather

3. Performance and specifications

Exterior view drawing of the engine (PU086TI)

Note) The images shown represent the standard model; they do not include all models.

Front/Rear (PU086TI)




EDL08220184

- 1. Fuel filter
- 2. Oil filter
- 3. Oil pan pulley

- 4. Crankshaft pulley
- 5. Oil drain plug
- 6. Oil pan

- 7. Flywheel housing
- 8. Flywheel

Left/Right (PU086TI)




EDL08220185

- 1. Cooling pan
- 2. alternator
- 3. Thermostat
- 4. Turbocharger
- 5. Exhaust manifold
- 6. Starter
- 7. Vibration damper
- 8. Cooling water pipe
- 9. Oil cooler
- 10. Oil pan
- 11. Oil drain valve
- 12. Fuel injection pump
- 13. Intake manifold
- 14. Fuel filter
- 15. Oil filter
- 16. Oil level gauge

3. Performance and specifications

Top (PU086TI)



EDL08220186


1. Oil cap

2. Breather

Engine identification number

Engine code and manufacturing number

The engine model and serial number is located on the engine as illustrated. These numbers are required when requesting warranty and ordering parts.



EA9O2001

Engine number engraving

C. Production Year(1 digit)D. Serial Number(5 digits)

E. After engine model SUFFIX(2 digits)

• Type 1				
(A)	(B)		C)	
A. Engine model S	SUFFIX	(5 digits)		
B. Production Yea	ır(1 digi	t)		
C. Serial Number(5 digits)		
 Type 2 				
(A)		(B)	(C)	(D)
A. Sales Model nar	ne(4~7	digits)		
B. Production Year	(1 digit	i)		
C. Serial Number(5	digits))		
D. After engine mo	del SU	FFIX(2	digits)	
 Type 3 				
(A)	(B)	(C)	(D)	(E)
A. Sales Model na	me(5 d	igits)		
B. Engine output(3	digits)			

Type 4
(A) (B) (C)
A. New representative specification (9 digits)
B. Production Year(1 digit)
C. Serial Number(5 digits)
Type 5
(A) (B) (C) (D)
A. Sales Model name(4~7 digits)
3. Production Year(1 digit)
C. Serial Number(5 digits)
D. After new representative specification(3 digits)
Type 6
(A) (B) (C) (D) (E)
A. Sales Model name(5 digits)
3. Engine output(3 digits)
C. Production Year(1 digit)
D. Serial Number(5 digits)
E. After new representative specification(3 digits)

3. Performance and specifications	

General information	43
General Information	43
Routine Inspection	43
Regular inspection table	44
General conditions	44
Use of Genuine Parts	46
Cooling system	47
General Information	
Coolant standards	47
Capacity of coolant	47
Checking the Coolant	47
Measurement of Coolant Concentration	47
Discharging the coolant	48
Charging the Coolant	49
Cleaning the cooling circuit	50
Inter cooler	51
Lubrication system	52
General Information	52
Engine oil standards	53
Engine Oil Capacity	54
Checking the Engine Oil	54
Replacement of Engine Oil	55
Replacement of Engine Filter	55
Fuel system	56
General Information	56
Fuel Standards	57
Water draining from fuel filter	58
Replacing fuel filter	58
Preventing fuel contamination	59
Fuel injection pump	59
Air bleeding in the fuel circuit	59
Fuel injection nozzle	60
Check fuel injection nozzle pressure	60
Removal of nozzle	61
Installation nozzle	61

Adjustment nozzle	61
Note for cleaning nozzle	61
Adjusting injection timing	61
Priming pump strainer cleaning	63
Intake/exhaust system	64
General Information	64
Air Filter	64
Disassembly of air filter	64
Cleaning of the Air Filter Element	65
Changing the air filter element	66
Turbocharger	66
Routine check and serving the turbocharger	66
Disassembly and cleaning a turbocharger	66
Cylinder block/head	67
Valve Clearance	67
How to adjust the valve clearance	67
Adjusting the Valve Clearance	67
Cylinder Compression Pressure	68
Electric system	69
Battery	69
Starter	69
Others/driving system	70
V-Belt	70

General information

General Information

As time passes after purchasing an engine, each of the engines parts age and initial engine performance cannot be maintained.

Regular inspection and replacement according to the recommended regular inspection table allows you to maintain an engine with the optimum conditions and best performance for a long period and prevent unexpected accidents in advance.

Users are responsible for the proper operation and maintenance of engines. Engines should be inspected and replaced by officially-certified technicians in a workspace with the specified tools and facilities. Observe the following instructions to perform inspections.

- 1. Perform inspections on a flat floor without a slope.
- 2. Excluding extreme circumstances, only perform inspection while the engine is stopped.
- 3. Disconnect the '-' terminal of the battery before performing an inspection.
- 4. Perform inspection in a well ventilated space.
- 5. Use a wooden prop or lift when working under the engine.

↑ DANGER

- Wait until the engine is sufficiently cooled before starting inspection after operating the engine.
 Otherwise, you may be burned.
- You may be poisoned by the emission when starting an engine in a closed space. Perform inspection at the well-ventilate space.
- Unless absolutely compelled, do not perform inspection under an engine.
- Do not be close to fire when inspecting an engine.
 Fuel, oil, or batteries may generate gas, causing fire.
- If inspecting the engine while it is running, do not wear accessories such as necklaces, rings, watches or gloves. Such accessories may become stuck in rotating parts while the engine is running and may cause serious bodily injury.

↑ CAUTION

- Incorrect inspection methods may cause of engine faults.
- Cleaning an engine with liquids such as water or wax may cause breakdown of electrical parts.
- Be careful when handling batteries, cables, and electrical wirings because current flows through those parts.
- Do not put heavy things or apply excessive force or impact on the fuel-related units.
- Make sure that you connect the battery terminal ('+' and '-') to the right terminal. Connecting the '+' and '-' terminals to the wrong terminal may cause damage to the electrical unit parts and fire.

Routine Inspection

Routine inspection is an inspection performed by an engine operator before operating the engine. It should be performed to protect operator's safety, as well as the engine.

The following is a minimal check list.

- Check whether the engine smoothly starts and the levels of fuel, oil, and coolant are within the normal range.
- 2. Check if any discharged emissions are colored and if the exhaust contains toxic gas elements.
- 3. Check whether abnormal noise occurs after starting an engine or not.
- 4. Check whether oil or water is leaking.

Regular inspection table

General conditions

Regular inspection and replacement according to the recommended regular inspection table allows you to maintain the engine with optimum conditions and best performance for a long period and prevent unexpected accidents in advance.

(○ : Inspection and Adjustment • : Replacement)

			Inspection interval (Hours)				urs)	
	Check Points Daily		First 50	200	400	600	1,200	Remarks
	Check for leakage(hoses, clamp)	0						
	Check the coolant water level	0						
Cooling system	Change the coolant water						•	
	Adjust the V-belt tension	0						Every 2,000hrs
	Clean the radiator						0	
	Check for leakage	0						
Lubrication	Check the oil level gauge	0						
system	Change the lubricating oil		• a	•				
	Replace the oil filter cartridge		• a	•				
	Check the leakage fuel line	0						
	Clean the fuel strainer of fuel feed pump			0				
	Remove sediment from fuel tank						0	
	Drain the water in separator			0				
Fuel system	Replace the fuel filter element				•			
	Check fuel Injection timing			0				When necessary
	Check the injection nozzles			0				When necessary
	Check the leakage for intercooler (hoses, clamp)	0						
Intake/Exhaust	Clean and change the air cleaner element			_O b	•			
system	Clean the inter-cooler air fins					0		
	Clean the turbocharger							Every 2,000hrs

Check Points		Daily	Inspection interval (Hours)					
			First 50	200	400	600	1,200	Remarks
	Check the state of exhaust gas	0						
	Check the battery charging	0						
Engine adjust	Check the compression pressure						0	When necessary
	Adjust Intake/Exhaust valve clearance		_O a					When necessary

<sup>a. First 50hr
b. Clean
* If the sulfur content of the fuel is more than 0.5%, the replacement and inspection cycle should be cut in half.</sup>

Use of Genuine Parts

An engine consists of many parts which are mechanically harmonized. To prevent engine faults in advance and use engines with best performance for a long period, maintenance and replacement of expendable parts should be conducted regularly.

Use of genuine parts is recommended. Using unauthorized or remanufactured parts may cause critical damage and faults to engine for which Hyundai Doosan Infracore shall not be held liable.

Cooling system

General Information

The coolant should be replaced according to the cycle specified in the inspection interval table. If the coolant gets dirty, the engine is overheated, and the coolant overflows in the thermal expansion tank.

Coolant standards

We recommend you to inject the antifreeze about $40\sim50\%$ of the entire coolant. The antifreeze prevents the freezing and corrosion of the system, and increases the boiling point of water. In winter, you may need to change the amount of antifreeze per ambient temperature as shown in the table below. The freezing point per antifreeze ratio shown in the table may differ slightly depending on the antifreeze type. For more information, see the specifications provided by the manufacturer.

Whenever you add coolant(water) to replenish the amount reduced by engine operation, the antifreeze portion is decreased. So, you need to increase the antifreeze level to the proper level after replenishing the coolant.

· concentration of antifreeze during winter

Ambient tem- perature (°C)	Coolant (°C)	Antifreeze (%)
Above -10	85	15
-10	80	20
-15	73	27
-20	67	33
-25	60	40
-30	56	44
-40	50	50

Capacity of coolant

Engine Mode	Coolant capacity (lit)
D1146	
D1146T	
DP086TA	
P086TI	14/11
DP086LA	
PU086	
PU086T	
PU086TI	13.2

Checking the Coolant

⚠ DANGER

If the radiator cap is opened to exchange or replenish coolant while the engine is overheated, hot water will spurt out and may cause serious burns. If it is bsolutely necessary to open the radiator cap while the engine is overheated, wrap the radiator cap with a cloth and lowly open the cap in two steps until the steam pressure has been released from the inside. After the steam pressure has been completely released, remove the radiator cap.

- 1. For the engine coolant, you should use clean tap water.
- 2. To the engine coolant add 40% of antifreeze to prevent corrosion.
- 3. Periodically check coolant to maintain the concentration of antifreeze and additives.

⚠ CAUTION

If you keep the antifreeze and corrosion inhibitor at a proper level, you can prevent the corrosion of engine effectively and keep the quality of the engine. Be careful that, if managed improperly, it can give a fatal impact on the coolant pump and cylinder liner.

4. You can check the concentration of antifreeze and corrosion inhibitor using the coolant test sheet.

Measurement of Coolant Concentration

Special Tools

Figure	Product Number/Name
test sheet C) B) A)	60.99901-0038 Coolant test sheet

The coolant concentration can be measured as follows.

If the engine coolant temperature is within a range of 10
 55°C, drain the coolant and fill half a plastic cup with it.

⚠ CAUTION


When taking out a sample of coolant from the supplementary tank, it is difficult to measure the precise concentration. Always take out sample by opening the drain plug of coolant.

- Soak the test sheet in the coolant and take it out after 3 ~
 seconds. Shake the sheet to remove the remaining coolant.
- 3. Wait for about 45 seconds until the test sheet changes its color.

ACAUTION

Measurement time should not exceed 75 seconds. The color changes as time passes.


4. Check the color on test sheet.



EDL0213002A

- Compare the color of part (A) on the test sheet to the color of GLYCOL/FREEZEPOINT (End pad) of the standard color table.
- Compare the color of the test sheet (B) to the color of MOLYBDATE (Middle pad) of the standard color table.
- Compare the color of the test sheet (C) to the color of NITRITE of the standard color table.

5. Compare and confirm the parts with identical colors on the test sheet and the standard color table.



EDL022154A

- Compare the changed pink color part A of the test sheet with the GLYOOL/FREEZEPOINT (End pad) of the standard color table on top of the container and confirm the concentration. The concentration indication has to be within the color scope of 33~50%.
- 2) It should be maintained at the optimum range, in the green section between 0.3 to 0.8 where the color of MOLYBDATE (Middle pad) on the standard color table (which is identical with the Middle (B) of the test sheet) is crossed with the color of NITRITE on the standard color table (which is identical with the (C) of the test sheet).
- If it is above 0.8 or, drain a little coolant and then add clean tap water to adjust the concentration.

ACAUTION

- If the color on the test sheet does not match the color of the standard color table, find a middle color on the standard color table. For example, if the color of (C) of the test sheet matches D and F on the NITRITE of the standard color table, select E.
- To prevent corrosion inside of the engine cooling unit, drain the coolant and replace it with new coolant once a year.

Discharging the coolant


The coolant can be discharged as follows.

1. Make sure that engine and radiator are cooled.

2. Open the radiator cap.


↑ CAUTION

- Never open the radiator cap while the engine is overheated. If the radiator cap is opened while the engine is overheated, hot water will spurt out and may cause serious burns. Open the radiator cap after ensuring that the engine has been cooled sufficiently.
- Mark and separately manage the containers for storing coolant from beverage containers to avoid confusion. If coolant is ingested, see a doctor immediately.
- 3. Loosen the drain valve which is located under the radiator to discharge the coolant.



EA5O4002

4. Disassemble the coolant discharge plug of the cylinder block, and discharge it to a container.



EA9O4003

5. Drain cooling water in the oil cooler.

Charging the Coolant

- 1. Make sure that engine is coolded.
- 2. Open the radiator cap.

⚠ DANGER

- Never open the radiator cap while the engine is overheated. If the radiator cap is opened while the engine is overheated, hot water will spurt out and may cause serious burns. Open the radiator cap after ensuring that the engine has been cooled sufficiently.
- Mark and separately manage the containers for storing coolant from beverage containers to avoid confusion. If coolant is ingested, see a doctor immediately.
- 3. Put in the coolant slowly.

ACAUTION

Be careful not to let foreign substances flow into the engine when replenishing coolant.

- 4. Be sure that the air is gone out from cooling system.
- 5. After checking the coolant level when the engine is warmed up, replenish coolant if necessary.

⚠ DANGER

If the engine is hot, wrap the coolant pressure cap with a cloth upon opening it so that the steam may be discharged. This can prevent you from burning by the hot steam coming out of the cap inlet.

↑ CAUTION

- Do not mix antifreezes from different manufacturers.
- Do not mix the coolant with different concentrations.
- Do not add antirust which is not recommended by us.
- As insufficient coolant concentration may cause corrosion or freezing, on the other hand, an excessive concentration may degrade the cooling performance. Mix coolant with 40% antifreeze to prevent corrosion.

⚠WARNING

Discard exchanged coolant according to the regulations set forth by the relevant authorities. Disposing of exchanged coolant into the ground, sewers, drains, rivers, or the sea will cause serious environmental pollution. Violation of regulations regarding discard of coolant without observing the handling regulations, will be punished.

Cleaning the cooling circuit

If the internal coolant circuit is contaminated by corrosion or foreignsubstance, the cooling effect is reduced. The resistance in the coolant circuit may damage the mechanical seal of the coolant pump.

The negative impact on the cooling circuit may be caused by use of improper antifreeze or corrosion inhibitor, or by use of coolant without such ingredients. If the coolant pump leaks or the coolant is severely contaminated within short period of time (6 months) after start of using the operation (e.g., the coolant color becomes muddy - probably brown, grey or black depending on the degree of contamination), before removing the coolant pump, clean the cooling system in the following way.


- 1. Discharge the coolant.
- 2. If you want to clean the cooling circuit swiftly, remove the thermostat.
- 3. Mix water and 1.5% of cleaning solution and fill the cooling circuit with this liquid.
- 4. Load the engine. When the coolant temperature reaches 60°C, run the engine for about 15 minutes.
- 5. Discharge the cleansing solution.
- 6. Repeat the step 3 and 4 above.
- 7. Fill the cooling circuit with hot water.
- 8. While running the engine at idle speed for 30 minutes, check if there is any leakage in the drain plug and coolant line. If the coolant is insufficient, replenish it.

⚠ CAUTION

Clean the cooling circuit regularly with cleansing solution.

Inter cooler

The air cooler adopts an air cooling fan, which has sufficient cooling capacity. The life and performance of an air cooler greatly depends on the intake air conditions. Dirty air may contaminate and clog the cooling pins. This results in reduced engine power or engine failure. So, always check the intake system for air leak, damage or contamination of air filter.



EA5O4003

ACAUTION

To keep the optimum performance of the air cooler, clean it regularly.

Lubrication system

General Information


Engine oil lubricates, cools, seals, prevents corrosion, and cleans engines, enhancing engine performance and extending the engine's lifetime. If a vehicle is continuously driven while engine oil is insufficient, the moving parts of the engine may get stuck, causing engine faults.

Engine oil should be checked through the oil level gauge and replenished if required. Oil level should be checked while the engine is stopped. To check the oil level, turn off the engine while it is running and wait for $5 \sim 10$ minutes to allow the engine oil to flow back into the oil pan. The engine oil level should indicate between the upper limit and the lower limit of the oil level gauge.

Engine oil should be periodically replaced based on the regular inspection table and the oil filter and the cartridge should be replaced as the engine oil is replaced.

Engine oil standards

Use the specified engine oil suitable for the environment and conditions of the site where the engine will be used.



EDL06200023

Please use the engine oil which satisfies the following recommended specifications.

Engine Model and Product Code	SAE Classification	Oil Class
D1146		
D1146T	SAE 10W40	
P086TI		ADI CL 4
DP086TA		
DP086LA		API CI-4
PU086		
PU086T		
PU086TI		

Note) Use of Hyundai Doosan Infracore genuine engine oil is recommended.

Engine Oil Capacity

Please replenish the engine oil based on the following recommended oil amount.

Engine Model	Engine oil capacity (lit)					
and	Engine only					
Product Code	Max.	Min.				
D1146	15.5	12				
D1146T	15.5	12				
P086TI	15.5	12				
DP086TA	15.5	12				
DP086LA	15.5	12				
PU086	15.5	12				
PU086T	15.5	12				
PU086TI	15.5	12				


Checking the Engine Oil

Check the oil level everyday using an oil levelgauge.

- The oil level should be checked when the engine is stopped and on an even level. If you started the engine, wait for 5~10 minutes to allow the engine oil to flow back into the oil pan.
- 2. Pull out the oil level gauge, and clean the indication line of the oil level gauge with clean cloth.


ACAUTION

Cleaning the indication line of the oil level gauge with dirty cloth allows the foreign substances to get into the engine, causing damage to the engine.



DV2213163A

3. Insert the oil level gauge, and then pull it out to check the engine oil level, viscosity, and contamination. Replenish or replace the engine oil if required.



DV2213016A

- 1) Check the oil level everyday using an oil level gauge.
- 2) Check if the oil is smeared between the upper limit (A) and the lower limit (B) of the oil level gauge.
- 3) If engine oil is smeared below the lower limit (B) or not smeared on the gauge at all, replenish engine oil.
- 4) Check condition of engine oil. If it is polluted, replace it with new oil.


ACAUTION

- Do not fill the engine oil above the upper limit.
 Exceeding the upper limit may damage the engine.
- Be careful not to let foreign substances flow into the engine when replenishing engine oil.

Replacement of Engine Oil

Check the oil level using an oil level gauge and replenish it if required. Replace the engine oil in the following steps when the engine is warm by running it.

- 1. Pull out the oil level gauge.
- 2. Open the drain plug of the oil pan to discharge the engine oil from the container.



DV2213017A

- 3. After discharging the engine oil, assemble the drain plug of ghe oil pan again.
- 4. Fill the engine oil into the cartridge of the oil filter.
- 5. Through the oil filler cap, fill the engine oil.
- 6. Idle the engine for several minutes so that the oil circulate through the lubrication system.
- 7. Then, stop the engine, wait for about 10 minutes, check the oil level, and fill the oil if required.

ADANGER

- Prolonged and repeated contact of skin with engine oil may lead to shrinking, dryness of skin and even cause dermatitis.
- Do not expose skin with exchanged engine oil for a long period.
- Always wear work clothes and gloves.
- When skin is stained with engine oil, immediately wash it with water, soap or hand cleaners.
- Do not clean skin with gasoline, fuel, thinner, or solvent.
- Apply a skin protective cream after cleaning from oil.
- Do not put oil-stained gloves or cloth in pockets.

⚠WARNING

Discard exchanged oil according to the regulations set forth by the relevant authorities. Disposing of discharged oil into the ground, sewers, drains, rivers, or the sea will cause serious environmental pollution. Violation of regulations regarding discard of engine oil without observing the handling regulations, will be punished.

Replacement of Engine Filter

Check the oil pressure and leakage, and replace the oil filter if required. Whenever replacing the oil, the oil filter cartridge should be replaced with a new on.

- 1. Using an oil filter wrench, loosen the cartridge by turning it counterclockwise.
- Wipe the oil filter head and cartridge contact thoroughly, and make sure that the oil filter cartridge is positioned properly.
- 3. Apply a little bit of oil to the o-ring area of the cartridge, assemble it until the O-ring surface may contact, and turn it 3/4 or 1 turn using a wrench to keep it air-tight.

⚠ CAUTION

When replacing the oil filter cartridge, be sure to use the genuine part of Hyundai Doosan Infracore.

Fuel system

General Information

The fuel injection pump and nozzle are composed of very sophisticated components with high precision. If fuel is mixed with foreign substance, it may clock the nozzle or the fuel injection pump components may be seized. So, be sure to keep the fuel system clean all the time.

ACAUTION

- Use clean, certified and qualified fuel only. Using irregular or unspecified fuel may cause critical damage and faults to the engine.
- · Replenish fuel while the engine is stopped.

Fuel Standards

The quality of fuel is very important to satisfy the engine performance, extension of engine life and the allowable exhaust gas level. Hyundai Doosan Infracore engine engine is designed to use diesel fuel available in the local market. If you want the optimum engine performance, select the proper fuel referring to the fuel selection table below.

• Low Sulfur Diesel


Property	ASTM D975	ASTM D975 2GRADE		EN 590:2013	
Flash point, min	No 2D 52°C	D923	55°C	EN2719	
Water & sediment, max.	0.05% vol.	D2709			
Water, max.			200 mg/kg	EN ISO 12937	
Total contamination, max.			24 mg/kg	EN 12662	
Distillation temperature	90%	Doc	65%: 250°C	EN 100 0405	
(% vol recovered)	2D 282-338°C	D86	85%: 350°C	EN ISO 3405	
Kinematic viscosity (at 40°C)	2D 1.9-4.1 mm ² /s	D445	2.0-4.5 mm ² /s	EN ISO 3104	
Density (at 15°C)			000 045 harden3	EN ISO 3675	
Density (at 15 C)			820-845 kg/m ³	EN ISO 12185	
Ester content	5% vol. max.	EN14078	7% vol. max. FAME	EN 14078	
Ash, max.	0.01% wt	D482	0.01% wt	EN ISO 6245	
	2D		10	EN ISO 20846	
Cultur may (by mass)	S15 15 mg/kg	D5453		EN ISO 20884	
Sulfur, max. (by mass)	S500 0.50%	D2622 D129 ²		EN ISO 13032	
	S5000 0.50%				
Copper strip corrosion, max.	No 3	D130	Class 1	EN ISO 2160	
Cetane number, min.	40	D613	51	EN ISO 5165	
Cetane index, min.			46	EN ISO 4264	
- Cetane index	40 min.	D976-80			
- Aromaticity	35% vol. max.	D1319			
PAH, max.			11% wet	EN 12916	
Operability, one of:		D2500 D4539 D6371			
- Cloud point	Report				
- LTFT/CFPP					
Cloud point			Location & season dependant	EN 23015	
CFPP			Location & season dependant	EN 116	
Carbon residue on 10% distillation residue, max.	2D: 0.35% wt	D524	0.30% wt	EN ISO 10370	
Oxidation stability, max.			25 g/m ³	EN ISO 12205	
Lubricity (at 60°C), max.	520 μm	D6079 D7688	460 μm	ISO 12156-1	
Conductivity, min.	25 pS/m	D2624 D4308	,		

Note) If the sulfur content of the fuel is more than 0.5%, the replacement and inspection cycle should be cut in half.

Water draining from fuel filter

An oil filter has two functions: oil filtering and water separa-

- 1. the water separation function of the fuel filter discharges water and sediment from the water separator.
- 2. Stop the engine, and loosen the drain plug for water separation manually.



DV2213019A

- Turn the drain plug (6) for water separation counterclockwise 2~3times until water is drained. Drain the water in the cartridge until fuel is discharged.
- 4. Tighten the drain plug for water separation by turning it clockwise.


↑ DANGER

Fuel may be drained when water is drained from the fuel filter. Fuel is highly inflammable. Fire may occur when you use fire near the engine when draining water from the fuel filter.

ACAUTION

- Do not tighten the plug excessively because it may damage the screw.
- If you do not check the fuel filter regularly and drain the water in the fuel filter, water flows into the fuel system of the engine, causing serious failure in the fuel system, etc., and decrease in or damage to the fuel filter performance. Inflow of water to the fuel system may stop the engine.
- Use clean, specified, and qualified fuel only. using irregular or unspecified fuel may result in more water in the fuel filter.

Replacing fuel filter



DV2213019A

- 1. Clean the area around the fuel filter head(3).
- 2. Disassemble the cartridge(2) by turning it counterclockwise with a fuel filter wrench.

⚠ CAUTION

Do not reuse the cartridge; replace them with new ones.


- 3. Remove the fuel filter screw adapter seal ring(4).
- 4. Clean the gasket contact of the fuel filter head(3).
- 5. Check the position of the new cartridge adapter seal ring(4).
- 6. Assemble the cartridge to the fuel filter head.

∴ CAUTION

Assemble the new fuel filter without fuel. Do not inject fuel into the new fuel filter. After replacing the fuel filter, do air bleeding in the fuel circuit.

7. Tighten the cartridge with hand until the O-ring contacts the fuel filter head surface.

8. Turn it by 3/4 to 1 turn with a fuel filter wrench.



DV2213020A

ACAUTION

If you tighten the cartridge excessively, the screw may be distorted or O-ring damaged.

Preventing fuel contamination

Most of the fuel contaminations encountered while using the alternator engine are caused by water and propagation of microbes.

Usually, the contamination results from improper handling of fuel. Propagation of microbes requires water contained in the fuel. To prevent propagation of microbes, you have to keep the water to the minimum level possible in the storage tank.

Fuel injection pump

- Check the fuel injection pump housing, and replace it if crack or damage is found.
- Check if the idle operaion and speed control lever's sealing device was not removed.
- Chcek if the idling or speed control lever's sealing line is not damaged.
- You should not modify the fuel injection pump if the sealing line is damaged, such engine cannot receive compensation.
- if the fuel injection pump is found abnormal, authorized personnel should handle it.


 The adjustment and test of the fuel injection pump must be conducted using a tester.

ACAUTION

If you separate the parts where the seal ring (copper seal ring, rubber coating seal ring, etc.) is assembled, you should replace the seal ring with a new one. Otherwise, leakage may occur in the fuel filter connections, preventing normal functioning.

Air bleeding in the fuel circuit

When the engine stops due to replacement of fuel filter, fuel injection pump or insufficient fuel, you should perform air bleeding.



FA9O4005

- 1. Turn the priming pump cap.
- Bleed the fuel by manually operating the priming pump with fuel filter outlet joint bolt and injection pump bleeder screw loosened.
- 3. Press the feed pump cap repetitively until the fuel without bubbles overflows from the bleeding plug screw.
- 4. After the whole air is pulled out, close the plug screws of the filter and the pump.
- Confirm the resistance of fuel delivery by repetition pressing of the feed pump cap, Pressure and turn the priming pump cap simultaneously to close it.

⚠ DANGER


Fuel is highly inflammable. Fire may occur when you use fire near the engine when air bleeding in the fuel circuit from the priming pump.

ACAUTION

If you separate the parts where the seal ring (copper seal ring, rubber coating seal ring, etc.) is assembled, you should replace the seal ring with a new one. otherwise, leakage may occur in the fuel filter connections, preventing normal functioning.

Fuel injection nozzle


- The injectors are designed to spray the fuel delivered by the injection pump directly into the spherical combustion chamber in the piston crown.
- The injector consists of the nozzle and the nozzle holder.



EFM2054I

- 1. Nozzle holder
- 2. Union nut
- 3. Shim
- 4. Coil spring
- 5. Guide bush
- 6. Washer
- 7. Cap nut
- 8. Nozzle

- Check fuel injection nozzle pressure
- 1. Install a nozzle to the nozzle tester.




DV2213023A

- 2. Check injection pressure using cranking for meeting the correct pressure.
- 3. Check the nozzle spray status. If it is defective, replace the nozzle.

ACAUTION

- As the nozzle injection nozzle is designed to operate under high pressure, you should handle it with special care.
- Do not hold your hands under the fuel jet, as there is a rise of injury. Do not inhale the atomized oil fuel.
 If possible, work under an extraction system.



DV2213024A

Engine Model	Opening pressure (kg/cm ²)	Remarks
D1146	214	at 200 rpm
D1146T	214	at 200 rpm
P086TI	214	at 200 rpm
DP086TA	214	at 200 rpm
DP086LA	214	at 200 rpm
PU086	214	at 200 rpm
PU086T	214	at 200 rpm
PU086TI	214	

Removal of nozzle

- Clamp the nozzle assembly and remove the nozzle holder.
- 2. Remove the nozzle nut and components inside.

Installation nozzle

- 1. After removing carbon deposit, submerge the nozzle in diesel oil and clean it.
- 2. Replace all the gaskets with new ones.
- 3. Assemble the parts and tighten them to specified torque.

Adjustment nozzle

- 1. the cap nut and assemble a nozzle to a nozzle tester.
- With the adjusting screw loosened, operate the nozzle 23 times to bleed it.
- 3. Operate the nozzle tester lever at the specified rate.
- 4. Adjust the injection pressure to the standard pressure using the adjusting screw.
- 5. After adjusting the injection pressure, tighten the cap nut to specified torque.
- Re-check the injection pressure and see if the spray pattern is normal. Spray pattern should be uniform and free of spattering.


Note for cleaning nozzle

- Clean nozzle body externally from soot and carbon,
 When cleaning several nozzles at the same time, make sure nozzle bodies and needles are not mixed up. Visually inspect needle and body.
- Cleaning is useless if the seat of the needle is indented or the pintle is damaged and the nozzle should be replaced.
- Clean annular groove with scraper over full circumference. Wash out dislodged carbon deposits and dirt.

- Scrape needle seat with cleaning cutter, Dip cutter in test oil before use. The cutter can also be clamped in a lathe.
- Polish needle seat with wooden cleaning tool, preferably by chucking the needle in a lathe at the pintle end.
- Clean the spray holes of nozzles by chucking a cleaning needle of suitable diameter in the collect. If the carbon deposits in the spray holes cannot be removed by rotating and pressing, have the needle project only slightly from the collect and drive out the carbon by lightly tapping on the tool.
- Before reassembly thoroughly wash nozzle body and needle in clean test oil.
- Hold the needle at the pintle end only; to avoid corrosion do not touch the lapped surfaces of the needle with you fingers.
- Thoroughly clean all other parts of the nozzle holder with clean fuel.
- Check nozzle discharge pressure in nozzle tester. The edge-type filter should not be pressed into the nozzle holder by more than about 5mm. If this depth is exceeded the injector must be replaced.

Adjusting injection timing


- 1. Adjust injection timing.
- Bring the piston of #1 cylinder to the compression TDC (OT) by turning the crankshaft. Again, turn 60° in the reverse direction of engine rotation.
- 2) Disassemble the fuel injection pipe that connect the fuel injection pump and #1 injection nozzle.
- 3) Disassemble the fuel injection pump delivery valve holder, and after removing the valve and valve spring, again assemble the valve holder and then, on it assemble the pipe of "U" shape on it.
- 4) Operating the priming pump of supply pump, turn the crankshaft slowly in the direction of engine rotation until the fuel will drop at the rate of a drop for 6 ~8 sec.
- 5) Confirm then whether the indication point at the flywheel housing inspection hole and the engraved specified injection angle are coincided or not, and if the injection timing is not correct, adjust as follows.



EA905001

Engine Model	Injection timing	Remarks
D1146	18°	BTDC
D1146T	18°/12°	BTDC
P086TI	12°	BTDC
DP086TA	19°	BTDC
DP086LA	14°	BTDC
PU086	18°	BTDC
PU086T	18°/12°	BTDC
PU086TI (EBPPA)	15° ±1°	BTDC
PU086TI (EBPPB)	18° ±1°	BTDC


- b) Loosen the drive gear fixing bolt of injection pump a bit.
- After turning slowly the coupling of injection pump until
 the fuel will drop from #1 plunger at the rate of a drop for
 6 ~ 8 sec., tighten the driving gear fixing bolt of fuel pump.
- 6) After the adjustment of injection timing, disassemble the "U" shape pipe, readjust the delivery valve and the valve spring.
- 7) Turn the coupling until the notch mark of the indicator plate attached to the fuel injection pump is aligned with the notch mark of the coupling.



EA9O5002

8) Tighten the Coupling fixing bolts and nuts to specified torque.

Torque	6.0 ~ 6.5 kgf·m
--------	-----------------




EAMD021I

9) Install the oil delivery pipe and return pipe.

Priming pump strainer cleaning

- 1. Clean the priming pump strainer filter frequently.
- 2. The strainer filter is incorporated in the priming pump inlet side



EA9O4004

Intake/exhaust system

General Information

The air filter purifies dust and foreign substances included in the air and supplies clean air into the engine. The air filter is directly related to engine lifetime, emissions, and engine output. Please periodically check, clean, and replace the air filter.

ACAUTION

- Do not operate the engine when the air filter is separated from the engine.
- Use specified air filters only. Using unauthorized or remanufactured air filters may result in critical faults.
- Foreign substances in the engine may cause abrasion inside the engine.
- Immediately exchange a damaged air filter with a new one.
- Be careful not to let foreign substances flow into engine or damage the air filterrelated electric apparatus when replacing an air filter.
- Be careful not let dust inside when assembling the air filter.

Air Filter


- Air cleaner is mounted on the engine to purify the air for combustion.
- The intervals at which the air cleaner requires servicing depend on the specific operating conditions encountered.
- Clogged air filters may cause black smoke and reduce power.
- A check should be made from time to time to see that the fastening elements securing the air cleaner to the intake manifold seal the connection tightly.
- Any ingress of unfiltered air is liable to cause a high rate of cylinder and piston wear.

Disassembly of air filter

↑ DANGER

Allowed only when the engine is stopped.

- Empty the dust bucket periodically. The dust should not exceed the half of the dust bucket capacity.
- You can disassemble the dust bucket by removing two clamps. Remove the dust bucket cover and empty the dust inside.
- Assemble the cover and dust bucket accurately with care
- 4. For easy alignment, the cover has dent and the dust collector has a protrusion. Here is the position where a filter is mounted horizontally, check the "TOP" mark on the air filter canister.




DV2213029A

1. Air cleaner ass'y

Cleaning of the Air Filter Element

Clean the air filter element by using the most suitable method for your work environment among the three methods stated below.

1. Use compressed air to clean the air filter element.




EDL022155A

- To clean, let sufficient compressed air reach the inside bottom of the element at 90° direction with an air gun.
- Move air gun up and down the element to blow air from inside to outside until no more dust is coming out from the element.
- 3) Do not use compressed air pressure exceeding 5 bars.

↑ DANGER

Always wear protective goggles before starting work. Otherwise, dust or foreign substances from the element may get in your eyes and cause injuries.

2. Clean the element by washing it.



EDL022156A

1) Before washing the element, clean the element by using compressed air as described above.

- Soak the element in the warm cleaning solvent for 10 minutes and then shake it back and forth for about 5 minutes.
- 3) Rinse the element with clean water, drain the water, and then dry it at room temperature. Fully dry the element before reassembling it to the engine.


ACAUTION

Never use steam spray, gasoline, alkali or hot cleansing solution to cleansing the element.

- 3. In an emergency, temporarily clean the element by using the following method.
- 1) Tab the end plate of the element with the thumb to clean it temporarily.

ACAUTION

- This method should only be used in an emergency when cleaning of element is necessary and no compressed air or cleansing solution is available.
- Under no circumstances should the surface of the element be hit or beaten with a hard object to shake the dust off.




EDL022157A

Note) Before reassembling the element, make sure that the filter paper is not wrinkled, the state of rubber sealing is good, and there is no deformed part in the element.

Note) Under any circumstances, do not reuse damaged elements. When in doubt, replace the element with a new one.

Changing the air filter element

1. Remove the hex nut, remove the dirty element.



DV2213030A

- 2. Replace with a new one or wash it.
- 3. Using a wet rag, wipe the inside of the filter housing.
- 4. The sealing contact of element.

A DANGER

Do not let dust come into the end of air filter.

Turbocharger

The Turbocharger does not need a specific maintenance. Whenever replacing the engine oil, check oil pipe for leakage or clogging.

- You should handle the air filter with special care to prevent foreign substance from getting in.
- The turbocharged compressed air and exhaust gas pipe should be checked periodically. Air leakage causes engine overheat, so repair is required.

↑ CAUTION

Be careful not to bend it.

If the impeller is severely contaminated, soak only the
wheel in a solvent and clean it with a rigid brush thoroughly. Here, be sure to soak only impeller, and the
turbocharger should be supported by a bearing housing,
not by an impeller.

Routine check and serving the turbocharger

The turbocharger performance is determined by maintenance state of the engine. So you should regularly perform inspection and check as specified.

- Intake system
 For the intake system, the air filter should be carefully managed. For a wet type air filter, the intake resistance should be small as possible.
- 2. Exhaust system

For the exhaust system, when exhaust gas leaks from the exhaust pipe or turbocharger joint, supercharging efficiency is lowered. So you need to pay attention to prevent gas leakage and burn. Heat resistant nuts are used for parts which are highly heated during operation, such as the turbine seal, and the nuts should not be mixed with other nuts. The screw burn prevention paint should be applied to the assembly nuts of the specified positions.

3. Fuel system

If the spray status of the fuel injection nozzle is not good, or the injection timing is not correct, the exhaust gas temperature increases to give a negative impact on the turbocharger. So, the nozzle should be tested.

4. Lubrication system

For the lubrication system, pay attention with the oil quality and the replacement time of the cartridge of the oil filter. Degradation of engine oil has bad effect on the turbocharger, as well as the engine body.

Disassembly and cleaning a turbocharger

You can disassemble the turbocharger from the engine to clean or inspect it. Here, be sure to seal the oil inlet and oulet with a tape, etc.

Cylinder block/head


Valve Clearance

Adjust the valve clearance.

- When disassembling the engine or cylinder head.
- When there is excessive noise in the valve connection.
- · When the engine runs abnormally even if the fuel injection system is normal.

How to adjust the valve clearance

- 1. Adjust the valve clearance.
- 1) Loosen the lock nuts of rocker arm adjusting screws.
- 2) Push the feeler gauge of specified value between a rocker arm and a valve stem (to measure the clearance of the valve and rocker arm contacting part)
- 3) Adjust the clearance with adjusting screw respectively and then tighten with the lock nut.




4) Adjust valve clearance with a feeler gauge and tighten the fixing nuts to specified torque.

Torque	4.4 ±0.45 kgf·m
--------	-----------------

Adjusting the Valve Clearance

1. Guide for valve clearance adjustment



EA9O5005

4. Regular inspection

- Rotate the crankshaft so that #1. cylinder may be positioned at the compression TDC (Top Dead Center). Then adjust the valves corresponding to mark " " in the below table.
- Note) #1. cylinder is located at the side where flywheel was installed.
- Note) #6. cylinder is positioned at the valve overlap when #1. cylinder is positioned at the compression TDC (Top Dead Center).
- 2) Rotate the crankshaft one rotation (360°) so that #6. cylinder may be positioned at the compression TDC (Top Dead Center). Then adjust the valves corresponding to mark " o " in the below table.
- Note) #6. cylinder is located at the side where cooling fan was installed.
- Note) #1. cylinder is positioned at the valve overlap when #6. cylinder is positioned at the compression TDC (Top Dead Center).

(I: Intake, E: Exhaust)

Cylinder No.	#	1	#	2	#	3	#	4	#	5	#(6
Cyllider No.	I	Ε	I	Е	I	Ε	I	Ε	I	Ε	I	Ε
#1 TDC	•	•	•			•	•			•		
#6 TDC				0	0			0	0		0	0

3) As for the valve clearance, adjust it when in cold.


Specifie	ed value	Measurement tolerance				
Intake valve	Exhaust valve	Intake valve	Exhaust valve			
0.3 mm	0.3 mm	±0.05 mm				

ACAUTION

- Crankshaft revolution is done by hands without using a starting motor.
- Turn it to the direction of engine rotation, but do not use the installing bolts at the turn.
- The cylinder no. and the order of intake and exhaust can be determined from the flywheel housing.

Cylinder Compression Pressure

- 1. Start and warm up the engine.
- 2. Stop the engine and disassemble the fuel injection nozzle holder assembly.
- 3. Install a special tool, compression pressure gauge adapter in the fuel injection nozzle holder hole.




DV2213046A

4. Connect the compression pressure gauge to the adapter.

Standard	Above 28kg/cm ²
Tolerance limit	24kg/cm ²
Difference between each cylinder	Within ±10%

Note) Testing conditions: at water temperature of 20°C and speed of 200 rpm (10 turns)




EA9O5004

Electric system

Battery

- Check for the electrolyte leakage by crack in the battery, and replace the battery if defective.
- Check the amount of electrolyte, and replenish distilled water if insufficient.
- Check the specific gravity of electrolyte. If it is below the specified value (1.12 ~ 1.28), replenish it.



DV2213040A_E

Starter

When servicing the engine, immerse the starter motor's pinion gear and ring gear in the fuel, wash them completely, and apply grease again. When you clean the surrounding of engine, be careful so that water may not enter the starter.

ACAUTION


- Starter should be protected from humidity all the time.
- Before working on the electric system, be sure to disconnect the ground wire ("-" minus wire) of the battery. Short circuit may occur while working on the electrical system. Connect the ground wire last after completing all of work.

Others/driving system

V-Belt


The tension of the V-belts should be checked daily .

- 1. Change the V-belts if necessary
- 1) If in the case of a multiple V-belt drive, wear or differing tensions are found, always replace the complete set of V-belts.
- 2. Checking condition
- 1) Check V-belts for cracks, oil, overheating and wear.
- 3. Testing by hand




EA9O2006

- 1) For the V-belt tension, when you press the center between pulleys, if it is pressed by 10~15mm, it is normal.
- 2) To check the tension of V-belt more accurately, you can use a V-belt tension gauge.
- 4. Tension measurement
- 1) Lower indicator arm (1) into the scale.



DV2213048A

2) Apply tester to belt at a point midway between two pulleys so that edge of contact surface (2) is flush with the V-belt.



DV2213049A

3) Slowly depress pad (3) until the spring can be heard to disengage. This will cause the indicator (1) to move upwards.


Note) If pressure is maintained after the spring has disengaged a false reading will be obtained.

- 4) Read the tension value at the point that the top surface of indicator arm(1) intersects with the scale.
- 5) Before taking readings makes ensure that the indicator arm remains in its position.

Note) If the value measured devotes from the setting value specified, the V-belt tension must be corrected according to the following table.

			Tension f	from a Tension Meter				
١.	Туре	Belt	New b	Replace-				
'		width (mm)	Upon installa- tion	After 10 minute	ment required			
	М	8.5	50	45	40			
	Α	11.8	55	50	45			
	В	15.5	75	70	60			
	С	20.2	75	70	60			
3	3V-2	18.8	90~100	70~80	60			
3	3V-4	39.4	180~200	140~160	120			
3	3V-6	60.0	270~300	210~240	180			


5. Tension adjustment and V-belt replacement



EDB58180011

- 1) Loosen fixing bolts and nuts.
- 2) Adjust the alternator until V-belts have correct tensions.
- 3) Tighten fixing bolts and nuts.
- 4) To change the V-belts loosen fixing bolts and nuts. Then push the alternator toward water pump pulley by hand.

6. Poly belt tension



EB5O6002

Number of belt folds (PK type)	Tension (kgf)
3	20 - 27
4	27 - 36
5	34 - 45
6	41 - 57
7	48 - 66
8	59 - 73

4. Regular inspection		

Marking system of units	75
Unit Conversion Methods	75
Tightening torque	76
Tightening torque of main parts	76
Tightening Torque of General Bolts	77
Tightening torque of plug screw	78
Hollow Screw (4-Hole) Tightening Torque	78
Engine Disassembly	79
Procedure of Disassembling an Engine	79
Engine Assembly	88
Procedure of Assembling Engine	



Marking system of units

Unit Conversion Methods

The following methods show how to convert SI units to US units and vice versa.

1. To convert an SI unit to a US unit, multiply a SI unit with the number in the following table.

Note) (SI Unit) X (Number) = (US Unit)

Note) 1mm X 0.03937 = 0.03937 in

2. To convert a US unit to an SI unit, divide the US unit by the number in the following table.

Note) (US Unit) \div (Number) = (SI Unit)

Note) 1 in \div 0.03937 = 25.4 mm

Item	Number	SI Unit	US Unit
	0.03937	mm	in
Length	3.28084	m	ft
	1.093613	m	yd
	0.621371	km	mile
	0.00155	mm ²	in ²
Area	0.1550	cm ²	in ²
Alea	10.76391	m ²	ft ²
	1.19599	m ²	yd ²
Weight	2.204623	kg	lb
weign	0.001	kg	t (ton)
	0.061024	СС	in ³
	0.061024	ml	in ³
Volume	0.061024	cm ³	in ³
	61.023744	L	in ³
	0.264172	L	gal
F8	2.204622	kgf	lbf
Force ^a	0.2248089	N	lbf
Acceleration	3.28084	m/s ²	ft/s ²
Acceleration	39.37008	m/s ²	in/s ²
	7.233014	kgf·m	ibf·ft
Torque ^b	86.79619	kgf∙m	ibf∙in
Torque	0.7375621	N·m	ibf∙ft
	8.850748	N·m	ibf∙in

Item	Number	SI Unit	US Unit	
Power	1.340483	kw	Нр	
Pressure	0.01	kPa	bar	
	7.500615	kPa	mmHg	
Pressure	20.88543	kPa	lb/ft ²	
	14.2233	psi	kg/cm ²	
Power	1.3596	kw	PS	
rowei	0.98635	ps	hp	
Fuel Consum ption	0.00162	g/kwh	lb/psh	
	0.000947817	J	BTU	
Energy	0.7375621	J	lbf∙ft	
	0.000277778	J	Wh	
Luminous Flux	0.09290304	lm/m ²	lm/ft ²	
Speed	0.6213712	km/h	mph	
Temperature	С	°C	°F	

a. $9.806 \times (kgf) = (N)$

b. $9.806 \text{ x (kgf·m)} = (N \cdot m)$

c. $\{(9/5) \times (^{\circ}C) + 32\} = (^{\circ}F)$ $\{(^{\circ}F) - 32\} \times (5/9) = (^{\circ}C)$

Tightening torque

Tightening torque of main parts

Major Parts	Screw (Diameter x pitch)	Strength (grade)	Tightening Torque	Remarks
Cylinder head bolt	M14 x 1.5	10.9T	1st: 6.0 kgf·m 2nd: 90° 3rd: 90° 4th: 90° 5th: 60° (Angle Method)	
Connecting rod bearing cap bolt	M14 x 1.5	12.9T	1st: 4 ±0.2 kgf·m 2nd: 60° ±3°	
Crankshaft main bearing cap bolt	M16 x 1.5	12.9T	1st: 15 kgf·m 2nd: 25 kgf·m 3rd: 30 kgf·m	
Crankshaft main bearing cap bolt	M12 x 1.5	10.9T	9.0 kgf·m	
Flywheel housing fixing bolt	M14 x 1.5	10.9T	8.0 kgf·m	
Flywheel fixing bolt	M14 x 1.5	10.9T	18.0 ±3.6 kgf·m	
Crankshaft pulley fixing bolt	M12 x 1.5	10.9T	13.4 kgf·m	
Oil spray nozzle	M14 x 1.5	-	4.5 ±0.45 kgf·m	
Injection nozzle nut	M28 x 1.5	-	7.0 ±0.5 kgf·m	
Injection pump bracket bolt	M10	8.8T	4.4 kgf·m	
Injection pump coupling bolt	-	-	6.0 ~ 6.5 kgf·m	
Injection pump driving gear nut	M24 x 1.5	8.8T	25.0 kgf·m	
Injection pipe nut	M14 x 1.5	8.8T	3.0 kgf⋅m	
Injection pump delivery valve holder	-	-	11.0 ~ 12.0 kgf·m	

Tightening Torque of General Bolts

Please refer to the following tightening torque for the bolts which are not listed in Tightening Torque of Main Parts.

1. Tightening Torque of General Bolts

					Strengt	th Classi	fication				
	3.6	4.6	4.8	5.6	5.8	6.6	6.8	6.9	8.8	10.9	12.9
Nominal Diameter ×	(4A)	(4D)	(4S)	(5D)	(5S)	(6D)	(6S)	(6G)	(8G)	(10K)	(12K)
Pitch (mm)				Е	lastic Liı	mit Value	(kg/mm	²)			l
	20	24	32	30	40	36	46	54	64	90	106
		•		•	Tighteni	ng Torqı	ue (kg·m)		•	
M5	0.15	0.16	0.25	0.22	0.31	0.28	0.43	0.48	0.5	0.75	0.9
M6	0.28	0.30	0.45	0.4	0.55	0.47	0.77	0.85	0.9	1.25	1.5
M7	0.43	0.46	0.7	0.63	0.83	0.78	1.2	1.3	1.4	1.95	2.35
M8	0.7	0.75	1.1	1	1.4	1.25	1.9	2.1	2.2	3.1	3.8
M8 x 1	0.73	0.8	1.2	1.1	1.5	1.34	2.1	2.3	2.4	3.35	4.1
M10	1.35	1.4	2.2	1.9	2.7	2.35	3.7	4.2	4.4	6.2	7.4
M10 x 1	1.5	1.6	2.5	2.1	3.1	2.8	4.3	4.9	5	7	8.4
M12	2.4	2.5	3.7	3.3	4.7	4.2	6.3	7.2	7.5	10.5	12.5
M12 x 1.5	2.55	2.7	4	3.5	5	4.6	6.8	7.7	8	11.2	13.4
M14	3.7	3.9	6	5.2	7.5	7	10	11.5	12	17	20
M14 x 1.5	4.1	4.3	6.6	5.7	8.3	7.5	11.1	12.5	13	18.5	22
M16	5.6	6	9	8	11.5	10.5	17.9	18.5	18	26	31
M16 x 1.5	6.2	6.5	9.7	8.6	12.5	11.3	17	19.5	20	28	33
M18	7.8	8.3	12.5	11	16	14.5	21	24.2	25	36	43
M18 x 1.5	9.1	9.5	14.5	12.5	18.5	16.7	24.5	27.5	28	41	49
M20	11.5	12	18	16	22	19	31.5	35	36	51	60
M20 x 1.5	12.8	13.5	20.5	18	25	22.5	35	39.5	41	58	68
M22	15.5	16	24.5	21	30	26	42	46	49	67	75
M22 x 1.5	17	18.5	28	24	34	29	47	52	56	75	85
M24	20.5	21.5	33	27	40	34	55	58	63	82	92
M24 x 1.5	23	25	37	31	45	38	61	67	74	93	103

Note) The standard torque values above are about 70% of the bolt elastic limit values.

Note) The tensile force has been calculated by multiplying the tensile strength with the screw cross-sectional area.

Note) A special screw should be tightened with 85% of the tightening torque of the standard value. For example, a MoS2-coated screw should be tightened with 60% of the tightening torque of the standard value.

2. Tightening Torque of Key General Bolts

		Strength Classification		
Nominal Diameter x Pitch (mm)	8.8T	10.9T	12.9T	Remarks
	Tigl			
M6 x 1	1	1.25	1.5	
M8 x 1.25	2.2	3.1	3.8	
M8 x 1	2.4	3.35	4.1	
M10 x 1.5	4.4	6.2	7.4	
M10 x 1.0	5	7	8.4	
M12 x 1.75	7.5	10.5	12.5	
M12 x 1.5	8	11.2	13.4	
M14 x 1.5	13	18.5	22	

Tightening torque of plug screw

M10	M12	M14	M16	M18	M22	M24	M26	M30
5.0	5.0	8.0	8.0	10.0	10.0	12.0	12.0	15.0

Hollow Screw (4-Hole) Tightening Torque

Material Classifi- cation	M8	M10	M12	M14	M16	M18	M22	M26	M30	M38
SM25C	-	1.6	2.5	3.5	4.5	5.5	9.0	13.0	18.0	30.0
SUM22L ^a	0.8	1.8	3.0	4.0	5.5	6.5	11.0	16.0	20.0	35.0
STS304	0.8	1.8	3.0	4.0	5.5	6.5	11.0	16.0	20.0	35.0

a. Applied to Hyundai Doosan Infracore Engines

Engine Disassembly


Procedure of Disassembling an Engine

ACAUTION

- Prepare tools and genuine parts necessary before disassembling engine.
- Prepare a shelf for the storage of removed parts.
- · Perform repairs in a light and clean space.
- · Keep hands clean while performing repairs.
- Keep parts removed from the engine in the order of disassembly.
- Do not allow parts removed from the engine to touch each other or be mixed with other parts.

Disassemble the engine in the following order.

- 1. Remove the oil level gauge
- 1) Pull out the oil level gauge.
- 2. Drain cooling water
- 1) Remove the radiator cap. Open the drain plug at the radiator lower part to drain the coolant as the right figure.




EA5O4002

ACAUTION


When removing radiator filler cap while the engine is still hot, cover the cap with a rag, then turn it slowly to release the internal steam pressure This will prevent a person from scalding with hot steam spouted out from the filler port.

2) Remove the drain plug from the cylinder block and drain out the cooling water into a container.




EA9O4003

3. Drain engine oil



EA9O4001


- Remove the oil drain cock of oil pan and pour the engine oil into the prepared vessel.
- 4. Remove the cooling fan



EA9M3001


 Remove the flange fixing bolts, then take off the flange and cooling fan.

5. Remove the V-belt




EA902007

- 1) Remove the V-belt by loosening the alternator tension adjusting bolt and tighten the bolt.
- 6. Remove the starter




ED7OM003

- 1) Loosen the starter assembling nuts and remove the starter being careful not to damage its gears.
- 7. Remove the fuel filter




ED7OM009

- 1) Remove the hollow screws of filter and tear down fuel supply and discharge rubber hose.
- 2) Remove fuel filter assembling bolts and disassemble the fuel filter.
- 8. Remove the breather
- 1) Loosen the clamp screw to remove the rubber hose.
- 9. Remove the Inter cooler



EA6M2001


- Tear down the various hoses and air pipes from the inter cooler.
- 2) Remove the intercooler fixing bolts and tear it down.
- 10. Remover the Alternator



EA9M3004


- Remove the alternator fixing bolts and disassemble the alternator.
- 2) Remove the tension adjusting bolts and bracket.

11. Remove the oil cooler



ED70M012


- 1) Loosen the cooling water pump and the rubber hose clamps of connected pipes, and disassemble it.
- 2) Remove the oil cooler assembling nuts and disassemble it
- 12. Remove the oil filter



EB8M3002


1) Remove the oil filter assembling bolts and disassemble the oil filter assembly.

13. Remove the water pump




ED7OM008

- 1) Remove the water pump assembling bolts and disassemble the water pump.
- 14. Remove the cylinder head cover



EB5M3012

- Remove the head cover assembling bolts and lift the cover.
- 15. Remove the nozzle




ENM3013S

- 1) Remove the fuel supply high pressure pipe and its assembling nuts that are connected between fuel injection pump and nozzle and disassemble the pipes.
- 2) After installing the special tool for removing nozzle temporarily, loosen the holder and then hammer up with a hammer which is a special tool so as for nozzle assembly to be disassembled.

ACAUTION


Be careful not to damage the nozzle at disassembled.

- 3) Pull the seal ring out through the nozzle hole of cylinder head and scrap it.
- 16. Remove the turbo charger



ED7OM010

- 1) Disassemble the oil supply pipe that supplies oil from cylinder block to turbo charger and the oil discharge pipe that discharges oil from turbo charger to cylinder block.
- 2) Remove the turbo charger assembling nuts and disassemble it from the exhaust manifold.
- 17. Exhaust manifold




ED70M011

- 1) Remove the exhaust manifold assembling nuts and disassemble the heat shield from the exhaust manifold.
- 2) Then disassemble the exhaust manifold and gasket.

ACAUTION

Do not reuse the gasket.

- 3) Scrap the used gasket.
- 18. Remove the intake manifold




ED7OM005

- 1) Remove the cooling water pipe assembling bolts and disassemble the pipe for the cylinder head.
- 2) Remove the gasket of cooling water pipe with a scraper thoroughly.

ACAUTION

Be careful for the gasket pieces not to get in the passage of cooling water.

19. Remove the cooling water pipe




ED7OM006

- Remove the cooling water pipe assembling bolts and disassemble the pipe for the cylinder head.
- 2) Remove the gasket of cooling water pipe with a scraper thoroughly.

ACAUTION


Be careful for the gasket pieces not to get in the passage of cooling water.

20. Remove the rocker arm



EA9M3011

- Remove the rocker arm bracket assembling bolts in the reverse order (zigzag method) of assembling and disassemble the rocker arm.
- 2) Disassemble the push rod.
- 21. Remove the cylinder head



EAMD102

- Remove the cylinder head bolts in the reverse order of tightening.
- 2) Remove it step by step.
- First step: Loosen 1 ~ 2 threads

Second step: Remove by loosening fully.


ACAUTION

- Lay the removed bolts orderly not to damage the threads at all and store.
- Prevent a collision between the bolt thread each other.
- 3) Take out the cylinder head gasket and scrap it.
- 4) Remove the foreign residues from the cylinder head surface and block surface.

ACAUTION


Try not to make any damage on the contact surfaces.

22. Remove the oil pan




EAMD034I

- Remove the oil pan assembling bolts and disassemble the pan.
- 2) After removing the oil pan gasket, scrap it.
- 23. Remove the Vibration damper




EA9M3012

- Remove the vibration damper assembling bolts in the reverse order of assembling and disassemble the damper assembly
- 24. Remove the timing gear case cover




- 1) Disassemble the oil seal using an oil seal removing jig.
- 2) Remove the cover fixing bolts and disassemble the cover from the timing gear case.
- 25. Remove the oil pump



EFM2025I

- 1) Remove the bracket fixing bolts of oil intake pipe.
- 2) Remove the pipe assembling bolts of oil pump and disassemble intake and supply pipe.
- 3) Remove the oil pump assembling bolts, and disassemble the oil pump.

26. Remove the piston assembly




EFM2026I

- Remove the connecting rod cap bolts in the reverse order of assembling but do same as the cylinder head bolt removal.
- Disassemble the upper/lower of connecting rod caps by tapping lightly with urethane hammer, and remove the bearing.
- By pushing the connecting rod with wooden bar from the direction of oil pan toward cylinder head, disassemble the piston assembly.
- 4) The disassembled piston assembly should be handled to prevent bumping each other, and stored as the cylinder's order.
- In order for connecting rod cap not to be swapped, temporarily assemble to the corresponding connecting
- 27. Disassemble the piston assembly
- 1) Remove the snap rings by means of a plier.




EAMD038I

 Heat the piston with a electric heater, then take out the piston pin from the piston as tapping it with a round wooden bar.




3) Remove the piston ring with a plier.



EAMD039I


- 4) Clean the piston thoroughly.
- 28. Remove the cylinder liner



EAMD087I


 Disassemble the cylinder liner with a special tool or hand but be careful not to generate any damage at cylinder block.

- 29. Remove the gear and idle gear pin
- 1) Remove the camshaft gear assembling bolts and disassemble the camshaft gear.




EDM2025

2) Remove the idle gear assembling bolts and disassemble the idle gear pin.




EAMD026S

- 30. Remove the fuel injection pump
- 1) Disassembly the oil hose for lubrication.
- 2) Remove the injection pump flange assembling nuts.




EAMD021

3) Remove the bracket fixing bolts of injection pump, and disassemble by pulling the injection pump backward.




EAMD022I

- 31. Remove the water chamber cover
- Remove the assembling bolts and disassemble the water chamber cover.
- 2) Remove the remnant gasket thoroughly.
- 32. Remove the flywheel




EDM2072I

- Remove the flywheel assembling bolts and disassemble it
- 2) The bolt removal is done by the reverse order of assembling and by the steps.
- 33. Remove the flywheel housing



EA9M3013


- Remove the flywheel housing assembling bolts and disassemble the flywheel housing.
- 2) Disassemble the oil seal of flywheel housing.
- 34. Remove the Injection pump drive gear
- 1) Remove the assembling nuts of drive gear.
- 2) Remove the drive gear housing assembling nuts and disassemble the gear assembly.
- 35. Remove the timing gear case



EAMD046I

- 1) Remove the timing gear case assembling bolts.
- 2) By tapping lightly with a urethane ham-mer the right and left back of timing gear case's connecting part, disassemble the timing gear case.

36. Remove the Bearing cap



EAMD047S

 Remove the bearing cap assembling bolts by the step in the reverse order of assembling, and disassemble the bearing cap.


Note) Remove by the sameway as the cylinder head bolts' removal.

- 2) Disassembled bearing caps are kept laid in order.
- 37. Remove the crankshaft
- Assemble the bolts on the both side of crankshaft temporarily
- Connect the rope to the bolts and lift the crankshaft by means of crane being careful not to give any damage on it.
- In order for the disassembled crankshaft to be prevented from bends or damage, put it on the special lathe and store.
- 4) Disassemble the metal bearings in turn and store them.

ACAUTION


Do not mingle with the metal bearings and bearing caps randomly. To prevent mixing, temporarily assemble the metal bearings to the corresponding bearing caps in turn.

38. Remove the camshaft and tappet



EAMD072S

- In order for camshaft not to be damaged, disassemble turning it.
- In order for the disassembled camshaft to be prevented from bends or damage, put it on the special lathe and store
- 3) Pull out the tappet.
- As required, pull out the camshaft bush from the cylinder block by a press.
- 5) Check for damage, scratch, and wearing state and if abnormal, tear down.
- 39. Remove the oil spray nozzle



EAMD048S

 Remove the valve screws of oil injection nozzle and disassemble it.

Engine Assembly


Procedure of Assembling Engine

CAUTION

- Cleanse all disassembled and disconnected parts.
 Especially, clean the oil and coolant path with compressed air and check if there is any resistance.
- Arrange general tools and special tools for engine assembly.
- Prepare clean engine oil to be applied on each sliding component.
- Prepare repair materials such as sealant and gaskets.
- Replace used gaskets, seal rings, and expendable parts with new ones.
- Each bolt should be tightened with the specified tightening torque in the order of tightening; however, excessive tightening torque should be avoided.
- Ensure that all engine parts are successfully operating after reassembly.
- · Check if any bolts are loose after the first assembly.
- · Always keep hands clean during assembly.

Assemble the engine in the following order.


- Cover the floor of the workshop with wood plate or thick paper to prevent damage to the cylinder head and place the cylinder block with the head fitting surface facing downward.
- 2. Attach the oil spray nozzle.



1) Tighten and assemble the oil spray nozzle flange with fixing bolts using the spray nozzle jig.

Torque	8 kg·m
--------	--------

- 3. Attach the tappet and cam shaft.
- Undercool a new bush with dry ice for about 2 hours and press it into position in the cylinder block using a bench press. After the pressing operation, measure the inside diameter of the cam bush to check if it is not deformed.
- 2) Apply engine oil to the entire face of the tappets and slide them into the tappet holes on the cylinder block.




EAMD072S

 Wet the cam bush inside diameter and camshaft with oil, and carefully assemble them while turning the camshaft.

ACAUTION


Be careful not to generate a damage to camshaft and bush.

4) Check to see that the camshaft rotates smoothly.




EDM2060I

4. Attach the crankshaft.




EFM2061I

 Install the main bearing (refer to assemble sequence: right figure) machined with two holes in the cylinder block so that the key is aligned with the key groove, then apply oil to the bearing surface.




EA0M4083

 Heat the crankshaft gear for at least 10 minutes to 120°C, then apply sealant (Loctite # 641) to the inside wall of the heated crankshaft gear evenly before inserting it to the end of crankshaft.




EA8M3014

3) Semi-tighten a bolt at both sides of the crankshaft, apply engine oil to journals and pins, then assemble the crankshaft with the cylinder block by tightening the fixing bolts.




EAMD075S

- 4) Coat engine oil to the pin and journal of crankshaft.
- 5) Install the oiled thrust washers with the oil groove facing outward.




EAMD076S

6) Install the bearing and thrust washers to the bearing cap and apply oil to the bearing and thrust washers.



EDL11180004


7) Install the bearing cap by matching the cylinder block No. with the bearing cap No.



EQM3058I

8) Apply oil to the entire part of the bearing cap bolts, then tighten in tightening sequence to specified torque.


Torque	30 kgf·m



- 9) After semi-tightening both bolts evenly, tighten them diagonally to the specified torque using a torque wrench as follows.
- 1st: Temporary bolt screwing about 1 ~ 2 threads.
- 2nd: With impact wrench, tighten up to about 15kgf·m.
- 3rd: With torque wrench, tighten up to about 25kgf·m.
- 4th: By means of torque wrench, tighten finally in the specified torque. (30kgf·m)
- 10) Tighten the bearing cap in the sequence of 4-3-5-2-6-1-7.
- 11) Check to see that the assembled crankshaft turns smoothly.
- 5. Attach the flywheel housing.
- 1) Temporarily install the guide bar on the cylinder block.
- 2) Apply gasket to the cylinder block.
- 3) Using the dowel pin and guide bar, install the flywheel housing and tighten the fixing bolts in a diagonal sequence to specified torque. (Zigzag method)


Torque	8 kgf·m
--------	---------

- 4) When the bolts are tightened, remove the guide bar.
- 5) The flywheel housing is assembled after the new oil seal was pressed (Coat engine oil over the outside of oil seal) before in the housing by a press.



EA9M3013

- 6) If any peripheral scar was generated due to oil seal at the oil seal contact surface of crankshaft, after inserting about 1 mm shim or thereabout in front of oil seal (Direction toward crankshaft.), measure and adjust.
- 6. Attach the rear oil seal.




EA8M3003


- Apply lubricating oil to the outside of the oil seal and flywheel housing inside diameter and fit them over the crank shaft, then assemble the oil seal using an oil seal fitting jig.
- 7. Attach the flywheel.
- Installation of flywheel ring gearWith a gas burner, heat the ring gear evenly until heat expansion takes place, then install it using a hammer.

ACAUTION

Do not allow the temperature of the ring gear to exceed 200°C




EA0M4029



EDB58180008

2) Install a guide bar into a bolt hole on the crank shaft, and lift the flywheel to align the dowel pin with the pin hole on the f I ywheel for temporary assembly operation.




EDM2072I

3) Coat the adhesive (#271 Loctite) over the assembling bolts and install bolts in the remaining holes. After that take out the guide bar, then install a bolt in the hole where the guide bar had been inserted.


 According to the order of tightening tighten the fixing bolts using a torque wrench in a diagonal sequence to specified torque.

Torque 18.5 kgf·m




EDM2073I

8. Attach the Tacho sensor.




EPM2030I

- Move the lock nut to hexagonal side of sensor completely.
- 2) Rotate (CW) the tacho sensor on fly wheel housing, until the end of it reach on fly wheel ring gear.
- Rotate (CCW) the tacho sensor for 270° (gap 1.0 mm) and fix lock nut.
- 4) Tolerance limit is ±27°. (gap ±0.1 mm)
- 9. Attach the cylinder liner.
- Stand the cylinder block so that the flywheel faces downward.
- Thoroughly clean the liner flange fitting surface and bore inside with compressed air to prevent the entry of foreign substances.
- After the cleaning operation, make the cylinder liner dried up and push it into the cylinder block by hand.




EAMD087I

- 4) Wet the liner inside diameter with engine oil.
- 10. Attach the water chamber cover.
- Coat the adhesive over the water chamber cover (Particular around bolt holes) and after attaching the gasket, assemble it to the cylinder block using the bolts for assembling.
- 2) As for tightening of bolts, after primarily tightening the bolts located at the both ends of cover (4ea at both sides) and middle bolts (Upper, lower 2ea), tighten the rest.
- 11. Attach the piston and connecting rod
- Use a piston heater to heat the piston approximately 100°C for 5 minutes.




DV2213156/

 Align the piston pin hole with the oiled connecting rod small end and press the piston pin (by lightly tapping with a rubber hammer) to assemble the connecting rod with the piston.




EAMD088I

- Install the snap rings and check to see that it is securely assembled.
- 4) Install the piston ring in the piston using piston ring pliers.
- 5) Identify the mark "Y" or "TOP" on the ring end to prevent the top and bottom of the piston ring from being interchanged and make the marked portion face upward. (The surface marked as "Y" is upper surface.)



EAMD090I

- 12. Attach the piston assembly.
- Adjust the angle among individual piston ring gaps to 90° and fit a piston assembling jig onto the piston, Use care not to match the ring gaps with the pin direction.




EDL11180005

- 2) Install the bearing by aligning it with the connecting rod key groove and apply oil to the bearing and piston.
- Position the valve seating surface toward the tappet hole and insert the piston with hand.


ACAUTION

Use care not to damage the cylinder liner and piston, and slightly lift and insert the piston into the cylinder so that the ring may not be damaged by the fillet of the liner.



4) Install the bearing in the connecting rod cap and apply oil.

5) Make sure that the manufacture serial numbers impressed on the connecting rod cap and connecting rod big end are identical, and install the connecting rod cap by aligning it with dowel pin.



EA0M4092


6) Tighten the fixing bolts to the specified torque using a torque wrench as follows.

<Connecting rod tightening torque>

Tightening	1st Step	4 ±0.2 kgf·m
torque	2nd Step	60° ±3°


Note) Do not apply oil to the joint before bolting.

7) Move the bearing cap with hand, and release and reassemble it if no movement is detected.




EAMD094I

13. Attach the Timing gear case.



EAMD082I

- Mount a new gasket using dowel pin on the cylinder block
- 2) Put the time gear case to the cylinder block by aligning the dowel pin hole of timing gear case with its pin, and then assemble it by tapping lightly with an urethane hammer to the right and left (Particularly around dowel pin).
- 3) Tighten the bolts for assembling to the specified torque.
- 4) Tighten primarily the bolts of both end parts and then do the rest.
- 14. Attach the timing gear and idle gear pin.
- 1) Install the oil pump idle gear onto the No.7 bearing cap.
- 2) With the oil port on the idle gear pin facing the cylinder block, install the idle gear pin.




EA8M3004

- 3) With the oil port on the idle gear pin facing the cylinder block, install the idle gear pin.
- 4) Install a thrust washer over the camshaft and assemble the cam gear by aligning it with camshaft key groove. Tighten the cam gear assembling bolts to the specified torque. (Zigzag method)

Torque 2.2 kgf·m

 Install the idle gear by coinciding the marks impressed on the crank gear, cam gear, fuel injection pump drive gear, and idle gear.



EA9M3015


6) Install a thrust washer on the idle gear and tighten to specified torque.

Torque 3.1 kgr·m	Torque	3.1 kgf·m
------------------	--------	-----------

7) Check and adjust the amount of backlash between gears using a feeler gauge.


Measuring position (between)	Backlash (mm)	Limit (mm)
Cam gear & idle gear	0.16 ~ 0.28	0.35
Crank gear & idle gear	0.16 ~ 0.28	0.35
Injection pump & idle gear	0.16 ~ 0.28	0.35

15. Attach the injection pump flange.



EA9M3021

- After assembling the fuel injection pump gear to the idle gear, tighten the assembling bolts of the injection pump flange.
- 2) Mount gasket by aligning the bolt holes with the pin holes on the bearing housing.
- 3) Turning the flywheel, adjust the pointer to the 16° position of the engraved scale.
- 4) After adjusting the injection timing of fuel injection pump drive gear, tighten the fixing bolts in the direction of fuel injection pump.
- 16. Attach the injection pump.
- 1) Install the injection pump bracket in the cylinder block.
- 2) After measuring the amount of run-out with an alignment setting jig.



EAMD107

3) Disassemble the bracket, adjust the shims, then reassemble it.


Run out 0.2 mm or less

- 4) Mount the top/bottom adjusting shims in the bracket and then mount the fuel injection pump.
- 5) Tighten the fixing bolts in a diagonal sequence to specified torque.

Torque 4.4 kgf·m	Torque	4.4 kgf·m
------------------	--------	-----------

- 17. Adjust injection timing.
- Bring the piston of #1 cylinder to the compression TDC (OT) by turning the crankshaft. Again, turn 60° in the reverse direction of engine rotation.
- 2) Disassemble the fuel injection pipe that connect the fuel injection pump and #1 injection nozzle.
- 3) Disassemble the fuel injection pump delivery valve holder, and after removing the valve and valve spring, again assemble the valve holder and then, on it assemble the pipe of "U" shape on it.

- 4) Operating the priming pump of supply pump, turn the crankshaft slowly in the direction of engine rotation until the fuel will drop at the rate of a drop for 6 ~8 sec.
- 5) Confirm then whether the indication point at the flywheel housing inspection hole and the engraved specified injection angle are coincided or not, and if the injection timing is not correct, adjust as follows.




EA9O5001

Engine Model	Injection timing	Remarks
D1146	18°	BTDC
D1146T	18°/12°	BTDC
P086TI	12°	BTDC
DP086TA	19°	BTDC
DP086LA	14°	BTDC
PU086	18°	BTDC
PU086T	18°/12°	BTDC
PU086TI (EBPPA)	15° ±1°	BTDC
PU086TI (EBPPB)	18° ±1°	BTDC

- b) Loosen the drive gear fixing bolt of injection pump a bit.
- After turning slowly the coupling of injection pump until
 the fuel will drop from #1 plunger at the rate of a drop for
 6 ~ 8 sec., tighten the driving gear fixing bolt of fuel pump.
- 6) After the adjustment of injection timing, disassemble the "U" shape pipe, readjust the delivery valve and the valve spring.


7) Turn the coupling until the notch mark of the indicator plate attached to the fuel injection pump is aligned with the notch mark of the coupling.



EA9O5002

8) Tighten the Coupling fixing bolts and nuts to specified torque.


Torque	6.0 ~ 6.5 kgf·m



EAMD021I

9) Install the oil delivery pipe and return pipe.

18. Attach the oil pump and oil pipe.




EFM2025I

- Install a dowel pin in the No.7 bearing cap, then assemble the oil pump by tapping lightly with urethane hammer.
- 2) Insert the lock washers and tighten the assembling bolts with specified torque.

Torque 4.4 kgf·m

- Assemble the oil suction pipe with the delivery pipe to oil pump by the bolts.
- 19. Attach the water pump.




ED7OM008

- 1) Mount a new gasket.
- 2) Install the water pump on the cylinder block and tighten the assembling bolts with specified torque.

Torque	2.2 kgf·m


- Connect water pipes and by-pass pipe to the water pump.
- 4) Connect a water pipe to the expansion tank.

20. Attach the front oil seal.



EAMD086I

- Apply lubricating oil to the outside of the oil seal and the oil seal hole of the timing gear case cover.
- Put the new oil seal on the oil seal hole of timing gear case cover aligning the center of them, then assemble the oil seal using an oil seal fitting jig.
- 21. Attach the timing gear case cover.




EAMD085S

- 1) Install dowel pin on the timing gear case.
- 2) Mount a gasket by aligning the fixing bolt holes with those on the gasket.
- 3) Align the dowel pin with the cover pin hole, then install the cover with light tap.
- Tighten the fixing bolts beginning with the oil pan fitting face


⚠ CAUTION

In the assembling, be careful not to be damaged by the crankshaft.

22. Attach the vibration damper.



EAMD111S



EDM2089I

 Insert the vibration damper to the crankshaft, and assemble by tightening the assembling bolts at the specified tightening torque according to bolt tightening order. (refer to right figure.)

13.4 ±2.6 kgf·m

23. Attach the oil pan.

 Remove the gaskets thoroughly that project at the timing gear case, case cover of cylinder block, and the contacting part of flywheel housing by means of a scraper.


ACAUTION

Be careful for the gasket pieces not fall into the engine during the work.

2) Coat the silicone at the gasket part that was removed (Contacting part), and attach the new oil pan gasket.


3) Assemble the oil pan by tightening the oil pan assembling bolts, and when tightening bolts, primarily tighten the bolts (4ea) at the both ends, and then tighten the rest bolts to specified torque.

Torque	2.2 kgf·m
--------	-----------



EAMD034

- Align the bolt holes with gasket holes to prevent damage to the gasket and tighten.
- 24. Attach the oil filter.




EB8M3002

 Install the oil filter onto the cylinder block, and tighten the fixing bolts.

Torque 2.2 kgf·m


2) Install packing and assemble the cartridge using a filter wrench.

25. Attach the oil cooler.



ED7OM012

- Assemble the oil cooler assembly by tightening the assembling nuts.
- 2) Connect the cooling water pipe with the cooling water pump and tighten a hose clamp.
- 26. Attach the starter.




ED7OM004

1) Assemble the starter in position on the flywheel housing.


Torque	4.4 kgf·m
--------	-----------

- 27. Attach the intake and exhaust valves.
- Identify the marks of "IN" and "EX" impressed on the valve head before assembling the valve with the valve head.
- 2) With a valve stem seal fitting jig, assemble the valve stem seal with the valve guide.



EA9M3017

3) After installing valve springs and spring retainer, press the retainer with a jig, then install cotter pin.




EA0M4007

- 4) Tap the valve stem lightly with a rubber hammer to check that the valve is assembled correctly.
- 28. Attach the cylinder head.
- Blow the bolt holes of cylinder block with a compressed air and remove the foreign matter.
- 2) Clean the head gasket contact surface thoroughly.

ACAUTION

Be careful for the foreign mat-erial not to enter into the combustion chamber.

 Assemble the new head gasket by aligning the holes with dowels of cylinder block with 'TOP' mark facing upward.



4) Check the inside of combustion chamber for foreign substances, and carefully mount the cylinder head assembly in the block by aligning the dowel pin with the dowel pin hole.

⚠ CAUTION


- Be careful not to damage the cylinder head gasket. If the dowel pin is not in alignment, lift the cylinder head again and then remount it.
- After tightening the cylinder head bolts, even at disassembling, the cylinder head gasket should be changed a new one.

	Type 1	Type 2			
Specification	TY 12.9T M14 x 1.5 x 146	DL08 M14 x 1.5 x 146			
_		6 kgf·m + 90° + 90°			
Torque	24.5 kgf·m	+ 90° + 60°			

- 5) Tighten in proper sequence to the specified torque according to bolt tightening order.
- 1st: Tighten at about 6 kgf.m with a wrench.
- 2nd: Tighten at rotating angle 90° with a wrench.
- 3rd: Tighten at rotating angle 90° with a wrench.
- 4th: Tighten at rotating angle 90° with a wrench.
- 5th: Finally, tighten at rotating angle method 60° with a torque wrench.


↑ CAUTION

- All bolts are tightened simultaneously by above steps.
- Before tightening bolts, the side parallel degree between cylinder heads should be adjusted.



EDM2097I

- 29. Attach the push rod.
- 1) Coat the push rod with engine oil and insert it into the push rod hole.
- 30. Attach the rocker arm assembly.
- 1) Apply lubricating oil to the rocker arm bush and shaft, and assemble the intermediate bracket with the rocker arm (rocker arm assembly) on the cylinder block using fixing bolts.



EB1M3026


2) In tightening the bolts, it must be done at the specified value using zigzag method.

Torque	M10: 4.4 kgf·m M12: 8.0 kgf·m
--------	----------------------------------

- 3) Semi-install valve clearance adjusting bolts onto the rocker arm.
- 4) Install the spring, rocker arm, bracket, rocker arm, spring, washer, and snap ring in the described sequence.


⚠ CAUTION

Install the rocker arm and bracket in the same direction.



ED7OM002

- 31. Adjust the valve clearance.
- 1) Loosen the lock nuts of rocker arm adjusting screws.
- Push the feeler gauge of specified value between a rocker arm and a valve stem (to measure the clearance of the valve and rocker arm contacting part)
- 3) Adjust the clearance with adjusting screw respectively and then tighten with the lock nut.




EA8M3007

4) Adjust valve clearance with a feeler gauge and tighten the fixing nuts to specified torque.

Torque	4.4 ±0.45 kgf·m
--------	-----------------

32. Guide for valve clearance adjustment



EA9O5005

1) Rotate the crankshaft so that #1. cylinder may be positioned at the compression TDC (Top Dead Center). Then

adjust the valves corresponding to mark " ullet " in the below table.

- Note) #1. cylinder is located at the side where flywheel was installed.
- Note) #6. cylinder is positioned at the valve overlap when #1. cylinder is positioned at the compression TDC (Top Dead Center).
- 2) Rotate the crankshaft one rotation (360°) so that #6. cylinder may be positioned at the compression TDC (Top Dead Center). Then adjust the valves corresponding to mark " ° " in the below table.
- Note) #6. cylinder is located at the side where cooling fan was installed.
- Note) #1. cylinder is positioned at the valve overlap when #6. cylinder is positioned at the compression TDC (Top Dead Center).

(I: Intake, E: Exhaust)

Cylinder No.	#1		#	#2		#3		#4		#5		#6	
Cymraer No.	I	Ε	I	Е	I	Ε	I	Ε	I	Ε	I	Ε	
#1 TDC	•	•	•			•	•			•			
#6 TDC				0	0			0	0		0	0	


3) As for the valve clearance, adjust it when in cold.

Specified value		Measurement tolerance	
Intake valve	Exhaust valve	Intake valve	Exhaust valve
0.3 mm	0.3 mm	±0.05 mm	

CAUTION


- Crankshaft revolution is done by hands without using a starting motor.
- Turn it to the direction of engine rotation, but do not use the installing bolts at the turn.
- The cylinder no. and the order of intake and exhaust can be determined from the flywheel housing.

33. Attach the intake manifold.



ED7OM005

- Put in the new gasket between the cylinder head and manifold, and assemble the intake manifold by tightening the assembling bolts.
- 34. Attach the exhaust manifold.



ED7OM011

 Install the exhaust manifold gasket over the stud bolts by aligning the gasket with the exhaust port on the cylinder head.

ACAUTION

Be careful to position the face and back of the gasket correctly.


2) Semi-assemble the exhaust manifold and install the heat resisting plate.

 Assemble them by tightening the assembling bolts. The tightening order of bolts is from the middle to left and right alternately.

ACAUTION


For upper and lower bolts differ in the length, so use the correct bolts.

35. Attach the turbocharger.



ED7OM010


- Fit a new gasket over the stud bolts of the exhaust manifold before tightening those turbocharger fixing bolts.
- 2) Install the oil supply pipe and return pipe.
- 3) Tighten the clamps of rubber hose that is connected air pipe to the intercooler.
- 36. Attach the cooling water pipe.



ED7OM006


- 1) Attach new cylinder head gasket.
- 2) Assemble the cooling water pipe by tightening the assembling bolts.

37. Attach the alternator.



EA9M3004

- 1) Install the alternator mounting bracket.
- 2) Install the alternator with fixing bolts to the mounting bracket.
- 38. Attach the fuel filter.




EA9M3019

- 1) Assemble the fuel filter with the intake manifold.
- Assemble the fuel feed hose according to the direction of an arrow impressed on the fuel filter head so that fuel can be fed in the sequence of FUEL FEED PUMP FUEL FILTER FUEL INJECTION PUMP.

5. About the engine


39. Attach the Injection nozzle.



EB1M3024

- Mount a seal ring on the seal ring seating surface of the cylinder head and assemble nozzle holder assembly with the nozzle pipe installing direction facing outward.
- 2) Be sure to follow the specified torque.

40. Attach the injection pipe.




ENM3013S

 Semi-assemble a nut at both ends of the fuel high pressure pipe and tighten them up one by one to specified torque.

Torque	3.0 kgf·m
--------	-----------

- 2) Tighten hollow screws to assemble the fuel return pipe.
- 3) Assemble the fuel return hose on the fuel injection pump.

41. Attach the cylinder head cover.




ENM3012S

 Assemble the new gasket with the cylinder cover, install the cover on the cylinder head, then tighten the fixing bolts in sequence to specified torque.

Torque	1.5 kgf·m
--------	-----------


- 2) Assemble the breather hose with PCV valve.
- 3) Insert the oil filler cap in the cylinder head cover.
- 42. Attach the cooling fan.



EA9M3001


- Install the fan drive pulley onto the timing gear case cover.
- Install the fan flange and cooling fan onto the cooling water pump.

43. Attach the V- Belt



EA9O2006

- 1) Install the V-belt on the crank pulley, alternator pulley and water pump pulley.
- 2) Adjust the V-belt tension using the tension adjusting support.
- 44. Attach the oil level gauge



EQM3005I

- 1) Apply sealant (Locktite #262) to the bottom side of the guide tube.
- 2) Then assemble the guide tube and oil level gauge on the oil pan.
- 45. Assemble by connecting the other oil and fuel hoses.

5. About the engine		

6. Cooling system

General information	109
General information	109
Failure Diagnosis	110
Thermostat	
General Information	111
Check of the thermostat	111




General information

General information

This engine is water-cooling type. Heat from the combustion chamber and engine oil heat are cooled down by coolant and radiated to the outside, resulting in the normal operation of the engine.

Looking into the cooling system, the water pumped up by the water pump circulates around the oil cooler through the water pipe to absorb the oil heat, and then flows through the water jacket of the cylinder block and water passage of the cylinder head to absorb the heat of the combustion chamber.

The water absorbing the oil heat and combustion chamber heat goes on to the thermostat through the water pipe, and circulates to the water pump if water temperature is lower than the valve opening temperature on the thermostat, while circulating to the radiator at water temperature higher than the valve opening temperature. At the radiator, the heat absorbed in the coolant is radiated to cool down and the coolant recirculates to the water pump.



EQM4001I

6. Cooling system

Failure Diagnosis

Phenomenon	Causes	Troubleshooting
	Not enough coolant	Replenish the coolant
	Defective radiator cap	Replace it
	Contaminated radiator	Clean the exterior of the radiator
	Defective V-belt offset	Adjust or replace it
	Contaminated or damaged V-belt	Replace it
	Damaged impeller	Replace the coolant pump
Overheated engine	Defective impeller fix	Replace the coolant pump
	Bad coolant pump operation	Replace it
	Bad water temperature controller operation	Replace it
	Bad coolant flow	Clean the coolant path
	Improper injection time	Check it with the failure diagnosis unit
	Damaged cylinder head gasket	Replace it
Overceeled engine	Bad water temperature controller operation	Replace it
Overcooled engine	Too low ambient temperature	Heat the block
	Damaged radiator	Repair or replace it
	Loosened or damaged radiator connection	Repair or replace the connection
	Defective radiator cap	Replace it
	Badly mounted coolant pump	Repair or replace it
Leaking coolant	Bad or damaged coolant pump gasket	Replace the gasket
	Badly mounted water temperature controller	Repair or replace it
	Bad or damaged water temperature controller gasket	Replace the gasket
	Damaged cylinder head gasket	Replace the gasket
	Damaged cylinder head or block	Replace it
	Bad coolant pump bearing	Replace the bearing
Noise	Bad or damaged cooling fan	Repair or replace it
NOISE	Bad rotation of the cooling fan	Replace it
	Defective V-belt offset	Adjust or replace it

Thermostat


General Information

The thermosatat maintains water temperature in the engine consistently and prevents heat loss to improve heat efficiency of the engine.

When the coolant temperature is below the normal temperature, the thermostat is closed and the coolant is bypassed and directly flows into the water pump. When the coolant temperature reaches the normal temperature or is higher than the temperature, the thermostat is fully open and the bypass circuit is closed. So the coolant flows into the radiator.

ACAUTION

- response to the change of cooling water than the bellows type thermostat. This happens because the heat capacity of the wax pellet type water temperature controller is larger than that of the bellows type water temperature controller. Therefore, to prevent rapid increase of engine coolant temperature, you must first operate the engine at idle until the engine is fully warmed up. When the weather is very cold, do not operate the engine in an overloaded condition or at high speed after starting the engine.
- When draining water from the engine cooler or injecting water to the engine cooler, work slowly to let the air in the cooler is fully exhausted.
- When a defect is found in the water temperature controller, replace it with a new one.




DV2213099A

- 1. To radiator
- 2. By pass valve
- 3. To bypass tube
- 4. From cooling water pump

Check of the thermostat

- Check whether the wax pellet and the spring are damaged or not.
- Put the water temperature controller into water and heat the water slowly to check water temperature controller operation.
- The water temperature controller is normal in the following case: it starts to be open at the water temperature of 82°C and it is fully open at the water temperature of 97°C.



DV2213100A_E

- Check if there is any foreign substance in the water temperature controller.
- Note) Clean the inside of the water temperature controller with an air gun.
- 5. Check if there are any foreign substance or damage part inside and outside of the hose.

6. Cooling system			

7. Lubrication system

General information	115
General information	115
Failure Diagnosis	
Oil pump	117
Oil pump disassembly	117
Oil pump assembly	117
Check of oil pump	117



General information

General information

This engine is the forced lubrication type of engine.

Oil pressure is generated and delivered by rotating the gear of the oil pump which is directly engaged with the crankshaftgear on the front of the cylinder block.


The oil pump delivers oil sucked from the oil pan with the suction pipe to the main path of the cylinder block through the oil cooler and oil filter. From the cylinder block, oil is delivered to the crankshaft bearings, camshaft bearings, and rocker arm for lubrication.

In addition, the turbocharger is connected to the engine lubrication circuit.

Around the cylinder block and the timing gear, lubricating oil is dispersed.

Each cylinder has an oil injection nozzle for cooling the bottom of the piston.

Engine oil is filtered through the oil filter and purified.



EDL08220187

7. Lubrication system


Failure Diagnosis

Phenomenon	Causes	Troubleshooting
	Bad oil	Replace oil with specified oil.
Too much oil consumption	Oil leakage from the oil seal ring and packing part	Replace it
	Worn or damaged piston and piston ring	Replace it
	Worn cylinder liner	Replace it
	Burnt piston ring	Replace it
	Worn valve guide oil seal, valve guide, or valve stem	Replace it
	Bad oil	Replace oil with specified oil.
Low oil pressure	Burnt oil pump relief valve	Replace it
	Clogged oil pump strainer	Cleanse the strainer
	Worn oil pump gear	Replace it
	Cracked oil delivery pipe of the oil pump	Replace it
	Defect oil pump	Repair or replace it
	Oil pressure gauge fault	Repair or replace it
	Worn bearings	Replace it
	Clogged oil filter	Replace the oil filter with a new one
Contaminated oil	Gas leakage	Replace piston ring with a new one
	Bad oil	Replace oil with specified oil.

Oil pump

Oil pump disassembly


1. Disassembly of oil pump drive gear



EQM4006I

- 1) Unscrew the screw and disassemble the oil relief valve.
- 2) Unfold the washer for the oil pump drive gear fixing nut and remove the nut.
- 3) Disassemble the drive gear.
- 2. Remove the oil pump cover fixing nuts and disassemble the oil pump cover.

Note) The oil pump cover is fixed with the two dowel pins.



EQM4007I

3. Disassemble the drive gear and driven gear.


Oil pump assembly

1. For reassembly, reverse the disassembly sequence.

Check of oil pump

 With steel rule and feeler gauge, measure the axial end play of the oil pump gear. Replace if the measured value is beyond the limit.






EQM40081

 With a feeler gauge, measure the amount of backlash between the oil pump drive gear and driven gear.
 Replace if the measured value is beyond the limit.

Backlash limit	0.50 ~ 0.64mm



EQM4009I

- 3. Measuring clearance between drive shaft and bushing
- Measure the outside diameters of the drive shaft and driven shaft, and replace if the measured values are less than the limit (Ø16.95mm)


Standard	Ø16.95 ~ Ø16.968mm
----------	--------------------

2) Measure the inside diameter of the pump body bushing to determine the clearance between the bushing and shaft, and compare the measured value with the standard value to determine whether to replace or not.

Clearance	0.032 ~ 0.077mm
-----------	-----------------

7. Lubrication system


General information	121
General information	121
High Sulfur content in diesel fuel	122
Water (Moisture) in diesel fuel	122
Failure Diagnosis	123
Fuel injection pump	124
General Information	124
Adjustment fuel injection pump	125
Fuel feed pump	140
General descriptions and construction	140
Fuel feed pump disassambly	142
Fuel feed pump assembly	142
Fuel feed pump inspection	142
Fuel feed pump testing	143



General information

General information

The fuel system consists of the fuel tank, injection pump, injection nozzle, fuel filter, andfuel lines such as pipes and hoses necessary to connect those components.



EDO8006I

↑ CAUTION

- The fuel lines should have a sufficient inner iameter.
- The fuel lines should be routed so that the fuel is not excessively heated by the heat radiation from the engine. The pipes should be laid as straight as possible without sharp bends.
- Make sure the pipes are protected against mechanical wear and well fastened to avoid vibrations.
- It is important that there are no fuel leakages or air infiltration neither on the suction or return line installation. Therefore securely fasten all the connections of fuel line.
- The return line back to the fuel tank must not be adjoin the suction line. In case of diesel fuel containing high water content due to insufficient fuel quality, maintenance difficulty or environmental adversity, an extra water separator with adequate capacity must be installed as user supply scope.

High Sulfur content in diesel fuel

Hyundai Doosan Infracore diesel engines can be operated with fuels Whose sulfur content is max. 0.05wt%.

Fuels with a sulfur content of > 0.05wt% are not Permitted as they result in increased corrosion and Hence greatly reduce the service life of the engines.

The oil and oil filter change intervals must be halved If the sulfur content is > 0.02wt%.

Water (Moisture) in diesel fuel

Water in the fuel causes;

- Incomplete combustion
- lammed or clogged nozzle
- · Damaged to the injection pump
- · Piston damage
- Destruction of engine

In case of diesel fuel containing high water content due to insufficient fuel quality, maintenance difficulty or environmental adversity, an extra water separator with adequate capacity must be installed as user supply scope.

Failure Diagnosis

Symptom	Causes	Troubleshooting
Engine does not start A. Fuel is not supplied from the fuel delivery pump	 Clogged fuel pipe, or air entered the fuel pipe line Defective delivery pump valve Seized delivery pump piston or push rod 	Correct Replace Disassemble / correct
B. Fuel is not injected from the fuel injection pump	 Clogged fuel filter cartridge Air entered to the fuel filter or injection pump Seizure or defect in the plunger or delivery valve 	Clean / replaceBleedDisassemble / correct
C. Improper fuel injection timing	 Defective installation of fuel injection pump bracket Defective adjustment of the fuel injection pump tappet Excessively worn cam of camshaft 	Inspect / correct Inspect / correct Replace
D. Fuel injection nozzle not working	 Seizure of needle valve of nozzle Fuel leakage between nozzle and needle valve Improper fuel injection pressure 	Service or replaceService or replaceAdjust
2. Engine starts but stops immediately	 Clogged fuel filter or clogged pipe between fuel delivery pump and injection pump Air entered into fuel Insufficient supply of oil by fuel delivery pump Clogged air breather in fuel tank, causing insufficient fuel supply. 	 Clean or replace Air bleeding Disassemble / correct Replace breather
3. Insufficient engine power	 Excessively work plunger Improper injection timing Defective delivery valve Excessive fuel leakage in injection nozzle Nozzle not working properly 	 Replace Adjust Replace Service or replace Disassemble / correct
4. Engine knocking occurs	Early injection timingHigh nozzle injection pressureNozzle not working properly	AdjustAdjustDisassemble / correct
5. Excessive engine smoke and knocking	 Defective injection timing Too low nozzle injection pressure Broken nozzle spring Nozzle not working properly Excessively work plunger Defective delivery valve seat Excessive fuel supply 	 Adjust Adjust Replace it Replace it Adjust Replace it Check feed pump
6. Unstable engine power	 Insufficient fuel supply Air entered into fuel Water entered into fuel Defective plunger operation Defective actuator operation Defective nozzle Injection start pressure different between cylinders Defective controller 	Check feed pump Air bleeding Replace fuel Disassemble / correct Disassemble / correct Disassemble / correct Adjust Adjust
7. Engine cannot reach the max. speed	Nozzle not working properlyDefective operation of actuator or controller	Disassemble / correct Adjust
8. Unstable engine idling	 Defective controller operation Defective plunger operation Defective magnetic pickup sensor 	Adjust Disassemble / correct Inspect or replace

Fuel injection pump

General Information

The fuel injection pump is driven by the crankshaft gear. It is connected to the forced lubrication system, so separate connection is not required.

The governor of electric fuel injection pump is consist of the actuator that is operated by the signal of the control system and the control system that maintain the engine RPM as the changing load.

Adjustment fuel injection pump

1. D1146

1) Injection pump: 65.11101 -7269A

Model: KP-PES6AD95B410RS2 (101061-8820 ZEXEL)
 Governor: KP-EP/RSV200-1350AQ49C311(105419-3930)

Plunger & barrel: 131153-1720Delivery valve: 131110-5120

• Feed pump: KP-FP/KE-ADS(105210-5280)

• Prestroke : 4.6 ±0.05 mm

2) Nozzle holder assembly: 65.10101-7050 (9134-153C LUCAS)

3) Nozzle: 65.10102-6026 (9135-143 LUCAS)

4) Injection pipe: 65.10301-6048
5) Injection order: 1 - 5 - 3 - 6 - 2 - 4
6) Injection timing: BTDC 18°

(A) Test condition for	Nozzle & Holder ass'y	105780-8140	Opening pressure: 175 kg/cm ²
injection pump	Injection pipe (ID, OD, L)	-	Ø2.0 X Ø6.0 - 600 mm
	Test oil	ISO4113	Temperature: 40 ±5 °C
		65.10102-6026	Nozzle (5 X Ø0.29)
(B) Engine standard parts	Nozzle & holder ass'y	65.10101-7050	Opening pressure: 214 kg/cm ²
	Injection pipe (ID, OD, L)	65.10301-6048	Ø2.0 x Ø6 - 650 mm

Rack diagram and setting valve at each point

	Check Rack		Pump speed	Injection Q`ty on F	Press	
	point	nosition	(rpm)	(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
	Α	-	900	-	93.5 ±2	-
Stand by	В	-	875	-	(103)	-
oower	С	-	100	-	(135)	-
	D	≈ 7.7	370	-	±2	-
	-	-	-	-	-	-

• Governor weight: 740 g

• Governor spring: k=10.0 kgf/mm

Idle spring: k=1.9 kgf/mmStart spring: k=0.01 kgf/mmFeed pump: 105210-5280

Lever ratio (min/max): 1:2


Plunger: Ø9.5 Left hand 20 + 45 lead

Delivery valve

Retraction pressure: 70 mm³/st, t-0.11
 Opening pressure: 23.1 kgf/cm²

- Spring: k=1.63 kgf/mm

Rack Diagram



EA9M4002

2. D1146T

1) Injection pump: 65.11101 -7271A

Model: KP-PES6AD95B410RS2 (101061-8820 ZEXEL)Governor: KP-EP/RSV200-1350AQ49C311(105419-3930)

Plunger & barrel : 131153-1720Delivery valve : 131110-5120

• Feed pump: KP-FP/KE-ADS(105210-5280)

• Prestroke : 4.6 ±0.05 mm

2) Nozzle holder assembly: 65.10101-7050 (9134-153C LUCAS)

3) Nozzle: 65.10102-6026 (9135-143 LUCAS)

4) Injection pipe: 65.10301-6048
5) Injection order: 1 - 5 -3 - 6 - 2 - 4
6) Injection timing: BTDC 18°

(A) Test condition for	Nozzle & Holder ass'y	105780-8140	Opening pressure: 175 kg/cm ²
injection pump	Injection pipe (ID, OD, L)	-	Ø2.0 X Ø6.0 - 600 mm
	Test oil	ISO4113	Temperature: 40 ±5 °C
		65.10102-6026	Nozzle (5 X Ø0.29)
(B) Engine standard parts	Nozzle & holder ass'y	65.10101-7050	Opening pressure: 214 kg/cm ²
	Injection pipe (ID, OD, L)	65.10301-6048	Ø2.0 x Ø6 - 650 mm

Rack diagram and setting valve at each point

	Check Rack		Pump speed	Injection Q`ty on F	Press	
	point posi	position (mm)	position (rpm)	(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
	Α	-	900	-	114.3 ±2	-
Stand by	В	-	875	-	(126)	-
power	С	14 or more	100	-	(140)	-
•	D	≈ 7.7	370	-	12.8 ±2	-
	-	-	-	-	-	-
Ē						l .

• Governor weight: 740 g

• Governor spring: k=10.0 kgf/mm

Idle spring: k=1.9 kgf/mmStart spring: k=0.01 kgf/mmFeed pump: 105210-5280

• Lever ratio (min/max): 1:2


Plunger: Ø9.5 Left hand 20 + 45 lead

Delivery valve

Retraction pressure: 70 mm³/st, t-0.11
 Opening pressure: 23.1 kgf/cm²

- Spring: k=1.63 kgf/mm

Rack Diagram



EA9M4002

3. P086TI

1) Injection pump: 65.11101-7309 (106674-4120 ZEXEL)Model: NP-PE6P120/700RS3S (106067-6010 ZEXEL)

Governor: Ghana electric control
Plunger & barrel: 134153 -2020
Delivery valve: 134110 - 1420

• Feed pump: NP-FP/KD-PS(105237-5470)

• Prestroke : 3.9 ±0.05 mm

2) Nozzle holder assembly: 65.10101-7055 (9135-293A LUCAS)

3) Nozzle: 65.10102-6049 (9135-291 LUCAS)4) Injection pipe: 65.10301-6049, 65.10301-6052

5) Injection order: 1 - 5 - 3 - 6 - 2 - 46) Injection timing: BTDC 12°

(A) Test condition for injec-	Nozzle & Holder ass'y	9135-293A	Opening pressure: 214 ±8 bar
tion pump	Injection pipe (ID, OD, L)	-	Ø2.2 X Ø6.35 - 650 mm
	Test oil	ISO4113 Temperature: 40 ±5	
	Nozzle & holder ass'y	65.10102-6049	Nozzle (5 X Ø0.34)
(B) Engine standard parts		65.10101-7055	Opening pressure: 214 kg/cm ²
	Injection pipe (ID, OD, L)	65.10301-6049 65.10301-6052	Ø2.0 x Ø6.35 - 650 mm

Rack diagram and setting valve at each point

	Check posi	Rack position (mm)	Injection Q`ty on F	Press		
			= =	(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
Ctond	Α	12.2	900	-	189 ±2	-
Stand by	-	-	-	-	-	-
power	-	-	-	-	-	-
	-	-	-	-	-	-
	-	-	-	-	-	-

• Governor weight: 26 g

· Governor spring: -

• Idle spring: -

· Start spring: -

Feed pump: 105210-5280Lever ratio (min/max): 1 : 2

• Plunger: Ø12 Left hand 30 lead

Delivery valve

- Retraction pressure: 100 mm³/st, t-0.09

- Opening pressure: 18.5 kgf/cm²

- Spring: k=0.87 kgf/mm

4. PU086

1) Fuel injection pump: 65.11101-7269A

Model type : PES6ADGovernor type : RSV

• Fuel feed pump: 105210-4830

• Cam lift: 11 mm

2) Rotating direction : Clockwise (Viewed at driving gear side)

3) Injection order: 1-5-3-6-2-44) Injection timing: BTDC 18° ±1°

(A) Test condition for injec-	Nozzle & Holder ass'y	105780-8140	Opening pressure: 175 kg/cm ²
tion pump	Injection pipe (ID, OD, L)	-	Ø2.0 X Ø8.0 - 600 mm
	Test oil	ISO4113	Temperature: 40 ±5 °C
		-	Nozzle (5 X Ø0.36)
(B) Engine standard parts	Nozzle & holder ass'y	65.10101-7050	Opening pressure: 214 + 8 kg/cm ²
	Injection pipe (ID, OD, L)	-	Ø2.2 x Ø6.0 - 650 mm

Rack diagram and setting valve at each point

	Check	Rack	Rack position (mm)	Injection Q`ty on F	Press	
	point	-		(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
	Α	10.5	1,100	88.5 ±2	±2.5	Full
Stand by	В	7.7	370	11.5 ±2	±25	Idle
power	С	*	100	(135)	-	-
	-	-	-	-	-	-
	-	-	-	-	-	-
				•	•	

Balance weight: 740 g

• Governor spring: k= 7.2 kg/mm

• Idle spring: k= 1.9 kg/mm

Idle sub spring: k= 3.0 kg/mm

• Start spring: k= 0.01 kg/mm

Max. discharge pressure: k= 3.4 kg/mm²

Lever ratio(min/max): 1: 1.2Plunger: Ø9.5, 20 + 45 lead

Delivery valve


- Retraction volume: 70 mm³/st, t=0.11

- Opening pressure: 23.1 kgf/cm²

- Spring: k=1.63 kgf/mm

• Feed pump: 105210-5280(KP-FP/KE-ADS)

Rack Diagram



EDM5001I

5. PU086T

1) Fuel injection pump: 65.11101-7271A

Model type : PES6ADGovernor type : RSV

• Fuel feed pump: 105210-4830

• Cam lift: 11 mm

2) Rotating direction : Clockwise (Viewed at driving gear side)

3) Injection order: 1-5-3-6-2-44) Injection timing: BTDC 12° ±1°

(A) Test condition for injection pump	Nozzle & Holder ass'y	105780-8140	Opening pressure: 175 kg/cm ²
	Injection pipe (ID, OD, L)	-	Ø2.0 X Ø8.0 - 600 mm
	Test oil	ISO4113	Temperature: 40 ±5 °C
		-	Nozzle (5 X Ø0.36)
(B) Engine standard parts	Nozzle & holder ass'y	65.10101-7050	Opening pressure: 214 + 8 kg/cm ²
	Injection pipe (ID, OD, L)	-	Ø2.2 x Ø6.0 - 650 mm

Rack diagram and setting valve at each point

	Check point	Rack position (mm)	Pump speed (rpm)	Injection Q`ty on F	Press	
				(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
	Α	10.5	1,100	113.5 ±2	±2.5	Full
Stand by power	В	7.7	370	11.5 ±2	±25	Idle
	С	*	100	-	-	-
-	-	-	-	-	-	-
	-	-	-	-	-	-
				•	•	

Balance weight: 740 g

• Governor spring: k= 7.2 kg/mm

• Idle spring: k= 1.9 kg/mm

Idle sub spring: k= 3.0 kg/mm

• Start spring: k= 0.01 kg/mm

Max. discharge pressure: k= 3.4 kg/mm²

Lever ratio(min/max): 1: 1.2Plunger: Ø9.5, 20 + 45 lead


Delivery valve

Retraction volume: 70mm³/st, t=0.11
 Opening pressure: 23.1kgf/cm²

- Spring: k=1.63 kgf/mm

• Feed pump: 105210-5280(KP-FP/KE-ADS)

Rack Diagram



EDM5003I

6. DP086LAF

1) Injection pump: 400912-00278

Model: 006PH609

• Governor : Electric governor

Plunger & barrel : -Delivery valve : -

Fuel feed pump : 006PH613Prestroke : 3.9 ±0.05 mm

2) Nozzle holder assembly: 65.10101-7055A

3) Nozzle: 65.10102-6049A

4) Injection pipe: 65.10301-6052B, 420208-00002

5) Injection order: 1 - 5 - 3 - 6 - 2 - 46) Injection timing: BTDC 14°

	Nozzle & Holder ass'y	-	Opening pressure:
(A) Test condition for injection pump	Injection pipe (ID, OD, L)	-	-
	Test oil	-	Temperature: -
		65.10102-6049A	Nozzle (5 x Ø0.34)
(B) Engine standard parts	Nozzle & holder ass'y	65.10101-7055A	Opening pressure: 214 kg/cm ²
	Injection pipe (ID, OD, L)	65.10301-6052B, 420208-00002	Ø2.2 x Ø6.5 x 650 mm

Rack diagram and setting valve at each point

	Check point	Rack position (mm)	Pump speed (rpm)	Injection Q`ty on F	Press	
				(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
Stand	-	-	-	-	-	-
by power	-	-	-	-	-	-
	-	-	-	-	-	-
	-	-	-	-	-	-
•						•

- · Governor weight: -
- · Governor spring: -
- Idle spring: -
- Start spring: -
- Feed pump: 006PH613
- Lever ratio (min/max): -
- Plunger: Ø12 Left hand 30 lead
- Delivery valve
 - Retraction pressure: 105 mm³/st, t=0.1 mm
 - Opening pressure: -
 - Spring: k=1.2 kgf/mm

7. DP086TAF

1) Injection pump: 400912-00282

• Model: 006PH612

• Governor : Electric governor

Plunger & barrel : -Delivery valve : -

Fuel feed pump: 006PH613Prestroke: 3.9 ±0.05 mm

2) Nozzle holder assembly: 65.10101-7080A

3) Nozzle: 65.10102-6040A

4) Injection pipe: 65.10301-6052B, 420208-00002

5) Injection order: 1 - 5 - 3 - 6 - 2 - 46) Injection timing: BTDC 19°

	Nozzle & Holder ass'y	-	Opening pressure:
(A) Test condition for injection pump	Injection pipe (ID, OD, L)	-	-
	Test oil	-	Temperature: -
(B) Engine standard parts		65.10102-6049A	Nozzle (5 x Ø0.3)
	Nozzle & holder ass'y	65.10101-7055A	Opening pressure: 214 kg/cm ²
	Injection pipe (ID, OD, L)	65.10301-6052B, 420208-00002	Ø2.2 x Ø6.5 x 650 mm

Rack diagram and setting valve at each point

	Check	Rack position (mm)	Pump speed	Injection Q`ty on F	Press	
	point		(rpm)	(A) Test condition for injection pump	(B) Engine standard parts	(mmHg)
Stand	-	-	-	-	-	-
by power	-	-	-	-	-	-
	-	-	-	-	-	-
	-	-	-	-	-	-
		•				•

- · Governor weight: -
- · Governor spring: -
- Idle spring: -
- Start spring: -
- Feed pump: 006PH613
- Lever ratio (min/max): -
- Plunger: Ø12 Left hand 30 lead
- Delivery valve
 - Retraction pressure: 105 mm³/st, t=0.1 mm
 - Opening pressure: -
 - Spring: k=1.2 kgf/mm

8. PU086TI (EBPPA)

1) Parts of pump

Pump speed limit: 1,400 rpmPump housing: 05B131-00

- Cradle

- Pressure-feed lubrication

• Cam sequence/rotate direction (Viewed from driving end): 1 - 5 - 3 - 6 - 2 - 4/Clockwise

• Tolerance of injection angle: ± 30° (Relate No.1 cylinder)

Prestroke : H=4.5 ±0.05 mm
 Camshaft : 05B168-0201-1YM

- Cam lift: 12 mm - Diameter: Ø30 mm

• Plunger and barrel ass'y: 05U1001-00

- Ø12 mm

- Right, 30LEAD

• Delivery-valve: 05F232-00

- D/V retraction VR=105 mm³ (Ø8 x 2.1 mm) t=0.1 mm

• Delivery-valve spring: 1.2 kgf/mm

• Holder delivery valve with damping valve : Orifice Dia. Ø0.65 mm

2) Parts of governorGovernor : RSVLever ratio : 1 : 1.2Flyweight : 610 g

Governor spring: k=7.2 kg/mm
Idle spring: k=1.9 kg/mm
Idle sub spring: k=1.03 kg/mm
Start spring: k=0.009 kg/mm
Boo. com spring: k=1.02 kg/mm


3) Feed pump

Order No.: 05LS2035A
 Pressure: P=1.5 kgf/cm²
 Piston spring: k=1.15 kgf/mm

4) Bench test data

	Inspection tolerances						
Attribute	Speed	L.D.A pressure	Fueling	Fueling tolerance	Max SP. CYL/CYL	Rack travel	
	r/min	kPa	mm ³ /st	mm ³ /st	mm ³ /st	mm	
Rated	1,100	140	140	±4.5 €	9	11.2 ±0.1	
Torque peak	800	140	153	±8	15	11.2 ±0.1	
Governor break	1,135 ±10	140				11.1 ±0.2	
High idle	1,225 ±10	140	21	±4		(4.5)	
Boost control	500	0	102	±6	10	9.1 ±0.3	
Start fuel	100	0	190 🔾	±10			
Low idle	375	0	10 🔾	±2 〇	3.4	(4.5)	

Rack Diagram



EDL08220188

9. PU086TI (EBPPB)

1) Parts of pump

Pump speed limit: 1,400 rpmPump housing: 05B131-00

- Cradle

- Pressure-feed lubrication

• Cam sequence/rotate direction (Viewed from driving end): 1 - 5 - 3 - 6 - 2 - 4/Clockwise

• Tolerance of injection angle: ± 30° (Relate No.1 cylinder)

Prestroke : H=4.5 ±0.05 mm
 Camshaft : 05B168-0201-1YM

- Cam lift: 12 mm - Diameter: Ø30 mm

• Plunger and barrel ass'y: 05U1001-00

- Ø12 mm

- Right, 30LEAD

• Delivery-valve: 05F232-00

- D/V retraction VR=105 mm³ (Ø8 x 2.1 mm) t=0.1 mm

• Delivery-valve spring: 1.2 kgf/mm

• Holder delivery valve with damping valve : Orifice Dia. Ø0.65 mm

2) Parts of governorGovernor : RSVLever ratio : 1 : 1.2Flyweight : 610 g

Governor spring: k=7.2 kg/mm
Idle spring: k=1.9 kg/mm
Idle sub spring: k=1.03 kg/mm
Start spring: k=0.009 kg/mm
Boo. com spring: k=1.02 kg/mm


3) Feed pump

Order No.: 05LS2035A
 Pressure: P=1.5 kgf/cm²
 Piston spring: k=1.15 kgf/mm

4) Bench test data

	Inspection tolerances						
Attribute	Speed	L.D.A pressure	Fueling	Fueling tolerance	Max SP. CYL/CYL	Rack travel	
	r/min	kPa	mm ³ /st	mm ³ /st	mm ³ /st	mm	
Rated	1,225	140	143	±4.5 €	9	11.5 ±0.1	
Torque peak	750	140	157	±8	15	11.5 ±0.1	
Governor break	1,250 ±10	140				11.4 ±0.2	
High idle	1,350 ±10	140	25	±4		(5.0)	
Boost control	500	0	113	±6	11	9.6 ±0.3	
Start fuel	100	0	190 🔾	±10			
Low idle	375	0	15 🔾	±3 🔾	5.2	(5.0)	

Rack Diagram




EDL08220189

8. Fuel system

Fuel feed pump

General descriptions and construction




EQM4019I

The P-type injection pump is mounted with K-ADS or KP type feed pump. These pumps have the same basic construction and operation, and the general descriptions of the KP type pump are given below.

The figures show its construction (above figure) and operation (following figure). The piston in the fuel feed pump is driven by the push rod and tappet via the camshaft of injection pump and performs reciprocating operation to control the suction and delivery of fuel. When the cam reaches the Bottom Dead Center as shown in the figure, the fuel is drawn in through the check valve on the inlet side.


The fuel pressurized as the cam rotates on flows through the check valve on the outlet side as shown in (B). If the feeding pressure increases abnormally, the spring is compressed, resulting in interrupting further delivery of fuel as shown in (C).



EQM4020I


This feed pump is mounted with a priming pump designed to permit manual feeding of fuel from the fuel tank with the injection pump mounted in the engine. During the manual feeding operation, air must be bled from the fuel lines. When using the priming pump, fix it securely to prevent the possible entry of moisture or other foreign substances in the inside of feed pump.

In addition, a strainer is fitted into joint bolt on the inlet side of the fuel feed pump to filtrate any foreign substances possibly mixed in fuel.



EB1M4003

Fuel feed pump disassambly



EQM4021S

- 1. Clamp the feed pump with a vise and disassemble the plugs (30, 32), strainer (31) and gaskets (35, 36).
- 2. Take off the priming pump (25), plug (16), both gaskets (18), spring (15), and check valve (14).
- 3. Take off the prig (7), gasket (8), spring (6), and piston (5) on the piston side.
- 4. Pull out the snap ring (20) holding the tappet (10).
- 5. Disassemble the snap ring, then take off the tappet (10) and push rod (1).

Fuel feed pump assembly

Reassembly operation is performed in reverse order of disassembly. All the gaskets must be replaced with new ones at reassembly.


Fuel feed pump inspection

- 1. If the check valve is damaged or scored on its seat face, replace it with a new one.
- 2. Inspect the piston and tappet for damage.
- 3. Replace the push rod if excessively worn, and replace together with the pump housing if required.

4. The inspection for wear should be performed in the same procedure as for suction pressure test described below.


Fuel feed pump testing

1. Suction capacity test



EQM4022I


- 1) Connect one end of a hose to the inlet side of the feed pump and immerse the other end of it into the fuel tank as illustrated.
- 2) Hold the feed pump in position about 1m above the level of fuel in the fuel tank.
- 3) Operate the tappet at the rate of 100rpm and check to see if fuel is drawn in and delivered for 40seconds or so.
- 2. Delivery test



EAMC016I

- 1) Make a test with the feed pump mounted on a pump tester as illustrated.
- 2) Operate the pump at the rate of 1,000rpm and check to see if the pump delivery is more than 405 cc/15 seconds.

3. Sealing test



EQM4023I

- 1) Plug up the delivery port on the feed pump and apply compressed air of 2 kg/cm² into the inlet side.
- 2) Submerge the feed pump in a container of diesel fuel and check for air leak.

. Fuel system	

General information	147
General Information	147
Turbocharger	148
Construction	
Function	149
Failure Diagnosis	150
How to Maintain Turbocharger	154
Special inspection of turbocharger	155




General information

General Information

The exhaust gas of the engine passes through the turbine wing of turbocharger to rotate the rutbine. At the same time, the impeller air of the compressor mounted on the other end of same shaft rotates to suck in the fresh air through air filter, and delivers it to the cylinder through inter cooler with high pressure.

The turbocharger is air-cooled. The bearing is lubricated by the lubricant supplied from the engine lubrication system. The engine power depends on the supplied fuel amount and engine efficiency. In order to make the supplied fuel burned completely to work for the engine efficiently, the sufficient air should be delivered to the cylinder. That is, the enfine power is virtually determined by the size of cylinder. If compressed air is delivered to the cylinder with a given capacity, the air amount in the cylinder increases to burn more fuel, thereby increasing the engine power.

The method of compressing the air to supply it into the engine cylinder is called supercharging; and the method of using the exhaust gas discharged from the combustion chamger for the same purpose is called turbocharging.




DV2213107A

No.	Name	No.	Name
1.	Compressor casing	A.	Air inlet
2.	Turbine casing	B.	Exhaust gas outlet
3.	Compressor wheel	C.	Exhaust gas inlet
4.	Impeller	D.	Engine oil delivery
5.	Turbine	E.	Engine oil recovery

Turbocharger

Construction



DV2213108A

No.	Name	No.	Name	No.	Name
1.	Turbine shaft	10.	Bolt	21.	Heat screen
2.	Thrust bush	11.	Clamp	22.	Compressor housing
3.	Oil shut off	13.	Bearing housing	23.	Clamp
4.	Fixing nut	14.	Retainer ring	24.	Bolt
5.	Seal ring	15.	Seal plate	27.	Liquid gasket
6.	Seal ring	16.	Thrust bearing	30.	Loctite
7.	Seal ring	17.	Journal bearing	31.	Liquid anti-burn angents
8.	Compressor wing wheel	18.	Screw		
9.	Turbine housing	19.	Screw		

Function

1. Turbine


The exhaust gas that is discharged from combustion chamger passes through turbine housing conveying an energy to turbine wings to give the rotating power, This is called as the turbine and in order not to influence a bad effect at bearing part, there are the seal ring and heat dissipator.

2. Compressor


It is connected to the same shaft with the turbine to make a revolving assembly, and receive the revolving force of turbine, and sends air to the suction manifold by suctioning and compressing it. This is called as the compressor.

3. Bearing

- 1) Thrust bearing force is applied to the turbine wheel and an arrangement is made for the shaft not to shift.
- 2) journal bearing (floating bearing) is adopted and it forms the double oil films at the in out surfaces in comparison to the general stationary type so that the bearing may be able to rotate independently and consequently the double layers of films act as the damper to make the slipping speed on the bearing surface less than the rotaing speed of shaft so that the dynamic stability may be obtained.
- Sealing at compressor shaft
 Inorder for the compressed intake air and lubricating oil not to leak, a seal plate and a seal ring are made to the double structures.



DV2213109A_E



DV2213110A_E

Failure Diagnosis

Phenomenon	Causes	Troubleshooting
	Rotating part is contacted	Repair or replace it
	Unbalanced rotation of a rotor	Repair or replace it
	Burn	Repair or replace it
	Loose joint	Check or repair it
	Deformed or damaged intake systemhose	Replace it
	Poor clamping state	Adjust and tighten the clamp
	Contaminated or damaged air filter	Replace and check if the impeller of the turbo- charger is damaged
	Leakage of coolant from the turbocharger or oil from the oil hose	Replace the hose and the gasket
	Leakage of gas from the exhaust manifold	Replace the gasket or tighten the fixing nut
Noise or vibration	Poor turbo actuator operation	Replace the turbocharger
	Leakage from the engine block and the exhaust manifold	Check the engine
	Contaminated blowby gas and abnormal oil amount	Check the turbo impeller and the turbo intake outlet
	Large gap of the turbocharger wheel, causing interference with the wall	Check if there is any sand or metallic foreign substance
	Damaged turbocharger wheel	Check if there is any sand or metallic foreign substance
	Damaged wheel and shaft of the turbocharger	Check if there is any sand or metallic foreign substance
	Poor rotating force of the turbocharger wheel	Check if there is any sand or metallic foreign substance

Phenomenon	Causes	Troubleshooting
	Leakage of gas from each part of the exhaust system	Check or repair it
	Clogged air filter element	Replace or clean it
	Contaminated or damaged turbocharger	Repair or replace it
	Leakage of air from the discharging part of the compressor shaft	Check or repair it
	Deformed or damaged intake system hose	Replace it
	Poor clamping state	Adjust and tighten the clamp
	Contaminated or damaged air filter	Replace and check if the impeller of the turbo- charger is damaged
	Poor turbo actuator operation	Replace the turbocharger
Lowered output	Leakage from the engine block and the exhaust manifold	Check the engine
	Contaminated blowby gas and abnormal oil amount	Check the turbo impeller and the turbo intake outlet
	Large gap of the turbocharger wheel, causing interference with the wall	Check if there is any sand or metallic foreign substance
	Damaged turbocharger wheel	Check if there is any sand or metallic foreign substance
	Damaged wheel and shaft of the turbocharger	Check if there is any sand or metallic foreign substance
	Poor rotating force of the turbocharger wheel	Check if there is any sand or metallic foreign substance
	Deformed or damaged intake system hose	Replace it
	Poor clamping state	Adjust and tighten the clamp
Oil leakage	Contaminated or damaged air filter	Replace and check if the impeller of the turbo- charger is damaged
	Leakage of coolant from the turbocharger or oil from the oil hose	Replace the hose and the gasket
	Poor turbo actuator operation	Replace the turbocharger

Phenomenon	Causes	Troubleshooting
	Leakage from the engine block and the exhaust manifold	Check the engine
	Contaminated blowby gas and abnormal oil amount	Check the turbo impeller and the turbo intake outlet
Oil la akaga	Large gap of the turbocharger wheel, causing interference with the wall	Check if there is any sand or metallic foreign substance
Oil leakage	Damaged turbocharger wheel	Check if there is any sand or metallic foreign substance
	Damaged wheel and shaft of the turbocharger	Check if there is any sand or metallic foreign substance
	Poor rotating force of the turbocharger wheel	Check if there is any sand or metallic foreign substance
	Poor clamping state	Adjust and tighten the clamp
	Leakage of coolant from the turbocharger or oil from the oil hose	Replace the hose and the gasket
	Leakage from the engine block and the exhaust manifold	Check the engine
	Contaminated blowby gas and abnormal oil amount	Check the turbo impeller and the turbo intake outlet
Oil consumption	Large gap of the turbocharger wheel, causing interference with the wall	Check if there is any sand or metallic foreign substance
	Damaged turbocharger wheel	Check if there is any sand or metallic foreign substance
	Damaged wheel and shaft of the turbocharger	Check if there is any sand or metallic foreign substance
	Poor rotating force of the turbocharger wheel	Check if there is any sand or metallic foreign substance

Phenomenon	Causes	Troubleshooting
	Deformed or damaged intake system hose	Replace it
	Contaminated or damaged air filter	Replace and check if the impeller of the turbo- charger is damaged
	Leakage of coolant from the turbocharger or oil from the oil hose	Replace the hose and the gasket
	Poor turbo actuator operation	Replace the turbocharger
Black and white	Contaminated blowby gas and abnormal oil amount	Check the turbo impeller and the turbo intake outlet
emissions	Large gap of the turbocharger wheel, causing interference with the wall	Check if there is any sand or metallic foreign substance
	Damaged turbocharger wheel	Check if there is any sand or metallic foreign substance
	Damaged wheel and shaft of the turbocharger	Check if there is any sand or metallic foreign substance
	Poor rotating force of the turbocharger wheel	Check if there is any sand or metallic foreign substance
Blue emissions	Leakage from the engine block and the exhaust manifold	Check the engine
Too much fog	Oil leakage to the turbine or compressor	Repair or replace it
100 much log	Worn or damaged seal ring due to worn bearing	Repair or replace it
	Clogged air filter element	Replace or clean it
	Clogged air duct	Check or repair it
T	Air leakage from the intake system	Check or repair it
Too much exhaust emissions	The turbocharger cannot rotate because of burning	Repair or replace it
	A turbine blade or compression wing contacts with the other one or is damaged	Repair or replace it
	Deformed or clogged exhaust system pipe	Check or repair it


How to Maintain Turbocharger

- 1. Cautions for engine operation
- 1) Observe the followings when starting, operating, and stopping an engine.


Item	Cautions	Reasons
	1) Check the oil amount	
	2) Therefore, start the engine with the starter motor to check the rise of oil pressure (until the gradation of the oil pressure gauge moves or the pressure indicator lamp is turned on).	2) Overhasty start of engine leads to engine rotation without lubricating turbocharger and other engine parts, causing abnormal wear or burning of bearings.
Starting an engine	3) If you replace oil, oil filter cartridge, or lubrication system parts or use an engine in cold areas, or the engine has stopped for a long period, loosen the oil pipe joint at the inlet of the turbocharger and run the starter motor until oil flows out. After completing the work, tighten the oil pipe joint again and start the engine.	3) When an engine has stopped or kept cold for a long period, circulation of oil in the pipe gets poor.
After starting an engine	Operate the engine at idle for five minutes from starting it.	1) When the engine is suddenly loaded while the engine and the turbocharger have not been smoothly rotated after starting the engine, parts with insufficient oil may be burnt.
	2) Check if oil, gas, or air is leaked from each part. If so, take proper action.	2) Leakage of oil, gas, or air (especially oil) reduces oil pressure and loss of oil cause burning of bearings.
	check the following.	
During Operation	1) Oil pressure At idle: 1.5 ~ 3.0 kg/cm ² Fully loaded: 3.0 ~ 5.5 kg/cm ²	Too low oil pressure causes abnormal wearing or burning of bearings. Too high oil pressure causes oil leakage.
	2) When abnormal noise or vibration occurs, slowly reduce the rotate count until the engine stops and then figure out the causes.	2) Operating an engine with noise or vibration may cause irreversible damage of the engine.
Stopping an Engine	Operate the engine at idle for five minutes before stopping it.	1) Sudden engine stop after operating the engine under high load allows the heat from the red-heated turbine blade to be delivered to the bearing system. Then oil burns and the bearing metal and rotation shaft are burnt.

Special inspection of turbocharger

You should check the radial and axial clearance of a rotor. This preventive action is to find the bearing wear status of the axial clearance so as to prevent the severe damage to the rotor and bearing.




DV2213034A




DV2213035A

- 1. Guide for checking the rotor for rotating condition The inspection of the rotor assembly for rotating condition should be performed by the degree of unusual sound. If a sound detecting bar is used, install its tip on the turbocharger housing and increase the engine revolutions slowly. If a high-pitch sound is heard continuously, it means that the rotor assembly is not normal. In this case, as the metal bearing and rotor are likely to be in abnormal conditions, the turbocharger should be replaced or repaired.
- Guide for checking rotor end play
 Disassemble the turbocharger from the engine, then check the rotor axial play and radial play.
 When disassembling the turbocharger, be sure to plug the oil inlet and outlet ports with taps, etc.
- 1) Rotor axial play






DV2213036A




EA8M4003

2) Rotor radial play

Limit of wear	0.12 mm



DV2213038A



EA8M4004

3) If the measured axial and radial plays are beyond the limit of wear, replace or repair the turbocharger.

10. Cylinder block/head

General information	159
General Information	159
Cylinder block	160
Check of Cylinder Block	160
Measurement of Cylinder Liner	160
Cylinder head	161
Disassembly of cylinder head	161
Assembly of cylinder head	161
Check of cylinder head	161
Valve	163
General Information	163
Check of Valve	163
Check of Valve Guide	163
Valve seat	163
Valve Spring	164
Rocker arm	166
Disassembly rocker arm	166
Assembly rocker arm	166
Check of rocker arm	166
Check of rocker arm shaft	166
Tappet and push rod	168
Tappet clearance	168
Visual inspection of tappet	168
Outside diameter of tappet	
Warpage of Push Rod	168
Camshaft	169
Camshaft end play	169
Check of camshaft	169
Check of cam	169



General information

General Information

The cylinder block is a single piece of alloy cast iron. To increase its stiffness, it is extended to a level below the crankshaft center line. The engine has replaceable wet cylinder liners and individual cylinder heads with strung-in valve seat rings and replaceable valve guides.


Cylinder block

Check of Cylinder Block

- Cleanse the cylinder block and check if there is any cracked or damaged part with naked eye.
- Replace the cylinder block if it is seriously cracked or damaged. Repair tiny cracks if existing.
- 3. Check if the oil path or coolant path is clogged or corroded.
- 4. Perform the hydrostatic test to check whether there is a crank or an air leakage.
- 5. Block the discharging outlets of the cooling water path and the oil path of the cylinder block and put pressure of 4 kg/cm² on the inlet. Then sink the cylinder block in the 70 °C water for 1 minute and check if air leaks.

Measurement of Cylinder Liner

 Assembly the cylinder liner at the cylinder block and measure inner diameter at upper, middle, lower that is, 3 step by 45° interval.



DV2213111A

- 2. Calculate the average values after eliminating the maximum and minimum values.
- 3. If the measured values are very close to the limit value or beyond, replace it.

Standard	Limit
Ø111.000 ~ Ø111.022mm	Ø111.122mm

Cylinder head


Disassembly of cylinder head

1. Disassemble the cylinder assembly, and put it on the shelf for assembly or clean lathe.

ACAUTION


Prevent any damage to gasket's contact surface of the cylinder head.

2. Disassemble the cotter pin, spring, spring seat pushing valve spring by a special tool.



EA0M4007

- 3. Pull out the intake and exhaust valves.
- 4. The disassembled parts are kept laid in turn.
- 5. Disassemble the valve stem seal.
- 6. By means of the special tool, punch, pull out a valve guide.



Assembly of cylinder head

- 1. Clean the cylinder head thoroughly.
- Replace the valve stem seal with new one, and by means of a special tool, press the stem seal into the valve guide of cylinder head.
- Coat engine oil to valve stem and valve guide and assemble the valve. However, be careful for the damage of valve stem seal.
- 4. Install the lower seat of valve spring to the valve guide of cylinder head.
- 5. After putting inner, outer springs, install the spring upper seat on it.
- 6. Assemble the valve by inserting the valve cotter pressing the valve spring with a special tool.
- After installing the valve, check whether the valve is correctly installed or not tapping it lightly with urethane hammer.


Check of cylinder head

- 1. Check for the cylinder head
- 1) Remove carbon from the cylinder head lower surface.
- 2) Check any crack or damage that can not found by naked eyes through the hydraulic or magnetic particle test.

ACAUTION


Be careful to magnetic particle test.

2. Distortion of lower surface



DV2213115A

10. Cylinder block/head



DV2213116A

- As shown in figure, measure the cylinder head's distortion at 6 directions with horizontal ruler and clearance gauge.
- 2) If the measured value is beyond the limit value, correct it by means of the fine grinding paper or grinding machine.
- If it is beyond the max. allowable value, replace the cylinder head.

	Standard	Limit
Warp	0.2 mm or less	0.3mm
Thickness : t (reference)	109.9 ~ 110.1mm	108.4mm

- 3. Flatness
- Check the flatness of the installing surface of cylinder head's intake and exhaust manifolds with horizontal ruler and clearance gauge.

Standard	Limit
0.05mm	0.2mm

- 4. The hydraulic test
- 1) The hydraulic test of cylinder head is same as the cylinder block test.

Valve

General Information


The overhead valves are actuated via chilled cast iron tapets, push rods and rocker arms from the camshaft.

Check of Valve

After cleaning the valves with clean diesel oil, measure the valve as follow.

- 1. Valve stem outer diameter
- Measure the valve stem's outside diameter at upper, middle, and lower to determine the wears and when the wear limit is more than limit, replace the valves.

Item	Standard	Limit
ln.	Ø8.950 ~ Ø8.970 mm	Ø8.92 mm
Ex.	Ø8.935 ~ Ø8.955 mm	Ø8.895 mm




DV2213117A_E

- 2. Valve seat contacting faces
- inspect the scratch and wear of valve stem seal contacting face, and if necessary correct with the grinding paper but if severe replace it.
- 3. Valve head thickness
- 1) if valve head thickness becomes less than limit, replace the valve.

Item	Standard	Limit
ln.	2.7 mm	0.5 mm or less
Ex.	2.2 mm	0.5 mm or less

↑ CAUTION

If the damage is severe, replace new one.




DV2213118A

Check of Valve Guide

 Inser the valve into valve guide and measure the clearance between valve and valve guide by the shaking degree of valve. If the clearance is bigger, measure the valve and then replace the more worn valve guide.

Item	Standard	Limit
In.	0.04 ~ 0.07 mm	0.1 mm
Ex.	0.06 ~ 0.09 mm	0.15 mm



DV2213119A_E


If the valve guide has already been replaced, measure the center with valve seat if it deviates or not and if abnormal it must be corrected.

Valve seat

- 1. Contacting face amount
- As for the valve seat's wear, measure the width of the contact surface with intake valve seat and exhaust valve seat. If beyond the limit value, replace the valve seat.

10. Cylinder block/head


- 2. Valve depression
- Assemble the valve at the valve seat of the cylinder head, and check the amount of depression of the valve from the lower portion of the cylinder head using a dial gauge.



EDM2032P


2) If the amount of depression is beyond the specified limit, replace the valve seat.

	Standard	Limit
Intake & Exhaust	0~0.3mm	0.55mm



EA0M4046

3. Valve seat disassembly




EA3M2032


- For the disassembling of valve seat, by welding the welding bead to a valve seat rotating tool or valve seat, pull it out with a special tool.
- 4. Valve seat assembly
- For the assembling of a new valve seat, by putting it among the dry ices of an ice box previously for about 2 hours for the cold shrinkage, and press it in the cylinder head by a special tool. (bench press)
- Apply valve lapping compound to the valve head seating face on the valve seat and lap the valve seat by turning it until it is seated in position, then wipe out the lapping compound.

Valve Spring

- 1. Visual check
- 1) Check the appearance of valve spring and if necessary replace the spring.
- 2. Valve spring free length
- 1) Use a vernier caliper to measure the valve spring free length.
- 2) If the measured value is less than the specified limit, the valve spring must be replaced.

Spring free Length		Standard
Intake valve		64 mm
Exhaust valve	Inner	60 mm
Extraust valve	Outer	71 mm






DV2213125A_E

- 3. Valve spring inclination
- 1) Use a surface plate and a square to measure the valve spring inclination.
- 2) If the measured value exceeds the specified limit, the valve spring must be replaced.

	Standard	Limit
Valve Spring Inclination	less than 1.8 mm	2.7 mm



DV2213124A_E


- 4. Valve spring tension
- 1) Use a spring tester to measure the valve spring tension.
- 2) If the measured value is less than the specified limit, the valve spring must be replaced.

	Set Length		Spring force	Limit
Intake valve	Valve sprin at 41mm se	•	70kg	±3%
Exhaust	Inner	38mm	28.6kg	±6%
valve	Outer	41mm	66kg	±5%

Rocker arm

Disassembly rocker arm

- 1. Disassemble the snap rings that are located at both ends of rocker arm shaft by a plier.
- 2. Disassemble in the order of washer, rocker arm bracket, rocker arm spring, rocker arm.



EA8M3008

Assembly rocker arm

1. Reassembling can be done in the reverse order of disassembling and following things should be heeded.


♠ CAUTION

- Check the oil supply hole of rocker arm shaft for any clog and clean thoroughly.
- Be careful not to occur any swap of position and reverse assembly.

Check of rocker arm

- 1. Visual check
- 1) Visually check the face of the rocker arm in contact with the valve stem end for scores and step wear.
- 2) If the wear is small, correct it with an oil stone or grinding paper of fine grain size. Rocker arm with a considerable amount of step wear should be replaced.
- 2. Rocker arm bushing diameter
- 1) Measure the inside diameter of the rocker arm bushing with an inside micrometer or vernier calipers, and compare the measured values with the rocker arm shaft diameter.
- 2) If the clearance exceeds the limit, replace either bushing or shaft, whichever worn more.

Standard	Limit
0.040~0.113 mm	0.226 mm or less




EA0M4059

Check of rocker arm shaft

- 1. Rocker arm shaft run-out
- 1) Place the rocker arm shaft on two V blocks and inspect the shaft for bend using a dial gauge.
- 2) If the amount of this run-out is small, press the shaft with a bench press to correct the run-out Replace the shaft if the measured value exceeds the limit.


Limit	0.2 mm
-------	--------



EDM2037I

- 2. Rocker arm shaft diameter
- 1) With an outside micrometer, measure the rocker arm shaft diameter at the point where the rocker arms have been installed. Replace the rocker arm if the amount of wear is beyond the specified limit.

Standard	Limit
Ø23.978 ~ Ø23.959 mm	Ø23.90 mm



EA9M3014

Tappet and push rod


Tappet clearance

Measure the clearance of the tappet and tappet holes of the cylinder block. If the value is beyond the specified limit, replace tappets.

Standard	Limit	
0.035mm ~ 0.077mm	0.15mm	

Visual inspection of tappet

Inspection if the tappet surface which contacts the camshaft has damage like crack or scratch. If the damage is small, correct it with oil stone or fine grinding paper, if excessive, replace it.




DV2213128A E

Outside diameter of tappet

With an outside micrometer, measure the tappet outside diameter If the measured value is beyond the limit, replace tappets.


Standard	Ø19.944 ~ Ø19.965mm
----------	---------------------




EDM2061I

Warpage of Push Rod

Put the push rod on a surface plate, and measure the warpage with a feeler gauge shile spinning it. If the reading exceeds the tolerance limit, replace it.






DV2213129A E

Camshaft

Camshaft end play

- 1. Push the thrust plate toward the cam gear.
- 2. With a feeler gauge, measure the clearance between the thrust plate and camshaft journal.




EA0M4067

3. If the end play is excessive, replace the thrust plate.

Standard	Limit	
0.28 ~ 0.43mm	0.6 mm	

Check of camshaft

1. Clearance between camshaft journal and camshaft bush




EA0M4063

- With an outside micrometer, measure the camshaft journal diameter.
- 2) Measure the inside diameter of the camshaft bushing on the cylinder block using a cylinder bore indicator, and compare the measured value with the camshaft outside diameter to determine the clearance.
- 3) Replace the bushing if the measured value is beyond the specified limit.

Standard	Limit
0.060~0.115 mm	0.230 mm

2. Run-out




DV2213136A

 Support the camshaft on two V blocks and check for run-out using a dial indicator. Correct or replace the cam shaft if the amount of run-out is beyond the value indicating need for servicing.

Standard	Limit
0.05 mm	0.5 mm

Check of cam

1. Cam lobe height



DV2213132A

- Use a micrometer to measure the cam lobe height and journal diameter.
- 2) If the measured number is less than the specified limit, the camshaft must replaced.

10. Cylinder block/head

		Standard	Limit
Cam lobe	Intake	49.15 mm	48.85 mm
height (C)	Exhaust	49.32 mm	49.00 mm
Cam journal ter (A,B)	l diame-	Ø57.86 ~ Ø57.88 mm	Ø57.52 mm

- 2. Cam surface
- Inspect the cam face for scratch or damage. Slight step wear or damage on the cam face may be corrected with oil stone or oiled grinding paper. But, replace if severely damaged.


11. Electric system

Electronic wiring diagram 173 Starter 174 General Information 174 Views 174 Wiring diagram 176 Alternator 178 General Information 178 Views 178 Wiring diagram 179 Air Heater 180	General information	173
General Information 174 Views 174 Wiring diagram 176 Alternator 178 General Information 178 Views 178 Wiring diagram 179	Electronic wiring diagram	173
Views 174 Wiring diagram 176 Alternator 178 General Information 178 Views 178 Wiring diagram 179	Starter	174
Wiring diagram	General Information	174
Alternator	Views	174
General Information	Wiring diagram	176
Views 178 Wiring diagram 179	Alternator	178
Wiring diagram	General Information	178
	Views	178
Air Heater	Wiring diagram	179
	Air Heater	180



General information

Electronic wiring diagram



EA9O2008

11. Electric system

Starter

General Information


The starter is attached to the back of the flywheel housing. When disassembling the engine, immerse the pinion gear and ring gear of the starter in fuel, brush them, and then apply greases to them in order to prevent rust.

ACAUTION

- Starter should be protected from humidity all the time.
- Before working on the electric system, be sure to disconnect the ground wire("-" minus wire) of the battery. Short circuit may occur while working on the electrical system. Connect the ground wire last after completing all of work.


Views

• D1146/D1146T/PU086/PU086T




EA902009

P086TI



EA8O3008

PU086TI




EDL08220190

11. Electric system


Wiring diagram

• D1146/D1146T/PU086/PU086T




EDE08220005

P086TI



EDE08220006

PU086TI



EDL08220027


11. Electric system

Alternator

General Information


The alternator is fitted with integral silicon redtifiers. A transistorized requlaor mounted on the alternator body interior limits the alternator voltage. The alternator should not be operated except with the regulator and battery connected in circuit to avoid damage to the rectifier and regulator. The alternator is maintenance-free, nevertheless, it must be protected against dust and, above all, against moisture and water.

Views



EA8O3006

Wiring diagram




EA8O3007


11. Electric system

Air Heater

- 1) Air heater Operating Conditions
 - It is recommended to use the air heater when the cooling water temperature is below 5 degrees.
 - Air heater, Timer, Relay is supplied, and the heater operation time is automatically adjusted according to the cooling water temperature.
 - Preheating / Post-heating time




2) Air heater Mounting parts




NO.	Description	Qty
1	PIPE, INLET	1
2	BOLT, COLLARED HEX	4
3	HEATER ASSY, AIR	1
4	GASKET, AIR PIPE	2

3) Air heater Diagram



4) Air heater schematic



11. Electric system		

12. Others/driving system

General information	185
General Information	185
Crankshaft	186
Measurement of Crankshaft	186
Measurement of Crankshaft Bearing and Connecting Rod Bearing	187
Piston	189
Disassembly of Piston	189
Assembly of Piston	189
Piston Inspection	190
Piston Ring and Ring Groove	191
Piston pin	
Connecting rod	193
Inspecting the connecting rod	193
Others	194
Engine timing	194



General information

General Information

The forged crankshaft has screwed-on counterweights.


The oil seal installed between the crankshaft and flywheel prevents oil leakage into the flywheel housing.

The connecting rods are die-forged, diagonally split and can be removed through the top of the cylinders together with the pistons. Crankshaft and connecting rods run in steel-backed lead bronze ready-to-fit bearings.


Crankshaft

Measurement of Crankshaft

- 1. Inspection and measurement
- 1) Visually inspect whether there is any crack or scratch on the journal and pins of the crankshaft.
- 2) Perform the magnetic particle testing or the liquid penetrant testing (color check) to check the cracks on the crankshaft. If cracks are found, replace the crankshaft with a new one.
- 2. Measuring journal and pin diameter
- Using an outer diameter micrometer, measure the crankshaft journals and pins toward the direction as shown in the figure to determine the amount of wear.



DV2213147A




DV2213148A

	Standard	Limit
Journal diameter	Ø83.966 ~ Ø83.988 mm	Ø83.000 mm
Pin diameter	Ø70.971 ~ Ø70.990 mm	Ø70.000 mm

- 2) If the amount of wear exceeds the tolerance limit, grind the crankshaft and assemble an under-size bearing.
- 3) There are 4 kinds as below, and the crankshaft also can be used by regrinding as below.
- Standard
- 0.25 (Inside diameter 0.25 mm less than standard)
- 0.50 (Inside diameter 0.50 mm less than standard)
- 0.75 (Inside diameter 0.75 mm less than standard)
- 1.00 (Inside diameter 1.00 mm less than standard)
- 4) "R" part standard value
- Crank pin "R": 4.3 ~ 4.5
- Crank journal "R": 3.8 ~ 4.0


ACAUTION

In case of crankshaft regrinding, the "R" part at the end of bearing must accurately be ground without fail and should avoid any processed jaw or coarse surface.



DV2213149A_E

- 3. Warpage of crankshaft
- 1) Put the crankshaft on the V block.
- 2) Put the dial gauge on the surface plate and measure the warpage of the crankshaft as spinning the crankshaft.



EDB58180012


No	Standard	Limit
4	0.1 mm	0.15 mm
3, 5	0.06 mm	0.1 mm
2, 6	0.03 mm	0.05 mm

Measurement of Crankshaft Bearing and Connecting Rod Bearing

- Visual inspection
 Visually inspect the crankshaft bearing and connecting rod bearing for scratch, unusual wear or damage.
- Oil clearance between crankshaft and bearing (Method 1: Dial gauge)
- 1) Assemble the main bearing to the cylinder block, tighten the bearing cap to the specified torque.

Item	Standard
Tightening torque	30 kgf⋅m

2) Measure the inner diameter.



DV2213151A


3) Assemble the bearing to the connecting rod, tighten the bearing cap to the specified torque.

<Connecting rod tightening torque>

Tightening	1st Step	4 ±0.2 kgf·m
torque	2nd Step	60° ±3°

Note) Do not apply oil to the joint before bolting.

4) Measure the connecting rod bearing journal inner diameter.



DV2213152A


 if the cleanrance exceeds the tolerance limit, grind the crankshaft journal and pin, and assemble under size bearing.

Item	Standard	Limit
Clearance	0.052~0.122mm	0.25mm

- Oil cleanrance between crankshaft and bearing.
 (Method 2: Plastic gauge)
- 1) Assemble the crankshaft to the cylinder block.
- 2) Place the plastic gauge on the crankshaft journal and pan.

12. Others/driving system

- 3) Assemble the bearing cap and tighten the bolt to the specified torque.
- 4) Loosen the bolt, remove the bearing cap.
- 5) Measure the width of the plastic gauge at the widest point using the ruler for plastic gauge measurement. This is the oil clearance.
- 6) Measure the oil clearance of connecting rod as the same procedure.
- 4. End play
- 1) Assemble the crankshaft in the cylinder block.
- 2) Install the dial gauge, and measure the end play of crankshaft by pushing the crankshaft to axial direction.



EAMD065S

Item	Standard	Limit
Axial end play	0.1~0.289 mm	0.5 mm

Piston


Disassembly of Piston

- 1. Disassemble the piston assembly
- 1) Remove the snap rings by means of a plier.




EAMD038I

 Heat the piston with a electric heater, then take out the piston pin from the piston as tapping it with a round wooden bar.



EAMD088I

3) Remove the piston ring with a plier.




EAMD039I

4) Clean the piston thoroughly.

Assembly of Piston


- 1. Attach the piston and connecting rod
- 1) Use a piston heater to heat the piston approximately 100°C for 5 minutes.



DV2213156A


2) Align the piston pin hole with the oiled connecting rod small end and press the piston pin (by lightly tapping with a rubber hammer) to assemble the connecting rod with the piston.

12. Others/driving system



EAMD088I

- Install the snap rings and check to see that it is securely assembled.
- 4) Install the piston ring in the piston using piston ring pliers.
- 5) Identify the mark "Y" or "TOP" on the ring end to prevent the top and bottom of the piston ring from being interchanged and make the marked portion face upward. (The surface marked as "Y" is upper surface.)




EAMD090I

Piston Inspection


- 1. Visual check
- 1) Visually check the pistons for cracks, scuff or wear, paying particular attention to the ring groove.
- 2. Clearance between the piston and cylinder liner
- With an outside micrometer, measure the piston outside diameter at a point 13mm away from the lower end of piston skirt in a direction at a right angle to the piston pin hole.

Piston of outside diameter	Ø110.883 ~ Ø110.897 mm
----------------------------	------------------------



EAMD066S

 Assembly the cylinder liner at the cylinder block and measure inner diameter at upper, middle, lower that is, 3 step by 45° interval.



DV2213111A

- Calculate the average values after eliminating the maximum and minimum values.
- 4) If the measured values are very close to the limit value or beyond, replace it.


Standard	Limit
Ø111.000 ~ Ø111.022mm	Ø111.122mm

5) The clearance is computed by subtracting the piston outside diameter from the cylinder liner inside diameter. Replace either piston or cylinder liner, whichever damaged more, if the clearance is beyond the specified limit.

Clearance between	0.103~0.139 mm
piston and liner	0.103~0.139 11111

Piston Ring and Ring Groove

- 1. Visual check
- Replace the piston rings with new ones if detected worn or broken when the engine is overhauled.
- 2. Piston ring gap
- Insert the piston ring into the upper portion of the cylinder liner bore so that it is held at a right angle to the cylinder liner wall.




DV2213158A_E

2) Measure the piston ring gap with a feeler gauge.

	Standard	Limit
Top ring	0.40 ~ 0.60 mm	1.5 mm
2nd ring	0.40 ~ 0.60 mm	1.5 mm
Oil ring	0.30 ~ 0.50 mm	1.5 mm

- 3) Replace piston rings with new ones if the gap is beyond the limit.
- 3. Piston ring side clearance
- Fit the compression ring and oil ring in the piston ring groove.
- 2) With a feeler gauge, measure side clearance of each ring, and replace either the ring or piston if the measured value is beyond the specified limit.

	Standard	Limit
Top ring	0.105 ~ 0.155 mm	0.2 mm
2nd ring	0.07 ~ 0.102 mm	0.15 mm
Oil ring	0.05 ~ 0.09 mm	0.15 mm




DV2213159A_E

- 4. Piston ring tension
- With a tension tester, measure piston ring tension.
 Replace the piston ring if the measured value is beyond the limit.

	Standard
Top ring	2.58 ~ 3.88 kg
2nd ring	1.81 ~ 2.71 kg
Oil ring	3.57 ~ 5.03 kg

Piston pin

- 1. Wear
- Measure the wear amount of the piston pin with a outside micrometer.
- 2) If the reading exceeds the tolerance limit, replace the pin.



DV2213160A


Item	Standard	Limit	
Outside diameter	Ø41.994 ~ Ø42.000mm	Ø41.940mm	

12. Others/driving system

- 2. Clearance
- Measure the clearance between the piston pin and connecting rod bushing, and replace either of them, whichever damaged more, if the measured value is beyond the limit.

	Standard	Limit	
Piston Pin (Piston)	0.003 ~ 0.015 mm	0.08 mm	
Piston Pin (Connecting rod)	0.050 ~ 0.081 mm	0.15 mm	

3. Condition check



DV2213161A


- Check the engaged condition of the piston and piston pin.
 If it is possible to force the pin into the piston heated with piston heater, the piston is normal.
- 2) When replacing the piston, be sure to replace the piston pin together.

Connecting rod

Inspecting the connecting rod

- 1. Distorsion
- Check the connecting rod for distortion. As shown in the figure below, install the connecting rod to the connecting rod tester, and check for distortion using a feeler gauge.
- 2) If the connecting rod is found distorted, never re-use it but replace with a new one.
- 2. Holes alignment (parallelism)
- Measure the alignment of the connecting rod piston pin bushing holes with connecting rod big end holes. At this time also, use both connecting rod tester and feeler gauge.

Standard	Limit
0.05 mm	0.1 mm or less




EA0M4034

- 3. Wear
- Assemble the connecting rod to the crankshaft and measure connecting rod big end side clearance using a feeler gauge.
- 2) Assemble the connecting rod to the piston and measure connecting rod small end side clearance.
- 3) If the measured values are beyond the limit, replace the connecting rod.

Limit	0.5 mm

Others

Engine timing




EA9O2004

- 1. Camshaft gear (Z= 54)
- 2. Injection pump gear (Z= 54)
- 3. Idle gear (Z= 42)

- 4. Crankshaft gear (Z= 27)
- 5. Oil pump idle gear (Z= 23)
- 6. Oil pump drive gear (Z= 36)

Appendix

Engine assembly	tolerance	197	7
	/ tolerance	101	



Engine assembly tolerance

Item	Compo- nent	Inspection Item		Specifications	Limit for Use	Action	Remarks
		Cylinder liner I.D. wear		Ø111 ~ Ø111.022	Ø111.222	Replace the liner	Measure the bottom of intact edge on the top
	Cylinder	Liner project	ion	0.03 ~ 0.08	-		At top of cylinder block
	block and liner	Flatness of top of cylinder block		0.05	-	Correct it with surface grinder	For length 200 mm
Engine body		Water pressi (for 1 min.)	ure test (kg/cm²)	4	-	Replace in case of water leak	
bouy		Valve seat	Intake	0 ~ 0.3	0.55	Replace the	
	Culindor	press	Exhaust	0 ~ 0.3	0.55	valve seat	
	Cylinder head and valve	Cylinder hea	d height	109.9 ~ 110.1	108.4	Replace the cyl- inder head	
	vaive	Water pressi (for 1 min.)	ure test (kg/cm²)	4	-	Replace in case of oil leak	Water temperature: 70°C
		Maximum piston O.D. Clearance between the piston and liner		Ø110.883 ~ Ø110.897	-	Replace the piston	Measure at the point 13 mm up from the bottom of the piston
				0.041 ~ 0.221	0.3	Replace if worn over the limit	
	Piston	Piston ring	Top ring	-	-	If the groove is	
		groove	2nd ring	3.06 ~ 3.08	-	over the limit,	
		width	Oil ring	4.04 ~ 4.06	-	replace the pis- ton	
		Piston projection at top of cylinder block		0.357 ~ 0.533	-		Measure the bottom of intact edge on the top
Major		Allowable we ence among	-	±15 g	-	Replace the piston	
drive		Distance de se	Top ring	0.40 ~ 0.60	1.5		Otam dand server I.D.
compo- nents		Piston ring	2nd ring	0.40 ~ 0.60	1.9	Replace the ring	Standard gauge I.D.: Ø108
rienis		gap	Oil ring	0.30 ~ 0.50	1.5		Ø 100
		Piston ring	Top ring	-	-	Danlage the ring	The allowable limit is
	Piston ring	side clear-	2nd ring	0.07 ~ 0.102	0.15	Replace the ring or piston	based on the standard
		ance	Oil ring	0.05 ~ 0.09	0.15	-or pistori	clearance
		Direction of ring opening		-	-	Install rings only with their open- ings 120° apart	
		Piston pin O	.D.	Ø41.994 ~ Ø42	Ø41.94	Replace the piston pin	
	Piston pin	Clearance between piston pin and piston groove		0.003 ~ 0.015	0.08	Replace if wear amount is over the specification	

Item	Compo- nent	Inspection Item	Specifications	Limit for Use	Action	Remarks
		Uneven wear on journal and pin	-	0.01	Repair it with a grinder	Lateral/longitudinal
		Journal O.D.	Ø83.966 ~ Ø83.988	Ø83	Use the undersize bearing (0.25, 0.5, 0.75, 1.0)	
		Pin O.D.	Ø70.971 ~ Ø70.990	Ø70		
		Ovalness of journal and pin	0.008	0.025		
		Allowable concentricity of journal and pin	0.01	0.03		
		Allowable inclination of journal and pin	0.02	0.03		
		Clearance between crankshaft and main bearing	0.052 ~ 0.122	0.25	Replace the bearing	Measure at the crown section
	Crankshaft	Axial play of crankshaft	0.1 ~ 0.289	0.5	Replace the thrust bearing	
		Crankshaft deflection	0.06↓	0.1	Repair it with a press	Bearing No. 4 (Supporting No. 1 and 7)
		Crankshaft levelness (g·cm)	60↓	60 or below	Check the dynamic balancing	Measure at 400 rpm
Major drive compo-		Journal bearing cap bolt tightening torque (kg·m)	30	-	Apply oil to the bolt	There should be no for- eign material on the bearing cap mounting surface
nents		Journal bearing crush	0.08 ~ 0.110	-		Tighten the bearing cap and unscrew one bolt for measurement
		Oil seal wear (Back side of crankshaft)	-	-	Replace the oil seal if oil leak is found	
		Connecting rod play	0.170 ~ 0.248	0.50	Replace the con- necting rod	
		Clearance between con- necting rod bearing and crank pin	0.034 ~ 0.098	0.25	Replace the bearing	
		Clearance between small end bushing and piston pin	0.050 ~ 0.081	0.12		
	Connect- ing rod	Connecting rod bearing crush height	0.04 ~ 0.07	-		Tighten the bearing cap and unscrew one bolt for measurement
		Big end and small end side clearance	-	0.50	Replace the con- necting rod	
		Allowable weight difference among connecting rods	30 g↓	-		
		Connecting rod bearing cap bolt tightening torque (kg·m)	1st: 4 kg·m ±0.2 2nd: 60° ±3°	-	Remove oil from bolt	Remove foreign materials from the connection surface

Appendix

Item	Compo- nent	Inspection Item	Specifications	Limit for Use	Action	Remarks
		Camshaft journal O.D.	Ø57.86 ~ Ø57.88	Ø57.52		
		Clearance between cam- shaft and bushing	0.12 ~ 0.17	0.24	Replace the cam bushing	
	Camshaft	Axial play of camshaft	0.28 ~ 0.43	0.6	Replace the thrust plate	
Major drive		Camshaft deflection	0.05	0.2	Repair or replace the cam-shaft	
compo- nents	Timing	Clearance between idle shaft bushing and idle shaft	0.025 ~ 0.091	0.15		
	gear	Axial play of idle gear	0.043 ~ 0.167	0.3	Repair or replace the gear	
		Gear backlash (cam, idle, crank and injection pump)	0.16 ~ 0.28	0.35	Replace the gear	

Item	Compo- nent	Ins	pectio	n Item	Specifications	Limit for Use	Action	Remarks				
		Intake valve stem O.D.			Ø8.950 ~ Ø8.970	Ø8.93	Replace the	When replacing the				
		Exhaust valve stem O.D.			Ø8.935 ~ Ø8.955	Ø8.91	valve and valve guide	valve, replace the guide as well				
		Clearand		Intake	0.030 ~ 0.065	0.1	Replace the					
		between stem and valve gu	d	Exhaust	0.045 ~ 0.080	0.15	valve and valve guide	Replace either one of them with more wear				
		Valve he		Intake	2.7	2.2	Replace the					
		thicknes	s	Exhaust	2.2	1.7	valve					
		Clearand	се	Intake	2.0	-						
		between guide an valve sp seat	ıd	Exhaust	2.0	-						
		guide an	ıd cylir g hole	ween valve nder head	-0.039 ~ -0.010	-		Press fit after applying oil to the valve guide				
		Concent and guid		f valve seat	0.05	-		Excluding spring seat				
				ength	Approx. 64	-						
		Intake valve spring	alve (Measuri		67 ~ 73	66.5	Replace the valve spring					
			Squareness (free)		1.5°	-						
Exhaust valve	Valve	Exhaust valve spring	, ,	free length	73.8	-						
vaive			Inner	Tension (kg) (Measur- ing length: 38 mm)	36 ~ 40	-	Replace the valve spring					
			Exhaust			Square- ness (free)	1.5°	-				
				free length	77.7	-						
			Spring	Spring	эрші		Outer	Tension (kg) (Measur- ing length: 41 mm)	71 ~ 79	-	Replace the valve spring	
				Square- ness (free)	1.5°	-						
			Contact surface of valve stem and rocker arm		-	-	If the rocker arm or stem is exces- sively burred, repair or replace it					
		rocker a	Clearance between rocker arm shaft and rocker arm bushing		0.040 ~ 0.113	0.2	Replace the bushing or shaft					
		Rocker arm shaft wear		_	Ø23.939 ~ Ø23.96	Ø23.75	Replace					
		Push roo	d defle	ction	-	0.3	Replace					

Item	Compo- nent	Inspec	tion Item	Specifications	Limit for Use	Action	Remarks	
Valves	Tappet	Clearance b pet and cylin	-	0.035 ~ 0.077	0.15	Replace the tap- pet		
		Tappet O.D.		Ø19.944 ~ Ø19.965	-	Replace the tap- pet		
		Contact of ta	appet and	-	-	Replace if excessive wear or deformation is found		
	Oil pres- sure	Oil pressure (at rated spe	eed)	4.8 or below	3.5	Check for oil leakage and clearance at each section		
		Oil pressure (idling withou		0.8 ~ 1.4	0.6	Use the recom- mended oil		
	Oil tem-	Max. allowal	(°C)	-	105		Temperature above this	
	perature	Instant allow temperature		-	120		limit is not allowed	
	Oil pump	Axial clearar pump gear	nce of oil	0.055 ~ 0.105	-	Deplete the goor		
			etween gear pump cover	0.032 ~ 0.077	-	Replace the gear or cover		
		Clearance between drive gear shaft and cover hole		0.040 ~ 0.094	-	Replace the bushing or cover		
Lubri-		Gear shaft O.D.		Ø16.950 ~ Ø16.968	-	Replace the gear shaft	Ø17e7	
cation system		Drive gear b	ushing O.D.	Ø28.000 ~ Ø28.033	-	Replace the bushing	Ø28e7	
		Backlash Backlash Pump gear a idle ge	Backlash		0.15 ~ 0.25	0.8	Adjust the back- lash	
			Pump drive gear and idle gear	0.15 ~ 0.25	0.8			
	Valve opening pressure	Oil pressure valve	adjusting (kg/cm²)	4.0 ~ 5.0	-			
		Bypass valve element	e for oil filter (kg/cm²)	1.8 ~ 2.3	-			
		By-pass valv	ve for oil (kg/cm²)	5.0 ~ 6.0	-	Replace the valve		
		Relief valve	(kg/cm²)	8.5 ~ 11.5	-			
		tion nozzle	lve for injec- (kg/cm²)	1.5 ~ 1.8	-			
	Oil filter	Damaged oil filter car- tridge		-	-	Clean or replace		

Item	Compo- nent	Inspection Item	Specifications	Limit for Use	Action	Remarks
	Radiator	Corrosion, damage or poor contact of radiator or pump	-	-	Repair or replace	
		Air leak test (air pressure) (kg/cm²)	1.0	-	Place the part into water. Replace it if air bubbles are seen	
		Pressure valve's opening pressure (kg/cm²)	0.5	-		
		Negative pressure valve's opening pressure (kg/cm²)	20	-		
Cool- ing sys- tem	Coolant pump	displacement (I/min) - Engine speed: 1,800 rpm - Coolant temperature: 80°C - Negative pressure: 0.5 (kg/cm²)	190 or higher	-	Check the coolant passage	Clogged
		Clearance between pump impeller and housing body	0.35	-	Replace if the impeller and housing touch each other	
		Squareness of pulley	0.3	-	Repair it with a bench press	
		Fan belt deflection (with thumb)	Approx. 15	-	Adjust	
	Coolant tempera- ture	Operating temperature (ideal temp.) (°C)	79 ~ 95	-	Temperature above this limit is	
		Instant allowable temp.	-	105	not allowed	
	Thermo- stat	Thermostat's opening temperature (under atmo- spheric pressure) (°C)	79	-	Replace	Type 2) Opening temperature: 83°C
		Thermostat's fully open temperature (°C)	94	-	Replace if a defect is found. Lift: 8 mm or higher	Fully open temperature: 95°C
	Pipe and others	Damaged, cracked poor packing of fuel pipe, injection pipe or nozzle holder	-	-	Repair or replace	
	others	Damaged fuel filter car- tridge	-	-	Replace the car- tridge	
Fuel system	Injection pressure of injection nozzle (kg/cm²)		220	-	Adjust with shims	1st: 160 2nd: 220
	Injection pump's overflow valve opening pressure (kg/cm²)		1.0 ~ 1.5	-	Replace the valve	
	Protrusion height of cylinder head surface (mm)		3.6 ~ 4.1	-	Replace the cyl- inder head and nozzle	
Com-	Engine test operation		-	-	Refer to the information for test operation in Appendix.	
pletion test	Cylinder compres-	Cylinder compression pressure (kg/cm²)	24 ~ 28	24 or higher	Repair	
	sion Compression pressure dif- ference among cylinders		Below ±10% from average value	-	Repair	At 200 rpm or higher (20°C)

Governor Actuator Controller



Governor Actuator

Definition

The governor detects the engine rpm using a magnetic pick-up sensor to adjust the flow rate of the injection pump and maintain the desired rpm.


The governor activates the engine's fuel injection pump when the accelerator pedal is pressed while the vehicle is in operation and adjusts the speed of the vehicle.

The governor detects the engine speed, compares it with the set speed and sends out an output signal to open or close the fuel injection pump accordingly until the actual speed reaches the set speed.

In terms of operating the vehicle, the driver monitors the speedometer and if there is a desired speed, this corresponds to the governor's speed input, while the governor's output adjusts the accelerator in order to maintain the desired speed.

Appearance and Installation

This is a picture of the governor actuator installed which electronically controls the injection pump assembled with the generator engine.



Operating Principles

In this system, when adjusting the engine output, the controller is adjusted to set and activate the IDLE and RUN RPM, while the electronic governor is operated to adjust the injection pump and engine output.

The moving core is activated to adjust the rpm.

Product Specifications


1. General specifications

Item		GN11 (DWA-2000)	GN12 (GNSA-2002)
Operating voltage	(kg/lit)	DC 24V	DC 24V
Max. fuel quantity	(°C)	Adjust	Adjust
Production capacity (40°C)	(cst)	200 ~ 1,000 KW	150 ~ 250 KW
Allowable humidity	(wt%)	100%	100%
Operating current	(°C)	1.5 A	2.0 A
Max. operating current	(°C)	4.5 A	3.1 A
Rack operating power	(°C)	58.7 N	27.5 N
Rack operating range (ASTM)		20 mm	21 mm
Engine injection pump specs.		Right rack type	Right rack type

2. Mechanical specifications

Item	GN11 (DWA-2000)	GN12 (GNSA-2002)	
Product dimensions	107.1 x 180.4 x 196.5	112 x 205 x 101	
Product weight	4.9 kg	2.6 kg	
Installed engine (Bosch type)	P 3000, P 7000	AD Series	
Material for exterior	AL (ALDC-12)	AL (ALDC-12)	
Material for core	Pure iron	Pure iron	
Coil size and no. of turns	Ø0.85 / 715	Ø0.6 / 790	

3. Outside view and main components of governor



1) Frame : The body of the governor. Made of ALDC-12 with high corrosion resistance.

2) Ball link assembly : A bearing assembly which connects the injection pump rack and governor

actuator operating lever.

3) Stop plate : A part assembled with the ball link assembly. It serves to stop the engine by

means of the emergency stop lever.

4) Static core assembly : A welded assembly composed of several layers of pure iron. A coil is wound

around a bobbin, press fitted into the frame of the static core and the assem-

bly, and then fixed in place with an epoxy resin.

5) Moving core assembly: A welded assembly composed of several layers of pure iron. When the gover-

nor controller adjusts the engine, the moving core assembly is activated to

control the fuel and adjust the speed.

6) Operating lever : A lever which connects the shaft and ball link assembly.

7) Stop lever : An emergency stop lever which stops the engine manually when the engine

cannot be stopped by the control panel. (Material: P.O. sheet)

8) Coil : A copper wire made of 0.85 ¢ LG B enamel and wound 715 turns around a

bobbin. It is connected to the governor controller and acts as an electromag-

net.

Control Unit (1)

The engine speed control unit used by Hyundai Doosan Infracore is an electronic control unit designed to be able to respond quickly and accurately to changes in the instantaneous load.

This control unit is designed to receive a signal from the magnetic pick-up sensor (speed sensor) of the engine when a fluctuation occurs in the engine load and then be automatically fine-tuned to the changes in the engine rpm, thereby providing high reliability and satisfying adverse environmental engine conditions.

The main feature of this device is that it includes functions for adjusting the amount of starting fuel and the fluctuations in the speed. It thereby helps to reduce engine emissions. It also has a function for parallel engine operation, a protective function for when the battery polarity is reversed, and functions designed to ensure safety during short circuits in the actuator circuit, battery power cut-off or failure of the magnetic pick-up sensor.

Description of Functions

In order for the controller or actuator to function normally, the output signal value of the magnetic pick-up sensor must be $0.5 \sim 120V$, and this signal is connected to "C" and "D" on the controller. Terminal "D" is connected to the negative ("-") battery terminal "E" inside the controller terminal.

When the signal from the magnetic pick-up sensor reaches the controller, it is converted into an analog speed signal and amplified.

In the event that the controller fails to receive the output value from the magnetic pick-up sensor during operation, the controller's output circuit shuts off all current flowing to the actuator.

The controller's integrated circuit receives the signal from the magnetic pick-up sensor based on the set speed value. This range is 8:1 and can be adjusted with the 25-turn potentiometer. This speed setting output value becomes the input value traveling to the dynamic control section. With the help of this dynamic control circuit, most of the engine and fuel systems perform evenly and stably.



CAUTION

For the connection to the magnetic pick-up sensor, either two wires twisted together or shielded wire should be used, but be careful that this shield is not grounded to the engine. If grounded to the engine, an incorrect speed signal may be delivered to the speed controller.

The controller's circuit may be affected by adjustments to the gain and stability. In order to increase the operating responsiveness of the actuator within the governor, turn the gain clockwise to adjust it. The adjustment range for the gain is approximately 33:1.

If the stability is turned in the clockwise direction, the actuator, i.e. governor reaction time increases.

While the engine is running, the starting fuel in the controller can be adjusted from an almost closed state to a completely open state. When the engine is started, the adjusted position of the speed is determined initially by the set idle value and the speed ramping circuit. When the engine has finished speeding up, the engine is kept at the set speed while satisfying the speed fluctuation rate of the controller.

The controller's output circuit switches the current for activating the actuator at a frequency of around 500 Hz.

This is because no visible changes appear in the output curve for the actuator since the switching frequency is much higher than the natural frequency of the actuator.

The transistors in the output section are switched in order to achieve effective control of the output, thereby reducing power consumption within the controller. The output circuit delivers up to 10 A of continuous current from the 12V or 24V battery system at 25.

The actuator responds to the average value of the current based on the position of the fuel control lever.

The performance of the speed controller is stable in its standard state. In order to switch this to the droop mode, terminals "K" and "L" must be connected to one another, and the amount of change must be adjusted with the adjustment control lever. In addition, the droop range increases when terminals "G" and "H" are connected.

The engine speed controller includes functions for protecting the actuator and the engine, as well as additional functions. For example, the controller circuit includes a protective circuit for minimizing overspeeding which may occur when an excessive load is applied to the engine while starting or running the engine. The current controller also includes a load divider and automatic parallel feeder which, when used, enable parallel operation.

Specifications

Item	Details	Specifications	
	Simultaneous Operation /	±0.25 % or less	
	Relative Normal Stability	±0.25 % Of less	
	Speed Range / Governor	1 K ~ 7.5 KHz continuously	
	Speed deviation based on changes in temp.	Max. ±1%	
	Idle Adjustment (Clockwise)	1,200 Hz or less	
	Idle Adjustment (Counterclockwise)	4,100 Hz or less	
Performance	Droop Range	Adjustable between 1 ~ 5%	
	Max. Droop Adjustment	FI - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	
	(With Terminals K-L Connected)	Fluctuation of 875 ±75 Hz / 1.0 A	
	Min. Droop Adjustment	Fluctuation of 15 + 6 Hz / 1 0 A	
	(with Terminals K-L Connected)	Fluctuation of 15 ±6 Hz / 1.0 A	
	Speed Trim Range	±200 Hz	
	Remote Variable Speed Range	500 ~ 7.5 Hz	
	J	100 ±15 Hz / Volt @ 5.0 K	
Terminal	L	735 ±60 Hz / Volt @ 65 K	
Sensitivity	N	148 ±10 Hz / Vo1t @ 1 Meg	
	Р	10 V DC supply @ 20 ma.	
Speed Switch Ad	justment Range	1,000 ~ 10,000 Hz	
E. Mariana and	Ambient Operating Temperature Range	-40 ~ 85°C	
Environmental Conditions	Relative Humidity	Up to 95 %	
Conditions	Surface Treatment	Corrosion resistance	
	Supply	12 or 24V DC (instantaneous and back voltage protection) *	
	Polarity	" - " ground	
	Power Consumption	50 mA of continuous current to actuator	
Input Power	Actuator Current at 25°C (Inductive Load)	Continuous min. 2.5 A, max. 10 A **	
	Speed Sensor Input Voltage	0.5 ~ 120V	
	Speed Switch Relay Contact	40.4	
	(N.O. and N.C.)	10 A	
Doliobility	Vibrations	1 G @ 20 ~ 100 Hz	
Reliability	Testing	100 % functionality test	
	Dimensions	Refer to outside view feature	
Туре	Weight	820 g	
	Installation	Installed vertically	


Λ

CAUTION


- * The droop is based on the 4,000 Hz speed detection frequency from no load to full load, as well as changes of 1 A in the actuator current. When the speed sensor signal is high, the amount of droop decreases, and when the amount of change in the actuator is large, the amount of droop changes significantly. For details about droop operation, refer to the description of droop.
- ** Protects against back voltage using a diode. A 15 A fuse must be installed on the battery anode
- *** There is a protective device which cuts off current flowing to the actuator in the event of a short circuit. Once this short circuit is removed, the device automatically returns to normal.

Components

DWC-2000



GAC-ESD5550





CAUTION

If the length of the wires is over 3 m, shielded wire must be used. One end must be grounded using shielded wire.

The speed control unit must be firmly installed in the control cabinet or engine just as with other sensitive control equipment.

If there is concern that the controller may come into contact with water or condensation, the controller must be installed vertically.

Description of Controller Terminology

1. Starting Fuel

Controls the amount of starting fuel during the initial ignition. When rotated clockwise, the amount of fuel increases.

2. Speed Ramping

Controls the time required to reach the maximum rpm. When rotated counterclockwise, the time required for reaching the rated rpm decreases.

3. Idle

Adjusts the idle rpm of the equipment. When rotated clockwise, the engine rpm increases.

4 Gain

Stabilizes fluctuations in speed occurring in the engine.

5. Stability

Stabilizes fluctuations in speed caused by the engine load.

6. Speed

Adjusts the engine rpm. When rotated clockwise, the engine rpm rises.

7. Overspeed

Adjusts the engine overspeed rpm. When rotated clockwise, the maximum rpm rises.

Droop rpm

Used when running the generator in parallel.

9. Reset

Used when resetting the overspeed controller.

10. Test

Used when checking or setting the overspeed.

11. Terminals A and B

Connected to the actuator in the engine injection pump. (No polarity)

12. Terminals C and D

Connected (no polarity) to the magnetic pick-up sensor.

Shielded wire must be used. It must also not be connected to the magnetic pick-up sensor for any other purposes.

13. Terminals E and F

Connected to the battery (ER - terminal, FR + terminal).

14. Terminals G and M

Terminals for maintaining the idle rpm.

15. Terminals K and L

Terminals for droop.

16. Terminals H, J, N and P

Auxiliary terminals.

Wiring

Please refer to the chart above for the basic electrical wiring. When connecting the actuator and battery to terminals A, B, E and F, the wire thickness must be at least 1.3 mm². If the wires are long, they must be thicker in order to reduce drops in voltage.

For the positive (+) battery terminal "F," a 15 A fuse must be used as shown in the picture.

The ground cable of the magnetic pick-up sensor connected to terminals "C" and "D" must either use two wires twisted together for its entire length or be shielded.

The shielded part of the wire for the magnetic pick-up sensor must be connected to terminal "D." The shielded part must be insulated so that it is not grounded to the engine. Otherwise, an incorrect frequency signal may be delivered to the speed control unit.

The voltage of the magnetic pick-up sensor must be at least 1V while the engine is running.

How to Adjust the Engine Performance (For New Controllers)

- 1. Before starting the engine
 - (1) Set the gain and stability potentiometers of the controller to the central positions.
 - (2) Starting fuel Turn the potentiometer as far clockwise as possible. (The position in which the most fuel is supplied)
 - (3) RPM ramping

 Turn it as far counterclockwise as possible. (The position in which the reaction speed is quickest)
 - (4) Turn the idle potentiometer as far clockwise as possible.
 - (5) Connect terminals G and M. (To maintain the idle rpm after starting the engine.)
- 2. After starting the engine

Once the engine is started, move the actuator to the maximum fuel supply position, then maintain the idle rpm after starting it.

- (1) Check the state of ignition and adjust the starting fuel and speed ramping suitably.
- (2) If the engine appears unstable after starting it, turn the gain and stability potentiometers counterclockwise to adjust them until it stabilizes.
- (3) After disconnecting terminals G and M, use the speed potentiometer to adjust the maximum rpm.
- (4) After reconnecting terminals G and M, adjust the idle rpm to 750 rpm, disconnect the connecting wires and then check and adjust the maximum rpm.
- 3. Setting the engine rpm

If the speed potentiometer of the controller is turned clockwise, the setting value of the engine rpm increases. In order to do so, a 5K potentiometer must be installed between terminals "G" and "J."

4. Adjusting the characteristics of the actuator

Do the following after setting the engine to the rated no-load speed.

- (1) Turn the gain potentiometer clockwise until the engine characteristics become unstable. Slowly turn the potentiometer clockwise until the engine stabilizes again. In order to obtain an accurate setting value, turn the potentiometer counterclockwise slightly.
- (2) Turn the stability potentiometer clockwise until the engine characteristics become unstable. Slowly turn the potentiometer counterclockwise until the engine stabilizes again. In order to ensure accuracy, turn the potentiometer counterclockwise slightly.

(3) If the engine is running with load, the gain and stability must be adjusted finely. Generally, this should be done in an unloaded, stable state.



CAUTION

In the event that it continues to appear unstable or demands higher performance in spite of being adjusted, refer to the section on troubleshooting.

5. Adjusting the starting fuel

Exhaust smoke occurring after the engine is started can be minimized as follows.

- (1) Idle the engine and connect terminals "M" and "G."
- (2) Use the idle potentiometer on the controller to adjust it to the minimum rpm at which the engine is stable.
- (3) Turn the starting fuel potentiometer counterclockwise until the engine speed drops. Increase the potentiometer slightly in order to set the idle rpm to a suitable speed.
- (4) There are two ways of increasing the engine rpm using the SPEED potentiometer on the speed controller.
 - **Method 1)** Accelerating the rated speed immediately after starting the engine (used in generators)

 Disconnect terminals "M" and "G" and start the engine, then adjust the speed ramping potentiometer in order to minimize the exhaust smoke while the engine accelerates from the idle rpm to the rated rpm.
 - **Method 2)** After starting the engine, keeping the engine at the idle rpm for a certain amount of time until it is accelerated to the rated speed
 - a) Use the switch to connect terminals "M" and "G." Turn the speed potentiometer counterclockwise to adjust the engine rpm. But if excessive exhaust smoke is produced while accelerating the engine, adjust the starting fuel potentiometer counterclockwise. But if it takes an excessive amount of time to start the engine, adjust the potentiometer clockwise gradually.
 - b) In order to minimize the amount of exhaust smoke while accelerating from the idle rpm to the rated speed, adjust the speed ramping potentiometer with the switch open.

6. Setting the idle rpm

The idle speed increases when the idle potentiometer on the controller is turned clockwise. When the engine is set to the idle speed, this controller must be in the "droop" state in order to be able to drive stably.

7. Droop operation

Droop is used when running the engine generator in parallel, so do not use it when running the engine in isolation.

The value increases when the selection switch is set to the DROOP position and the droop potentiometer is turned clockwise.

In other words, the greater the load applied to the engine in this position, the more the speed drops.

The droop range is determined by the amount of change in the current flowing to the actuator when the engine load changes from no load to full load.

The droop range can be determined by means of internal adjustment of the controller alone and is usually set to within 10%.

After adjusting the droop range, you can reset the previously set value of the rated speed. After measuring the engine rpm, reset the speed as necessary.

8. Auxiliary input

Auxiliary terminal "N" receives signals from the load divider, automatic parallel feeder or other auxiliary devices in the governor system. Connect auxiliary devices for the speed controller directly to this "N" terminal. Use shielded wires when connecting wiring. When the automatic parallel feeder is used independently from the load divider, a 3 m resistor must be used between terminals "N" and "P" in order to adjust the voltage of the engine speed controller and parallel feeder.

The engine rpm drops when an auxiliary device is connected to terminal "N," so be sure to reset the controller.

A jumper must be used between terminals "G" and "J" or the frequency must be adjusted when the engine speed controller is operating at the maximum acceptable frequency.

When using this device, the acceptable frequency range of speed control is increased to over 7,000 Hz.

9. Auxiliary supply

Power can be supplied to auxiliary devices in the governor system at terminal "P" at an even voltage of +10 V, with a maximum current of 20 mA.

Terminal "G" is the reference potential terminal for terminal "P." If terminal "G" is short-circuited, the engine speed controller may be damaged.

10. Remote speed adjustment

A speed adjustment potentiometer is required in order to continuously adjust the engine speed remotely over a certain speed range.

Refer to the following chart in order to select a potentiometer to suit the uses based on the required speed range. If the required speed range is not in this chart, select a potentiometer for a range which is one level higher.

In order to obtain the correct speed range, additional fixed resistors can be attached to both ends of the potentiometer. Connect the potentiometer for setting the speed range according to the following wiring connection diagram.




CAUTION

The generator set supplied by Hyundai Doosan Infracore does not include a speed potentiometer for remote control. The consumer must install one themselves if they desire remote control. In order to obtain engine stability at a very low speed setting, a droop potentiometer can be used to obtain a small amount of droop.

On the other hand, when the speed setting is at its highest, the actuator runs almost stably regardless of the set droop value.

< Capacity and Wiring Connection Diagram for Remote Control Potentiometer >

Speed range	Potentiometer value
900 Hz	1 K
2,400 Hz	5 K
3,000 Hz	10 K
3,500 Hz	25 K
3,700 Hz	50 K



Troubleshooting

1. When the system does not work

When the engine actuator does not work, you can deduce the fault by performing the following four-step voltage test.

Be sure to check the polarity when performing measurements.

Step	Terminal	Specifications	Possible cause		
		Battery supply voltage (12 or 24V DC)	DC battery power not connected, check for damaged fuse		
1	F (+) & E (-)		Low battery voltage.		
			3. Faulty wiring connection.		
		1.0V AC (when starting the engine)	Large gap between magnetic pick-up sensor and ring gear (Check gap)		
2	C & D		Faulty wiring in magnetic pick-up sensor (Check whether the resistance between terminals C and D is 30 ~ 1,200)		
			3. Fault in magnetic pick-up sensor		
3	D(1) 0 C()	P (+) & G (-) 10V DC (Internal supply voltage)	Short circuit in terminal P (causes fault in controller)		
3	P (+) & G (-)		2. Fault in magnetic pick-up sensor		
		1.0 ~ 2.0V DC (when starting the engine)	Low setting value for controller speed adjustment.		
4	F (+) & A (-)		Open or short circuit in actuator wiring.		
4			3. Fault in controller		
			4. Fault in actuator		


2. System not working properly In the event that the system is not running properly, perform the following test.

Item	Details	Specifications
Engine overspeeds	 Do not run the engine Apply a DC power supply to the actuator. 	The actuator will move to the position for maximum fuel supply. Then disconnect the magnetic pick-up sensor connected to terminals C and D.
		(1) If the actuator moves to the position for maximum fuel supply: There is a prob- lem in the controller.
		(2) If the actuator is in a neutral fuel position: This is due to the wrong speed signal for the engine speed
	Manually maintain the speed	1. When the voltage is between 1.0 ~ 2.0V DC
	required for engine operation. Measure the DC voltage between terminals A (-)	(1) The speed potentiometer is set higher than the required speed.
	and F (+) of the speed controller.	(2) There is a fault in the engine speed controller.
		The actuator or connecting device is restricted when the voltage exceeds 2.0V DC
		3. When the voltage is less than 1.0V DC
		(1) There is a fault in the speed controller.
		4. The gain value is too low
The actuator Is not	Measure the battery voltage	Replace the battery if the voltage is less
working properly	while the engine is running.	than 7V in a 12V system or less than 14V in a 24V system.
	2. If terminals A and F are	Fault in the actuator or battery wiring
	connected momentarily, the	Restricted by the actuator or connecting
	actuator should move to the	link
	position for maximum fuel	3. Faulty actuator
	supply.	Check for a blown fuse in the actuator or a short circuit in the actuator wiring.
Operating at a	Measure the voltage at out-	If the measured voltage has a difference of
speed less than that required by	put terminals A and B of the actuator while the engine is	less than 2V with the battery voltage, the fuel control is being obstructed such that it
the engine	running.	cannot reach the maximum fuel supply
	-	position, presumably due to interference from the actuator linkage.
		The speed setting is too low
		2. The speed setting is too low

Control Unit (2)

Components

DWG-2013



Installing (Mounting) the Controller and Cautions

- 1. Install the controller vertically on the face of the control panel, away from water or moisture, and be careful that heat from heating elements near the controller is not transferred to it.
- 2. Also, in the event that it is exposed to moisture for an extended period of time (over one month or dew condensation), it may not reach the rated rpm due to a change in the resistance value of the internal circuit caused by exposure to moisture, so dry it off sufficiently before using it.
- 3. Do not rely exclusively on the function of the actuator in the electronic governor to prevent overspeeding. It is recommended to install a second, independent engine stopping device, such as a fuel shutoff solenoid.
- 4. Regarding setting each Hyundai Doosan Infracore engine to the average set range depending on the type of engine, the indications for the set range on the front of each adjustable resistor recommend the settings within the set range.

EMC (Electromagnetic Compatibility)

In order to minimize damage to the controller due to unnecessary nearby electromagnetic waves, either mount the controller on a grounded metal surface or use a shielded metal case. All wires should be shielded and the shielded part should be grounded to a single point. We cannot provide guarantees for any EMC-related product quality issues arising in the case that the above-mentioned installation method for preventing electromagnetic waves is not performed.


Description of Control Mode Items


In order to minimize damage to the controller due to unnecessary nearby electromagnetic waves, either mount the controller on a grounded metal surface or use a shielded metal case. All wires should be shielded and the shielded part should be grounded to a single point. We cannot provide guarantees for any EMC-related product quality issues arising in the case that the above-mentioned installation method for preventing electromagnetic waves is not performed.

- 1. Items for auxiliary (emergency) control mode
 - (1) Speed control resistor: Controls the engine's running speed.
 - (2) Gain control resistor: Controls the gain (sensitivity).
 - (3) Stability control resistor: Controls the stability (responsiveness).
 - (4) Starting fuel control resistor: Controls the amount of fuel when the engine is started.
 - (5) Speed ramping control resistor: Controls the time it takes to reach the rated speed after starting the engine.
 - (6) Idle control resistor: Controls the initial engine speed.
 - (7) Droop control resistor: Controls the amount of droop (%) during droop operation.
 - (8) Differential control switch (dip switch): A control switch for selecting differential functions.
 - (9) Overspeed lamp control resistor: Controls the activation timing of the engine speed lamp and relay.
 - (10) Run lamp control resistor: Controls the activation timing of the engine operation lamp and relay.
 - (11) Crank lamp control resistor: Controls the activation timing of the initial speed indicator lamp and relay.
 - (12) TB1: A terminal block for external input/output wiring connections.
 - (13) TB2: An output terminal for the engine overspeed relay contact. (Capacity 2 A/125V AC).
 - (14) TB3: An output terminal for the engine operating speed relay contact. (Capacity 2 A/125V AC).
 - (15) TB4: An output terminal for the initial engine speed relay contact. (Capacity 2 A/125V AC).

Adjustment (Tuning) Order and Method

- The potentiometer's guide range on the front of the case is the adjustment range applied to Hyundai Doosan Infracore engines.
- When adjusting the potentiometer, use a flatblade precision screwdriver of the right size. (Be careful not to damage the resistor)
- Check whether the wiring connections of all external devices are correct before starting the engine.





- 4. Adjusting the Engine Start-up Characteristics
 - (1) Connect the G-M terminals (turn the initial engine speed (idle) switch ON). Starting Fuel



IMPORTANT

Purpose of adjustment: Adjusting to the most economical amount of fuel based on the state of the engine installed.

Recommended direction: 1 o'clock to 5 o'clock

Problems when adjusted incorrectly: In the 7 o'clock to 1 o'clock direction, there is not enough fuel, which may cause faulty starting. In the 5 o'clock or higher direction, fuel efficiency worsens during starting and the amount of exhaust gas may increase.

(2) Adjust the speed ramping potentiometer in the 9 o'clock to 12 o'clock direction.



IMPORTANT

The farther it is turned clockwise, the longer it takes to reach the rated (run) speed. (Up to 10 seconds or more)

If the value is too low, overshoot or hunting may occur due to sudden increases in speed. Fuel efficiency may worsen and the amount of exhaust gas may increase.

- (3) Start the engine: Turn on the start motor.
- 5. Adjusting the engine operating speed and initial speed (idle)
 - (1) Adjust the engine operating speed (frequency).



IMPORTANT

After starting the engine, disconnect the G-M terminal. (Turn the initial speed switch OFF) Adjust the speed (frequency) with the speed potentiometer while in an unloaded state.

Clockwise: RPM increases / counterclockwise: RPM decreases

(2) Adjusts the initial engine speed.



IMPORTANT

After turning the initial speed switch ON again, use the idle potentiometer to adjust the speed to 800 rpm.

Purpose of adjustment: Adjusting the initial amount of fuel for starting the engine and for the preheating function after starting the engine.

Recommended direction: 12 o'clock to 3 o'clock. There are differences in the direction for each engine model or rated rpm but we recommend an engine rpm of 800.



IMPORTANT

Problems when adjusted incorrectly: The initial starting performance is degraded and excessive fuel consumption occurs while preheating.

One must not overlook the fact that the idle speed is one of the main factors which determines the start-up characteristics of the engine.

Hence, after adjusting the potentiometer, the initial speed must be adjusted regardless of whether or not idle mode is used.

- 6. Adjusting the Governor Characteristics
 - After disconnecting the G-M terminal (initial speed switch OFF), adjust it when the engine reaches the operating speed (run speed).
 - (2) Adjust the gain.




IMPORTANT

Turn the gain potentiometer clockwise until the engine becomes unstable in an unloaded state.

Slowly turn the gain potentiometer counterclockwise and set it at the position that the rpm becomes in the most stable state.

For the sake of stability, turn the gain potentiometer around 20 arcminutes (10°) in the counterclockwise direction.



7. Adjusting the stability

- (1) Turn the stability potentiometer clockwise until the engine becomes unstable in an unloaded state.
- (2) Slowly turn the stability potentiometer counterclockwise and set it at the position that the rpm becomes in the most stable state.
- (3) For the sake of stability, turn the stability potentiometer around 20 arcminutes (10°) in the counterclockwise direction.

8. Other adjustments


(1) Adjusting the ON timing of the engine operation (run) lamp.



IMPORTANT

Turn the run potentiometer counterclockwise at the engine operating speed until the engine run lamp turns on.

In order to prevent the lamp from blinking (turning on/off when the load changes after setting the rated speed), turn it another 90° in the counterclockwise direction.



(2) Adjusting the ON timing of the initial speed lamp (crank lamp).



IMPORTANT

Turn the crank potentiometer counterclockwise at the crank speed until the crank lamp turns on. In order to prevent the lamp from blinking (turning on/off when the load changes after setting the rated speed), turn it another 90° in the counterclockwise direction.

(3) Adjusting the ON timing of the engine overspeed lamp.



IMPORTANT

Push the test button at the engine operating speed and slowly turn the overspeed potentiometer counterclockwise until the engine overspeed lamp turns on and the engine shuts off. It will be set to a speed around 15% higher than the engine operating speed.



IMPORTANT

After all adjustments are complete, restart the engine and check whether the start-up, no load and load characteristics are stable.

In order to prevent the lamp from blinking (turning on/off when the load changes after setting the rated speed), turn it another 90° in the counterclockwise direction.

- 9) Adjusting the starting fuel (minimizing exhaust gas)
 - (1) Crank speed switch ON → adjust crank speed to 800 rpm → turn the starting fuel potentiometer counterclockwise until the engine speed drops. → For the sake of stability, turn it another 15° in the clockwise direction.




CAUTION

If the amount of exhaust gas is not excessive when starting the engine, we recommend adjusting the starting fuel potentiometer to a higher setting in the 5 o'clock direction.

If set too low, startability worsens and immediately after starting the engine, overshoot may occur and cause the engine to exceed the set overspeed value.

- 10) When the engine will not start
 - (1) If there are no problems with the wiring connections \rightarrow adjust all control values to the "factory setting." (Refer to DV2213211A)
 - \rightarrow Restart the engine.
 - (2) If the problem is not resolved: There may be a problem with the controller hardware so replace the controller.



External Wiring Connections

- Refer to the wiring connection diagram to connect them.
- All wiring must be over the specified 1.5 mm² and be shielded.
- When using shielded wiring, all shielded wires not indicated on the wiring connection diagram must be grounded to the frame.
- 1. Twisted cables must be used for the actuator wiring.



IMPORTANT

After connecting the wiring, the resistance between A-B must be 3.5 \sim 4.5 Ω .

2. The cables for the magnetic speed sensor must be "shielded wires," and the shielded part must be connected to terminal D as well.



IMPORTANT

If this shielded part is grounded to the engine or not grounded, a distorted speed signal may be entered and cause problems such as hunting, so be sure to ground it.

3. Be careful not to reverse the polarity of the battery connected to terminals E and F, and be sure to install a 10 A fuse between the positive (+) battery terminal and terminal F.



IMPORTANT

After connecting them, be sure to check whether the voltage between the terminals is DC 24V (±4 V). Also, ground terminal E to the frame. (Wiring connection no.10)

- 4. Connect a 5 kW resistor externally as shown in the picture to enable the engine speed to be fine-tuned within a range of around "set speed ± 210 rpm."
- 5. When using a 12V battery or an actuator with a current consumption over 5 A, use a jumper to connect terminals G and H.
- 6. A selection switch for switching between the crank speed mode and run speed mode.
- 7. The droop mode selection switch.



IMPORTANT

ON (connected): droop mode / OFF (disconnected): isochronous mode

8. Connects the signal coming from the auxiliary device used in the parallel operating system to terminal N.



IMPORTANT

Use shielded wires.

9. Accessory power supply: Terminal P, which supplies rated power of +10[V], 20[mA], can be used as a power supply for external auxiliary devices and applied in a variety of different ways.



IMPORTANT

However, it should only be used within the range of the rated capacity. Be careful to avoid short circuits, and in the event that the capacity is exceeded, it may cause critical damage to the controller.



CAUTION

Incorrectly connected wires or abnormal battery voltage can cause critical damage to the controller so be sure to inspect them before use.


Mounting and Connecting the Magnetic Speed Sensor

- 1. The optimal gap between the magnetic speed sensor and ring gear is 0.45 mm. In order to achieve this, tighten the sensor until it makes contact with the ring gear, then turn it another 3/4 turns in the reverse direction to obtain a suitable gap.
- 2. The speed sensor signal can be checked by measuring the voltage (AC) between terminals C-D while the engine is running.
- 3. The sensor voltage applied to the controller must be over AC 3V.

Adjusting the Speed Externally

- By connecting the speed adjustment potentiometer externally as shown in the picture, you can adjust the engine speed remotely and externally within a certain speed range. Refer to the chart to set the resistance value according to the required speed range.
- 2. When the engine speed is set to the minimum speed in remote control mode, it causes a decrease in speed due to the instability and load on the system. Hence, when using the minimum speed setting, use the droop potentiometer to adjust the amount of droop to a low level (turning the potentiometer counterclockwise), thereby enabling engine stability to be maintained.

On the other hand, when the speed setting is at its highest, the governor runs almost isochronously regardless of the set droop value.



Speed Range	Potentiometer Value	Engine rpm Converted for Number of Ring Gears		
	value	160	152	146
900 Hz	1 K	337 rpm	355 rpm	370 rpm
2,400 Hz	5 K	900 rpm	947 rpm	986 rpm
3,000 Hz	10 K	1,125 rpm	1,184 rpm	1.230 rpm
3,500 Hz	25 K	1,315 rpm	1,381 rpm	1,438 rpm
3,700 Hz	50 K	1,387 rpm	1,460 rpm	1,520 rpm

3. State of adjustment at time of factory release

300611-00683		
Overspeed	1,725 rpm (based on 160 gear teeth)	
Run lamp	Maximum CW	
Gain	Mid-range (facing 12 o'clock)	
Stability Mid-range (facing 12 o'clock)		
Starting Fuel Full CW (Maximum Fuel)		
Speed Ramping Facing 9 o'clock		
Droop Full	CCW (Minimum)	
E.M. Speed Adjustment	(160 gear teeth)	
Speed Adjustment	4,000 Hz (1,500 rpm)	
Idle Adjustment 2,133 Hz (800 rpm)		

CW: Clockwise, CCW: Counterclockwise

300611-00684		
Overspeed	1,725 rpm (based on 160 gear teeth)	
Run lamp Maximum CW		
Gain Mid-range (facing 12 o'clock)		
Stability	Mid-range (facing 12 o'clock)	
Starting Fuel Full CW (Maximum Fuel)		
Speed Ramping	Facing 9 o'clock	
Droop Full	Full CCW (Minimum)	
E.M. Speed Adjustment	(160 gear teeth)	
Speed Adjustment	4,800 Hz (1,800 rpm)	
Idle Adjustment	2,133 Hz (800 rpm)	

CW: Clockwise, CCW: Counterclockwise

300611-00685		
Overspeed	2,070 rpm (based on 160 gear teeth)	
Run lamp	Maximum CW	
Gain	Mid-range (facing 12 o'clock)	
Stability	Mid-range (facing 12 o'clock)	
Starting Fuel	Full CW (Maximum Fuel)	
Speed Ramping	Facing 9 o'clock	
Droop Full	Full CCW (Minimum)	
E.M. Speed Adjustment	(152 gear teeth)	
Speed Adjustment	3,800 Hz (1,500 rpm)	
Idle Adjustment	2,026 Hz (800 rpm)	

CW: Clockwise, CCW: Counterclockwise

300611-00686		
Overspeed	2,070 rpm (based on 160 gear teeth)	
Run lamp	Maximum CW	
Gain Mid-range (facing 12 o'clock)		
Stability Mid-range (facing 12 o'clock)		
Starting Fuel	Full CW (Maximum Fuel)	
Speed Ramping	Facing 9 o'clock	
Droop Full	Full CCW (Minimum)	
E.M. Speed Adjustment	(152 gear teeth)	
Speed Adjustment	3,800 Hz (1,500 rpm)	
Idle Adjustment	2,026 Hz (800 rpm)	

CW: Clockwise, CCW: Counterclockwise

Droop Parallel Operating Mode (Manual Parallel)

Definition of droop: A reduction in the speed setting following an increase in the load

- Purpose of droop: Droop is used with the purpose of load sharing in the parallel operating system among generators.
- If there is no droop function in the parallel system, the generator may overload or motorize.
- Applying droop: In order to use droop, turn on the droop selection switch connected to terminals K-L.
- When in droop mode, the speed decreases due to an increased load, but you can use the "Droop" potentiometer (7) to determine the amount (%) of droop.



IMPORTANT

Turning it clockwise increases the amount of decrease. (Increases the amount (%) of droop) The amount of droop generally used is less than 10%. In order to maintain stability in speed droop governors, the minimum amount of droop required is at least 2.5%. The value of the rated speed already set based on the adjusted amount of droop can change so check the engine speed and readjust the speed as necessary.

Accessory Input (Automatic Parallel)

- Accessory terminal N receives signals from the load sharing unit, auto synchronizer or other accessories in the governor system.
- Use shielded wires when connecting wiring.
- The engine speed drops when an accessory is connected to terminal N so the speed adjustment potentiometer must be reset.
- When the control device is operating at the maximum acceptable frequency, a jumper or frequency trim
 control may be required between terminals G and J. When using this device, the acceptable frequency
 range of speed control is increased to over 7,000 Hz.

Controller Lamp Display (Diagnosis) Functions

- Power : The lamp turns on when a battery power supply is connected and an internal control voltage (DC 12V) has been generated. This means that the main controller is running.
- Pick Up : The lamp turns on when the magnetic speed sensor signal entering terminals C-D is over AC 3.0V.
- Crank : The lamp turns on and the relay activates when the set rated speed (crank speed) is reached.
- Run : The lamp turns on and the relay activates when the set rated speed (run speed) is reached.
- Overspeed: When the engine speed reaches the set overspeed, the lamp turns on, the relay activates and the actuator output is blocked.

System Troubleshooting (Instability)

- 1. Instability at rapid intervals (hunting): Applying SW D1 and D2
 - (1) The differential function activates when D1 is placed in the ON position.
 - (2) This can increase the responsiveness to changes in speed (rpm), thereby enabling quicker response to changes in speed.
 - (3) Slight hunting may occur at rapid intervals due to sensitive response to external frequency noise. In such cases, turn D1 off and readjust the gain and stability.
 - (4) If the instability persists in spite of doing so, turning off SW D2 on the device can help to stabilize the engine.
 - (5) After taking such measures, readjust the gain and stability again in order to optimize the system. This will help to reduce and eliminate instability.
- 2. Instability at slow intervals (hunting)

The main factors involved in hunting at slow intervals have many causes but generally, it occurs when tuning is not optimized due to the slight differences in mechanical characteristics in each engine. Such hunting can mostly be resolved by readjusting the gain and stability within the controller.



IMPORTANT

Refer to the information on the order of adjustment.

- 3) If the problem is not resolved with the methods above
 - (1) Loss of control function due to a fault in the controller itself replace the controller.
 - (2) Fault in an external mechanical device (actuator, fuel injection device, turbine, etc.) adjust the mechanical device.

When the System is Not Working

In the event that the engine governor system is not working properly, you can deduce the cause by performing the test in the following chart.

Here, (+) and (-) represent the polarities of the measuring instrument. Using the method in the chart below, if the test results are normal, there may be a problem in the actuator or the actuator wiring connections so the actuator must be inspected.

Step	Measured terminals	Time of measurement	Normal value	Presumed cause of fault	Troubleshooting	
1	F (+) & E (-)	E/G stopped	DC 24V	Battery failure	Check battery line,	
2	F (+) & E (-)	E/G starting	DC 15 or higher	Faulty connection	replace battery.	
3	C & D	E/G stopped	300 ~ 1,200 Ω using test ohm- meter	Defective speed sensor Damaged or incorrectly connected speed sensor wiring	Check sensor line. Replace speed sen-	
4	C & D	E/G starting	1.5V or higher when measured with tester AC voltmeter	Gap between speed sensor and ring gear too wide. Defective speed sensor	sor.	
5	A & B	E/G stopped	3.8 ~ 4.5 Ω using test ohm- meter	Check line for short circuit if measured value is less than 3.8 Ω Check line for open circuit if measured value is over 4.8 Ω Defective actuator	Check actuator line for short or open circuit. Replace actuator	
6	P (+) & G (-)	Key S/W ON	DC 9.5 ~ 10.5V	Faulty control device	Replace controller.	
7	F (+) & A (-)	While in operation	DC 9 ~ 15V when normal DC 1 ~ 3V when abnormal	Low speed setting. Short or open circuit in actuator wiring connection Actuator	Check speed settings. Check actuator line. Check actuator and replace if faulty.	

Digital Speed Controller

Product Overview and General Specification

1. Product information

Digital speed controller (DSC-1000) is applicable to generator (vehicles and vessels) engines as a high performance embedded electronic control system designed based on PID control for fast and precise control of engine speed with an enhanced micro controller unit (MCU) that minimizes analog circuits vulnerable to user environments.

This product features PID auto setting functions along with battery voltage, pick-up sensors and actuator condition checking. It also has a black box function that manages engine operation records when faults are detected for users to have more convenience in operating this precise digital speed controller.

Product features

- · Rigid and stable case structure and easily recognizable front design
- Readily understandable GUI (graphic user interface) with graphic LCD displays
- Easy and simple setup with 8 button keys without manual controls by users
- Fast setting available by migrating initial settings depending on types of the engines
- · Listing fault messages (over speed, pick-up error, etc.) and recording messages
- RS232 and CAN ports available for communication
- Digital inputs and PID auto setup functions for PID control parameters
- Application of digital clock for fault timing and engine operating hours


2. Product appearance

Digital Speed Controller is made of a rigid aluminum case taking into account anti-shock, electromagnetic resistance and environmental protection. An embedded system containing graphic LCD and high performance MCU is inside the controller and a heat sink is located on the outside of the case for protection and precise control of actuator operating elements.

A terminal block is located on the bottom and right of the front side for easy connection to external devices. Over speed, run and crank signals are displayed on the front LED and contact points (a or b) are also available for outputs on external controllers or indicators.


RS232 and CAN communication is available and DSUB-9 connector enables universal use of RS232 communication.

Users can easily input and adjust values for parameter inputs using 8 button keys. In addition, graphic LCD shows graphic displays, bar graphs and design symbols so that users can readily identify the control information while external LED displays important conditions of the engine.




3. Product specification

No.	Item	Description
1	MCU	16-bit DSC dsPIC33FJ256
2	Dioploy	Graphic LCD 128*64
2	Display	LED: 6 ea
3	Keypad	8 Button Keys
4	Output	3 Contact Points (a and b)
5	Input	RMS 3V (Min)
6	Memory	128 Mb
7	Communication	RS232 57600 bps
,	Communication	CAN (J1939)/250 kbps
8	Rated Power	DC 24V (12V ~ 30V)
9	Current Consumption	120 mA
10	Operating Temperature	-20 ~ 70°C
11	Storing Temperature	-30 ~ 80°C
12	Operating Humidity	0 ~ 95%



No.	Item	Part No.	Name
1	D-SUB Cable		
2	Pick It	850329-00502	Toolkit Cable
3	USB Cable		

4. Product system diagram




5. Product I/O signals

No.	Terminal	I/O Type	Terminal Functions
1	Actuator (A, B)	Output	Outputs are actuator control signals. Wiring should be 18AWG (105°C) or better. (However, terminals A and B can be used regardless of their polarities)
2	Pick-Up (C, D)	Input	Inputs are RPM sensor signals. Terminal D should be connected to the ground in connection with the shield cable. Gap between the RPM sensor and the gear tooth should be adjusted between 0.9 and 1.1 mm (sensor inputs should be at least 3V AC RMS).
3	Battery Voltage (-E, +F)	Input	It is a power input terminal for the controller and inputs are DC +24V/15A. The positive pole of the battery should be connected to the terminal F. (Back voltage protection circuit is built in.)
4	Crand	Input (G)	It has a ground signal and is connected to the ground of the potentiometer.
5	Speed Trim (G, H, J)	Input (H)	Inputs are RPM trim signal values and the voltage level is between 0 and 5V. It is connected to the output of the potentiometer.
6	(3,, 3)	Input (J)	Outputs are DC +5V and it is connected to VCC of the potentiometer.

No.	Terminal	I/O Type	Terminal Functions
7	Droop (K, L)	Input	Terminal K receives droop function selecting information. Terminal L has a ground signal and the switch is connected to terminals K and L. Once the terminal K is connected to the ground, droop starts to operate.
8	ldle (M)	Input	Terminal M receives idle function selection signals. Once it is connected to the ground, idle operation starts.
9	AUX (N)	Input	Terminal N receive load sharing and synchronization signal for parallel operation. The signal level is an input between DC -5 and +5V.
10	10V (P)	Output	Outputs are +10V/20 mA ratings and it can be used for various purposes including power to external auxiliary devices.
11	Crank Contact Point (1, 2, 3)	Output	The second crank contact point is a shared terminal while terminals 1 and 2 are for the contract point b and terminals 2 and 3 for the contact point a. The contact point a starts to operate when the digital speed controller reaches at the RPM delivering control signals to the actuator after the engine is activated.
12	Run Contact Point (4, 5, 6)	Output	The fifth run contact point is a shared terminal while terminals 4 and 5 are for the contact point b and terminals 5 and 6 for the contact point a. The contact point a starts to operate when the engine reaches its designated normal speed RPM.
13	Over Speed Contact Point (7, 8, 9)	Output	The eighth over speed contact point is a shared terminal while terminals 7 and 8 are for the contact point b and terminals 8 and 9 for the contact point a. The contact point a starts to operate when the engine reaches its designated over speed RPM.
14	CAN (10, 11)	I/O	Terminal 10 is for CAN-L communication and 11 is for CAN-H communication. CAN-H and CAN-L are used for CAN communication.
15	Power LED	Output	When DC+24 V power is supplied to the controller, the LED turns on in red on the power level.
16	Pick-Up LED	Output	When the controller receives normal input signals from the pick-up sensor, the LED turns on in red on the pick-up level.
17	Crank LED	Output	The 2- and 3-terminal contact point a starts to operate and the LED turns on in red on the crank level when the digital speed controller reaches at the RPM delivering control signals to the actuator after the engine is activated.
18	Run LED	Output	The LED turns on in red on the run level when the engine reaches its designated normal speed RPM with 5- and 6-terminal contact point a starting to operate.
19	Over Speed LED	Output	The LED turns on in red on the over speed level when the engine reaches its designated over speed RPM with 8- and 9-terminal contact point a starting to operate.
20	Error LED	Output	The LED turns on in red on the error level when abnormal events of the controller occur.
21	RS232	I/O	D-SUB 9PIN (male) is connected to the host through RS232 communication port.
22	Ground	Ground	The GND part and the ground should be earthed in shared connection.


6. Product dimension



Installation

Digital Speed Controller should be connected to the pick-up sensor attached on the engine and the actuator. Speed trim, droop, idle and aux terminals can be used for additional functions in connection with surrounding circuits. Contact points a or b can also be used to operate external devices using crank, run and over speed functions. RS232 and CAN port allow communication with PCs or external host computers for data transfer and monitoring functions.

- 1. Connecting to the engine
 - (1) Battery, pick-up and actuator connection diagram



(2) Connecting to batteries

Battery voltage is DC +24V and the battery is connected to the controller matching E (-) and F (+) with the respective polarities of the battery. E (-) is connected to (-) of the battery and F (+) to (+) of the battery. Depending on cases, wiring can be done in a serial connection to the contact point a of MC and the fuse (DC +24V/15 A) when connecting to system panels or generator control devices.

(3) Connecting to actuators

The actuator is also called governor and controls the amount of the fuel spray to the engine cylinder. The controller is connected to the actuator attached on the engine by connecting two wires of the controller terminal to A and B of the actuator regardless of their polarities. Wiring should be 18AWG (105°C) or better and the outside should be wrapped by plastic tubes for insulation or insulated mesh lines.


(4) Connecting to pick-up sensors

The pick-up sensor lets users know the engine speed and is connected to terminals C and D that can receive signals of AC RMS 3V or higher. Wiring should be twisted or shielded cables connected to the ground together with the terminal D. Gap between the pick-up sensor and the gear tooth should be adjusted between 0.9 and 1.1 mm.

- (5) Operating sequence for digital speed controller
 - Power On/Off: It means that DC +24V power is either supplied or terminated through E (-) and F
 (+) of the battery matching with their respective polarities.
 - LCD On/Off : It means to turn on or off the LCD display alone while DC +24V power is supplied through E (-) and F (+) of the battery matching with their respective polarities and the controller is in operation.


Operating sequence for the controller

- **Step 1)** When DC +24V power is supplied to the controller, the controller starts to operate. It indicates that power LED turns on and the power is being normally supplied.
- Step 2) Inputs for speed trim, droop and idle functions are received.
- **Step 3)** The controller checks the signals of the speed pick-up sensor.
- **Step 4)** Actuator control signals are output together with designated values of other information for crank, run and over speed functions according to the PID control values.
- **Step 5)** The controller checks the operation condition and displays LED outputs and fault messages according to the detected information.



2. Connecting to speed trim, droop, idle and other inputs

(1) Speed trim, droop, idle and other inputs diagram



(2) Connecting to speed trim

Speed trim is an analog voltage signal port for input to fine-tune the engine speed. A potentiometer is used for precise adjustment of the resistance values. The potentiometer needs to be connected to terminals G, H and J. Terminal G should be connected to the ground and it is recommended to use shielded cables. Terminal H is connected to G depending on the current consumption of the actuator (for actuators with 5A or higher). J is an input terminal for fine-tuned voltage values between 0 to 5V.

(3) Connecting to droop

The switch is connected to terminals K and L. Signals indicating whether droop function works or not serve as inputs to the controller by keeping K and L either open or close. Inputs can be done by toggle or converting switches.

(4) Connecting to idle

The port on one side of the switch is connected to terminal M and the port on the other side to the ground. Connection between terminal M and the ground becomes either open or close by keeping the switch open or close. When connection between the terminal and the ground becomes close, the controller will have idle function. Inputs can be done by toggle or converting switches.

(5) Connecting to aux

AUX is a terminal for control signal inputs from load sharing devices or synchronization devices through terminal N. It shares load from the generator in parallel operation and receives signal inputs from synchronization devices for the controller to control changes to load. Input signal level is between DC -5 and 5 V and it is recommended to use shielded cables for signal wires.

(6) Connecting power to external devices

It can supply power output of 10 V/20 mA to external devices through terminal P. Users can easily use this terminal when external auxiliary devices need power supply.


However, power supply of 20 mA or higher should not be used and care should be given to prevent short circuits.

3. Connecting to crank, run, over speed and communication

(1) Crank, run, over speed and communication connection diagram

It is used to deliver operation information to external devices by activating contact point (a or b) when activating crank, run or over speed functions.

RS232 and CAN communication is connected to external PCs or hosts so that the controller can transmit system settings or operation information.



(2) Connecting to crank terminals

Terminals 1, 2 and 3 are the ones for crank output contact point and the contact point will be in operation when the controller activates the crank function. The second crank contact point is a shared terminal while terminals 1 and 2 are for the contact point b and terminals 2 and 3 for the contact point a. Contact points a and b start to operate when the controller reaches at the RPM delivering control signals to the actuator after the engine is activated. The diagram shows wiring to operate AC220V lamp. The shared terminal is for 220V inputs and the crank lamp turns on when the contact point a starts to operate.

(3) Connecting to run terminals

Terminals 4, 5 and 6 are the ones for run output contact point and the contact point will be in operation when the controller activates the run function. The fifth crank contact point is a shared terminal while terminals 4 and 5 are for the contact point b and terminals 5 and 6 for the contact point a.

Contact points a and b start to operate when the engine reaches its designated normal speed RPM. The diagram shows wiring to operate AC220V lamp. The shared terminal is for 220V inputs the run lamp turns on when the contact point a starts to operate.

(4) Connecting to over speed

Terminals 7, 8 and 9 are the ones for over speed output contact point and the contact point will be in operation when the controller activates the over speed function. The eighth over speed contact point is a shared terminal while terminals 7 and 8 are for the contact point b and terminals 8 and 9 for the contact point a.

Contact points a and b start to operate when the engine reaches its designated over speed RPM. The diagram shows wiring to operate AC220V lamp. The shared terminal is for 220V inputs the over speed lamp turns on when the contact point a starts to operate.

(5) Connecting to CAN communication

Terminal 10 is for CAN-L communication and terminal 11 for CAN-H communication. CAN-H and CAN-L are used for CAN communication with remote control and monitoring of the controller operation. The communication code is based on J1939.

(6) Connecting to RS232 communication

D-SUB 9pin (female) is for RS232 communication for connection to external PCs or hosts. It can configure system parameters of the controller or communicate with analytic applications.

Configuration and Operation

The controller can be configured and operated by input keys according to the menus on the LCD display by selecting proper ones and assigning values in the selected menu to input control information to the system. Input information should immediately apply to the controller system once updated.


1. Input keys

The controller has 8 input keys including LCD, Mode, Menu, Enter, Up, Down, Left and Right. Each key as respective functions as follows:

LCD	LCD key turns on and off the display.	
Mode	Mode key switches the display to either operation mode or wave form display.	
Menu	Menu key lets users change the menu display and go back to the previous menu.	
Enter	Enter key applies designated values on the LCD display to the system.	
Δ	Up key lets users go up or increase values in the selected menu on the LCD display.	
∇	Down key lets users go down or decrease values in the selected menu on the display.	
	Left key lets users move to the left in the selected menu.	
\triangleright	Right key lets users move to the right in the selected menu.	

2. LCD display menu

The overall menu tree of the controller is as follows:




(1) LCD displays after powered on

When DC +24 V power is supplied to the battery terminal (E (-), F (+)) of the controller, the power LED in the front side of the controller turns on in red and the error LED turns on in red where there are fault conditions. At this moment, the LCD display is not activated and Hyundai Doosan Infracore logo will appear for 1 second followed by the operation display after pressing the LCD button.


The controller will start control based on information from pick-up sensor and other input devices and designated parameter values. At this moment, where breakdowns of the surrounding devices or system errors occur, the LCD display will show such errors and processing messages.

Step 1) DC +24V power supply to the terminals E (-) and F (+)

When DC +24V power is supplied to the terminals E (-) and F (+), the controller will start to operate with the LCD display off. After pressing the LCD button, Hyundai Doosan Infracore logo will appear for 1 second as shown below followed by the controller operation display. Then, the LCD display will switch between on and off by pressing the LCD button.




Step 2) The operation display will show 1 second after the logo appears.




(2) LCD main menu display

Displays main menu screen of the controller

The main menu of the controller has 10 sub-menus.





Main Menu of the Controller 1 to 2

EDL11160053

(1) Engine type

The controller can start operation once the initial system values are configured.

Users can load preset values depending on types of the engines by selecting the type.

(2) System setup

It consists of sub-menus related to system settings including RUN/IDLE/OVERSPEED/CRANK/ GEARNUMBER.

3 PID gain setup

It consists of sub-menus to designate Kp, Ki and Kd parameter values related to the engine PID control.

(4) PID auto setup

It offers function for automatic designation of Kp, Ki and Kd parameter values related to the engine PID control.

(5) Date/Time setup

It offers function for users to move to the screen for designating year, month, day and hour.

(6) Alarm list

It offers function for users to move to the alarm display for the alarm list.

(7) Actuator test

It offers menu to test the impedance (XL) of the actuator and any problems in operating load current. It displays current and voltage according to the duty values.

(8) Default setup

It offers menu to apply designated default values to the selected engine.

(9) System info

It offers menu that shows information of the controller. Such information includes the serial number, software version, last update date, alarm count and engine runs.

(10) LCD setup


It offers menu to configure LCD operating conditions including brightness, auto on/off and off hours.

(11) System monitor

It offers menu to monitor the controller operation. It shows values for Engine RPM, Valve Duty, Valve Current, Aux RPM Input, Pickup Voltage and Bat Voltage.


(3) Engine type setup menu

This menu offers function to configure setting values of the controller depending on types of the engines in advance and apply such preset values to the selected engine.



(4) System setup menu display of the controller

It consists of sub-menus for the system configuration items of the controller including the one for configuring RUN/IDLE/OVERSPEED/CRANK/GEAR NUMBER related to RPM setting. Depending on additional functions, users can designate values for STARTING FUEL/SPEED RAMPING/ACTUATOR MAX/LOW BATTERY.



1 Set run rpm

Users can designate normal speed (target RPM) of the engine.

Users need to input different normal speed values depending on the specification of the selected engine.

(2) Set idle rpm

Users can designate the idle speed values of the engine as RPM.

Users need to input values to control the idle operating speed of the engine.

(3) Set over speed

Users can designate RPM values to activate engine protection function when the speed exceeds the normal level (target RPM) and reaches the overspeed range that may cause problems to the engine.

When the engine RPM reaches the over speed RPM range, the engine immediately stops with error messages and alarms.

4 Cranking rpm

Users can designate RPM values to activate the actuator when the engine starts to operate.

(5) Gear number

Users can input the number of flywheel teeth in the engine to the controller so that the controller can calculate the accurate RPM depending on the values of the pick-up sensor from the engine.

6 Starting fuel

Users can designate the amount of fuels used when the engine starts to operate and the operating current for the controller to activate the actuator changes based on these values.

7 Aux. speed

Users can adjust values to ensure safe operation of the engine based on the AUX signal values when AUX is enabled.

8 Speed ramping

Users can input ratio values of speed changes when the speed increases or decreases in the idle condition of the engine.

(9) Max current

Users can designate the maximum operating current for the actuator of the engine.

10 Low battery

It measures the battery voltage supplied to the controller. When the measured values are lower than the present voltage values, it will be alarmed. Usually, the acceptable battery voltage is between 20 and 22V (without load).

11 Droop gain

Users can designate the droop values applicable to maximum load based on the current consumption of the actuator.

(12) F-load curr


Users can designate the maximum current values when the generator is in full load.

(13) N-load curr

Users can designate the operating current values of the actuator when the generator has no load.

(5) PID gain setup menu

Users can input Kp, Ki and Kd values as inputs to the PID control of the engine. Kp means proportional values while Ki means integral of the proportional values and Kd means differential of the proportional values.



(6) PID auto setup menu

The menu offers function for automatic designation of the P, I and D parameter values related to the engine PID control.


After starting the engine, select DRIVE UNIT MENU in the main menu while the engine has no load and then PID auto setup menu, press Enter. Then, the system message shows "Auto Setup Mode PID setting?" with YES or NO option. If you select YES, the controller will repeatedly change the RPM to automatically calculate the optimized P, I and D values.


If the controller identifies the optimized P, I and D values within 30 cycles, it will display "PID Auto Setup Complete, OK". When you press Enter, it will apply tuned P, I and D values and close the menu.

If the controller fails to identify the optimized P, I and D values within 30 cycles, it will display "PID No Successful, OK". When you press Enter, it will apply the final P, I and D values and close the menu.

(7) Date/Time setup menu


Users can designate year, month, day, hour and minute for the controller and the designated time will be used to monitor the system and manage fault messages.






(8) Alarm list menu

This menu displays year, month, day, hour and minute for the errors in the controller and types of the faults in codes which are used in troubleshooting.




(9) Default setup menu

When you cannot identify the type of the control engine by the controller, this menu offers the most common parameter setting values. For default setup, select YES and then press Enter button. If you don't want to implement this function, press No button. If you press YES, all the configuration values will be changed to the default ones of the engine.



(10)System info menu

The controller displays its information including the serial number, software version, last update date, alarm count and engine runs.



3. Engine configuration

(1) Engine type configuration


Users can store control setting information depending on types of the engines in the internal memory of the controller. If you select your engine type, applicable parameters will be automatically configured accordingly. This feature is available for 16 different types of engines.


Designated parameters by engine type (Configuration values by engine type)

No.	Menu Name	Run rpm	Over Speed	Gear Teeth	Starting Fuel	PID Value
1	DB58 1,500 rpm (50 Hz) 129T	1,500 rpm	1,725 rpm	129 65%		Optimal Value
2	DB58 1,800 rpm (60 Hz) 129T	1,800 rpm	2,070 rpm	129	65%	Optimal Value
3	DE08 1,500 rpm (50 Hz) 102T	1,500 rpm	1,725 rpm	102 65%		Optimal Value
4	DE08 1,800 rpm (60 Hz) 102T	1,800 rpm	2,070 rpm	102 65%		Optimal Value
5	DE08 1,500 rpm (50 Hz) 140T	1,500 rpm	1,725 rpm	140	65%	Optimal Value
6	DE08 1,800 rpm (60 Hz) 140T	1,800 rpm	2,070 rpm	140	65%	Optimal Value
7	DE08 1,500 rpm (50 Hz) 146T	1,500 rpm	1,725 rpm	146 65%		Optimal Value
8	DE08 1,800 rpm (60 Hz) 146T	1,800 rpm	2,070 rpm	146	65%	Optimal Value
9	DL11 1,500 rpm (50 Hz) 152T	1,500 rpm	1,725 rpm	152 65%		Optimal Value
10	DL11 1,800 rpm (60 Hz) 152T	1,800 rpm	2,070 rpm	152	65%	Optimal Value
11	DV15 1,500 rpm (50 Hz) 160T	1,500 rpm	1,725 rpm	160	65%	Optimal Value
12	DV15 1,800 rpm (60 Hz) 160T	1,800 rpm	2,070 rpm	160 65%		Optimal Value
13	DV18 1,500 rpm (50 Hz) 160T	1,500 rpm	1,725 rpm	160	65%	Optimal Value
14	DV18 1,800 rpm (60 Hz) 160T	1,800 rpm	2,070 rpm	160 65%		Optimal Value
15	DV22 1,500 rpm (50 Hz) 160T	1,500 rpm	1,725 rpm	160 65%		Optimal Value
16	DV22 1,800 rpm (60 Hz) 160T	1,800 rpm	2,070 rpm	160	65%	Optimal Value

Engine configuration procedure

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- Step 2) Select Engine Type by using Up and Down buttons in DRIVE UNIT MENU and then press Enter button.
- Step 3) Go to Engine Type Menu and select your engine type using Up and Down buttons. Then, press Enter button. At this moment, setting values according to the selected type of the engine are designated and will be used as information for the controller to control the actuator.






(2) System setup configuration

Main setting items of the controller includes GEAR NUMBER, CRANKING RPM and SET RUN RPM. You need to designate setting values to these items. Other system setup items are optional and therefore you can designate values for those items as necessary.

Configuring set run rpm

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select SET RUN RPM in SYSTEM SETUP menu and then press Enter button.


 Use Up and Down buttons to increase or decrease the normal operating speed of the engine and then press Enter button.



Configuring set idle rpm


- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select SET IDLE RPM in SYSTEM SETUP menu and then press Enter button.

 Use Up and Down buttons to increase or decrease the idle operating speed of the engine and then press Enter button.




Configuring set over speed

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select SET OVER SPEED in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to increase or decrease the over speed values of the engine and then press Enter button.



Configuring cranking rpm


- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select CRANKING RPM in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to increase or decrease the RPM values at which the controller starts to control the actuator when the engine starts to operate and then press Enter button.



Configuring gear number


- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select GEAR NUMBER in SYSTEM SETUP menu and then press Enter button.

 Use Up and Down buttons to increase or decrease the number of gear teeth in the engine and then press Enter button.




Configuring starting fuel

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select STARTING FUEL in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to increase or decrease the percentage for the amount of fuel sprayed when the engine starts and then press Enter button.



Configuring speed ramping


- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select SPEED RAMPING in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to increase or decrease the ratio of changes to the speed when increasing from the idle speed or decreasing from the increased speed and then press Enter button.



Configuring max current

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select MAX CURRENT in SYSTEM SETUP menu and then press Enter button.


 Use Up and Down buttons to increase or decrease the limit of the maximum current consumption of the actuator and then press Enter button (Max. 10 A).



Configuring low battery

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select LOW BATTERY in SYSTEM SETUP menu and then press Enter button.


 Use Up and Down buttons to input voltage values at which low battery alarms are activated and then press Enter button.



Configuring droop gain

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select DROOP GAIN in SYSTEM SETUP menu and then press Enter button.

 Use Up and Down buttons to increase or decrease the RPM values with adjusted ratio to decrease at the maximum load when the generator is in parallel operation and then press Enter button.




Droop Function

Droop function is indicated in percentages as follows: RPM with no load is subtracted by RPM with maximum load and then divided by RPM with no load.


(Example for 3% droop)

Assuming that RPM with no load is 1,800 and RPM with maximum load is 1,854 then the percentage will be 3%. It means that the generator output will be changed by 33.3% as the frequency changes by 1% due to the actuator control.




(Example for 7% droop)

Assuming that RPM with no load is 1,800 and RPM with maximum load is 1,926 then the percentage will be 5%. It means that the generator output will be changed by 14.3% as the frequency changes by 1% due to the actuator control.




F - load curr

- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select F LOAD CURR. in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to input the maximum current values of the actuator for the generator with full load and then press Enter button.



N - load curr


- Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.
- **Step 2)** Select System setup menu in DRIVE UNIT MENU using Up, Down, Left and Right buttons and then press Enter button.
- **Step 3)** Select N LOAD CURR. in SYSTEM SETUP menu and then press Enter button. Use Up and Down buttons to input the operating current values of the actuator for the generator with no load and then press Enter button.



(3) PID gain setup configuration


Configuring PID gain Kp, Ki and Kd values

- **Step 1)** Press Menu button of the controller and then you can see DRIVE UNIT MENU. Use Up, Down, Left and Right buttons to select PID gain setup menu and then press Enter button.
- **Step 2)** Use Up and Down buttons in PID GAIN SETUP to select PROPORTIONAL, INTEGRAL or DERIVATIVE and then press Enter button.




Configuring PID sampling time


- **Step 1)** Press Menu button of the controller and then you can see DRIVE UNIT MENU. Use Up, Down, Left and Right buttons to select PID gain setup menu and then press Enter button.
- **Step 2)** Use Up and Down buttons in PID GAIN SETUP to select SAMPLING TIME and then press Enter button. Use Up and Down buttons to input SAMPLING TIME values and then press Enter button.




- (4) PID auto setup value configuration
 - **Step 1)** Select your type in Engine Type menu and then start the engine with the preset configuration values maintaining it with no load.
 - **Step 2)** During the normal operation, press Menu button of the controller and then you can see DRIVE UNIT MENU. Use Up, Down, Left and Right buttons to select PID auto setup menu and then press Enter button.
 - **Step 3)** The menu offers function for automatic designation of the P, I and D parameter values related to the engine PID control. Select PID auto setup menu in DRIVE UNIT MENU and then press Enter button to see the system message "Auto Setup Mode PID setting?" with YES or NO options.




Step 4) Press YES and then the system message "PID AUTO SETUP MODE" will appear. As PID auto setup was initiated during the operation, PID auto tuning is already in progress.



- **Step 5)** PID tuning repeats a process to obtain PID values and a window to indicate whether the process succeeded or failed will appear in several minutes (approx. 4 to 6 minutes). If the process succeeded, the system message window will appear together with OK button. If you press Enter button, you will go back to normal operation window and the auto-tuned values will apply to the normal operation that will be continued.
- **Step 6)** If auto-tuning failed to identify optimized P, I and D values within 4 to 6 minutes, the system message window will display failure. If you press Enter button, you will go back to normal operation window. If you want to repeat the process, you need to start with Step 1 again.




- (5) Date/Time value configuration
 - **Step 1)** Press Menu button of the controller and then you can see DRIVE UNIT MENU. Use direction buttons to select Date/Time setup menu.
 - **Step 2)** Use Up, Down, Left and Right buttons to input year, month, day and hour and then press Enter button.



(6) Alarm list

- **Step 1)** Press Menu button of the controller and then you can see DRIVE UNIT MENU. Use direction buttons to select Alarm List menu and then press Enter button.
- Step 2) Use Up, Down, Left and Right buttons in ALARM LIST menu to confirm the fault messages.



Alarm code table

Alarm Code	Alarm Item	Description	Identified Alarm Out- put
E01	Battery Low	When the battery voltage continues to be lower than Low Battery voltage values for more than 5 seconds	LCD alarm message, Error LED lamp
E02	Battery High	When the battery maintains its voltage exceeding 30VDC for more than 5 seconds	LCD alarm message, Error LED lamp
E03	Pick-up Error	Problems in sensor signals when the engine starts (Engine RPM lower than 600)	LCD alarm message, Error LED lamp
E04	Pick-up Error	Pick-up Error Problems in sensor signals during the engine operation (Engine RPM 600 or higher)	
E05	Actuator Current Short		
E06	Actuator Current Broken	Short-circuits in the actuator or the connecting circuits	LCD alarm message, Error LED lamp
E07	Over Speed Engine RPM exceeding the configured over speed values		LCD alarm message, Error LED lamp
E08	FET Drive Error	Damages to components in the actuator output section inside the controller	LCD alarm message, Error LED lamp


(7) Actuator test

The menu offers function to test whether there is any problem in operating load current of the actuator attached to the engine. It indicates voltage and current for on/off.

(8) Default setup functions

- **Step 1)** Press menu button of the controller and then you can see DRIVE UNIT MENU.

 Use Up, Down, Left and Right buttons to select Default setup menu and then press Enter button.
 - At this moment, the system message "Initialization system setting?" will appear.
- **Step 2)** Use Left and Right buttons to select either YES or NO in System Message and then press Enter button.




Default setup will change the configuration values of the engine to the default values. In order to initiate default setup, you need to select YES and then press Enter button. Press No button if you don't want to.

(9) System info functions

Step 1) Press menu button of the controller and then you can see DRIVE UNIT MENU.

Use Up, Down, Left and Right buttons to select System info menu and then press Enter button.




The menu displays information of the controller and the information includes the serial number, software version, last update date, alarm count and engine runs.

(10) LCD setup functions

- **Step 1)** Press Menu button of the controller and then you can see DRIVE UNIT MENU.

 Use Up, Down, Left and Right buttons to select LCD setup menu and then press Enter button.
- **Step 2)** Use Up and Down buttons to select menus including LCD BRIGHTNESS and LCD CONTRAST for adjustment and then press Enter button. Use Up and Down buttons to input setting values and then press Enter button.



(11) System monitor Functions

button.

Step 1) Press Menu button of the controller and then you can see DRIVE UNIT MENU.

Use Up, Down, Left and Right buttons to select System monitor menu and then press Enter

It offers menu to monitor the controller operation. It shows values for Engine RPM, Valve Duty, Valve Current, Aux RPM Input, Pickup Voltage and Bat Voltage.

4. How to operate

- (1) Operating sequence for digital speed controller
 - Step 1) Supply DC +24V power to the battery terminals (E (-), F (+)) of the controller.
 - **Step 2)** Configure parameter values required for selection of the engine type and control of the engine.
 - **Step 3)** Install the controller on the generator system and complete circuit wiring.
 - **Step 4)** The controller will activate the actuator with power supply and pick-up sensor input.
- (2) Detailed operating sequence
 - **Step 1)** Supply DC +24 V power to the battery terminals (E (-), F (+)) of the controller.

Power supply to the controller can be done by direct connection to the battery or power supply controlled by external control devices. Fuses (15 A/24V) are required for power supply to the controller through the terminal.

When the controller displays Low Battery Fault message, you need to charge the battery or replace it with the one having normal voltage before starting the controller.

Step 2) Configure parameter values required for selection of the engine type and control of the engine.

There are 3 ways to configure parameters required for the controller:

- 1. Using default setup
- 2. Designating the engine type in Engine Type menu
- 3. Configuring each parameter in System setup menu

For more information, see Chapter 3. Configuration and Operation.

- **Step 3)** Install the controller on the generator system and complete circuit wiring.

 Once the configuration is completed, the controller will be in Stand By condition preparing to receive input information from pick-up sensor and surrounding terminals and operate.
- **Step 4)** The controller will activate the actuator with power supply and pick-up sensor input. When the power is supplied and the pick-up terminal delivers normal sensor inputs as the engine starts, the controller activate the actuator.

Troubleshooting

1. Alarm list check

Where there are problems in the system operation, you need to review the alarm list menu of the controller and then check the engine and the system in reference to the alarm codes.

Alarm Code	Alarm Item	Alarm Condition	Output Control	Measures	
	Battery Low	When the battery voltage continues to be lower than Low Battery voltage values for more than 5 seconds	LCD alarm message	Check the battery line	
E01			Error LED lamp	Replace the battery	
E02	Battery High	When the battery maintains its voltage exceeding 30V DC for more than 5 seconds	Alarm message pop-up on LCD	Check the battery line	
			Error LED on	Replace the battery	
E03	Pick-up Error	Problems in sensor signals when the engine starts.(Engine RPM lower than 600)	Alarm message pop-up on LCD	Check the RPM sensor and connecting circuits	
			Error LED on	Replace the RPM sensor	
			Actuator control signal off		
	Pick-up Error	Problems in sensor signals during the engine operation (Engine RPM 600 or higher)	Alarm message pop-up on LCD	Check the RPM sensor and connecting circuits	
E04			Error LED on	Replace the RPM sensor	
			Actuator control signal off		
E05	Actuator Current Open	Disconnection in the actuator or the connecting circuits	Alarm message pop-up on LCD	Check the disconnection in the actuator and connecting circuits	
			Error LED on	Replace the actuator	
E06	Actuator Current short	Short-circuits in the actuator or the connecting circuits	Alarm message pop-up on LCD	Check the disconnection in the actuator and connecting circuits	
			Error LED on	Replace the actuator	
E07	Over Speed	Engine RPM exceeding the configured over speed values	Alarm message pop-up on LCD	Check the speed setting	
			Error LED on	Adjust PID setting values	
			Actuator control off		
	FET Drive Error	Damages to components in the actuator output section inside the controller	Alarm message pop-up on LCD	Check the actuator and connecting circuits	
E08			Error LED on	Replace the controller	
			Actuator output power cutoff		

- (1) When problems described in alarm codes E03, E04, E07 or E08 occur, the engine is not available for safe operation and therefore the engine will stop as the controller will turn off the actuator for safety.
- (2) When problems described in alarm codes E03, E04, E07 or E08 occur, the engine will not be able to restart as long as the alarm is not released.
- (3) When alarms occur, you can release them by turning off the power of the controller.

2. System checks and measures

For initial installation, it is recommended for you to check any disconnection in circuits before taking measures described here (see Chapter 2. Installation for how to install the controller).

You can check the controller for failure diagnosis in accordance with the following procedure.

- **Step 1)** Check the battery voltage whether it is higher than the Low Voltage setting value.

 If normal, supply power to the controller and then operate it. If the voltage is lower than the setting value, you need to charge the battery or replace it before operating the system.
- **Step 2)** Check the input resistance in the DC +24V input terminals (-E, +F) of the battery whether the resistance is higher than approx. 10K Ohm. If the resistance does not meet this condition, do not supply power to the controller and contact our A/S center for service request.
- **Step 3)** Check whether the power LED turns on or not after supplying power to DC +24V input terminals (-E, +F) of the battery. If the LED does not turn on, cut the power off and contact our A/S center for service request.
- Step 4) Check whether the power LED turns on and Hyundai Doosan Infracore logo appears on the LCD display after supplying power to DC +24V input terminals (-E, +F) of the battery.
 If you cannot see the logo, press LCD key button to check the LCD display once again.
 If you cannot still see the logo, cut the power off and contact our A/S center for service request.
- Step 5) Check the controller terminals (C & D) with AC meter or oscilloscope to check whether signal inputs of AC RMS 3V or higher are detected. If no signal detected, check whether the pick-up sensor maintains the gap between 0.9 and 1.1 mm and then check whether the pick-up sensor has resistance of 110 Ohms (±10%). If you cannot still detect no signal, replace the pick-up sensor and then operate the controller.